

Digital Panel Meters 40 Series

DC INPUT DIGITAL PANEL METER

(4 digits, process meter)

Model: 40DV

OPERATING MANUAL

CONTENTS

1. INTRODUCTION.....	4
1.1 BEFORE USE.....	4
1.2 SAFETY PRECAUTIONS (that must be observed).....	5
1.3 POINTS OF CAUTION.....	7
1.4 COMPONENT IDENTIFICATION.....	8
1.5 INSTALLATION.....	10
1.5.1 EXTERNAL DIMENSIONS	10
1.5.2 PANEL CUTOUT DIMENSIONS	10
1.5.3 INSTALLATION	11
1.6 WIRING INSTRUCTIONS	12
1.6.1 CAUTION IN WIRING	12
1.6.2 RECOMMENDED SOLDERLESS TERMINAL.....	12
1.6.3 TERMINAL ASSIGNMENT.....	12
1.6.4 WIRING INPUT SIGNAL.....	13
1.6.5 WIRING HOLD INPUT	14
1.6.6 WIRING POWER	15
1.6.7 ATTACHING/REMOVING TERMINAL COVER	16
2. BASIC SETTING AND OPERATION.....	17
2.1 BASIC SETTING	17
2.1.1 BASIC SETTING FLOW.....	17
2.1.2 MOUNTING/REMOVING FRONT PANEL	17
2.1.3 BASIC SETTING PROCEDURE.....	18
2.2 BASIC SETTING OPERATION AND INSTRUCTIONS	20
2.2.1 BASIC SETTING OPERATION.....	20
2.2.2 INSTRUCTIONS ON BASIC OPERATION.....	22
3. SETTING DISPLAY SCALING	23
3.1 STEP 1. DISPLAY SCALING VALUE A.....	27
3.1.1 DISPLAY SCALING LIST	27
3.1.2 OPERATING PROCEDURE	28
3.2 STEP 2. DISPLAY SCALING VALUE B	30
3.2.1 OPERATING PROCEDURE	30
3.3 STEP 3. DECIMAL POINT POSITION	32
3.3.1 DECIMAL POINT POSITION LIST	32
3.3.2 OPERATING PROCEDURE	33
4. OPERATION	35
5. PARAMETER CONFIGURATION.....	36

6. AVERAGING INPUT	37
6.1 OPERATING PROCEDURE.....	38
7. ADJUSTING BRIGHTNESS OF DISPLAY	39
7.1 OPERATING PROCEDURE.....	40
8. HOLDING DISPLAY	42
9. USER CALIBRATION.....	43
10. INSPECTION / CLEANING	44
11. TROUBLESHOOTING.....	45
11.1 ERROR MESSAGES.....	45
11.2 INITIALIZING SETTING VALUES.....	46
11.2.1 OPERATING PROCEDURE.....	46
11.3 CONFIRMING FIRMWARE VERSION.....	48
11.3.1 OPERATING PROCEDURE.....	48
12. APPENDICES.....	49
12.1 SPECIFICATIONS	49
12.2 MODEL NUMBERING	52
12.3 PARAMETER LIST	53
12.4 PARAMETER MAP	54
12.4.1 SCALING SETTING MODE.....	54
12.4.2 DISPLAY SETTING MODE	54
12.5 CHARACTER SET	55


1. INTRODUCTION

1.1 BEFORE USE....

Thank you for choosing us. Before use, please check contents of the package you received as outlined below.

■ PACKAGE INCLUDES

Digital panel meter



Accessories

Mounting bracket (2)	Engineering unit sticker label sheet (1)	Instruction manual
Ordering Information Sheet		(included with the option code '/SET' only)

■ MODEL NO.

Confirm Model No. marking on the product to be exactly what you ordered.

1.2 SAFETY PRECAUTIONS (that must be observed)

The following signs are used in this manual to provide precautions required to ensure safe usage of the unit. Please understand these signs and graphic symbols, read the manual carefully and observe the description.

The following signs show seriousness of safety hazard or damage occurred when used wrongly with the signs ignored.

! WARNING	Indicates a potentially hazardous situation which, if not avoided, may result in serious injury or death.	
! CAUTION	Indicates a potentially hazardous situation which, if not avoided, may result in injury or in property damage.	
 Indicates prohibitions.	 Indicates mandatory cautions.	 Indicates cautions.

! WARNING



CAUTION

For safety, make sure that wiring is performed by qualified personnel only.
• Failure to do so may result in a fire, electric shock or injury.



CAUTION
ELECTRIC SHOCK

Do not touch the terminals while the power is on.
• Doing so may result in electric shock.



CAUTION
ELECTRIC SHOCK

Do not touch anything except for the buttons in removing the front panel.
• Doing so may result in malfunction or electric shock.



MANDATORY
CAUTION

Check the connection diagram carefully before wire connection.
• Failure to do so may result in malfunction, a fire or electric shock.



MANDATORY
CAUTION

Provide safety measures outside of the unit to ensure safety in the whole system if an abnormality occurs due to malfunction of the unit or another external factor affecting the unit's operation.



PROHIBITION
TO BE WET

Do not splash water on the unit.
• Doing so may result in a fire, electric shock or injury.



MANDATORY
CAUTION

Stop using the unit immediately if smokes, unusual smell or abnormal noises come(s) from it.
• Using the unit continuously may result in a fire or electric shock.



Stop using the unit if it is dropped or damaged.
• Using the unit continuously may result in a fire or electric shock.

MANDATORY
CAUTION



Tighten the terminal block with a specified torque.
• Excessive fastening may result in damage of the terminal screws and loose screws may occasionally result in ignition.

MANDATORY
CAUTION



Do not throw the unit into the fire.
• Doing so may result in rupture of the electronic component.

PROHIBITION

⚠ CAUTION



Never discompose or remodel the unit.
• Doing so may result in electric shock, malfunction or injury.

PROHIBITION
TO DISCOMPOSE



Do not connect or remove the unit while its power is on.
• Doing so may result in electric shock, malfunction or injury.

PROHIBITION



Do not allow fine shavings or wire scraps to enter the unit in machining screws or wiring.
• Doing so may result in malfunction of the unit.

MANDATORY
CAUTION



Make sure to attach the terminal cover.
• Failure to do so may result in electric shock.

MANDATORY
CAUTION



Do not remove the front panel except in setting parameters.
• Doing so may result in malfunction due to mixing of foreign substances.

MANDATORY
CAUTION



Be aware of static electricity in operating buttons.
• Failure to do so may result in malfunction.

MANDATORY
CAUTION



Do not pull the wires connecting to the unit.
• Doing so may result in electric shock, damage of the unit or injury.

PROHIBITION



Do not use the unit in an atmosphere where combustible gas is present.
• Doing so may result in inflammation, ignition, or smoke.

PROHIBITION



Do not cover the ventilation slits with cables, etc.
• Doing so may result in malfunction or heating.

PROHIBITION

1.3 POINTS OF CAUTION

■ CONFORMITY WITH EU DIRECTIVES

- This equipment is suitable for Pollution Degree 2, Measurement Category I (input, transient voltage 1500 V) and Installation Category II (transient voltage 2500 V). Reinforced insulation (input to power: 300 V) is maintained. Prior to installation, check that the insulation class of this unit satisfies the system requirements.
- The equipment must be installed such that appropriate clearance and creepage distances are maintained to conform to CE requirements. Failure to observe these requirements may invalidate the CE conformance.
- Our products conforming to the EU Directives conforms to the standards required based on the premise that they are built into various equipment, apparatus or control panels to use. Because the EMC performance depends on the configuration, wiring or arrangement of the equipment, apparatus and control panels you build, it is necessary for you to make such equipment, apparatus or control panels to conform finally to the CE Marking by yourselves.

CAUTION

This product conforms to the EMC Directive for electrical and electronic apparatus intended for use in industrial environments. If it is used in the residential environments, it may cause radio interference, and the user is requested to take appropriate measures.

■ ENVIRONMENT

Install the unit within the installation specifications.

- Indoors use.
- Environmental temperature must be within -10 to +55°C (14 to 131°F) with relative humidity within 30 to 90% RH without condensing.
- Altitude up to 2000 meters.
- Provide sufficient space around the unit for heat dissipation.
- Mount the unit to a panel between 1.6 and 8 mm thick.
- Install the unit in a well-ventilated place in order to prevent internal temperature rise.
- Refer to "PANEL CUTOUT" to install several units. In mounting the unit with other equipment side by side, provide sufficient space between them, according to the dimensions in the panel cutout.
- Do not use the unit under the following environments:
 - Where the unit is exposed to direct sunlight, rain or wind. (The unit is not designed for outdoor use.)
 - Where condensation may occur due to extreme temperature changes.
 - Where corrosive or flammable gas is present.
 - Where heavy dust, iron powder or salt is present in the air.
 - Where organic solvent such like benzine, thinner, and alcohol, or strong alkaline materials such like ammonia and caustic soda may attach to the unit, or where such materials are present in the air.
 - Where the unit is subject to continuous vibration or physical impact.
 - Where there are high-voltage lines, high-voltage equipment, power lines, power equipment, equipment with transmission unit such like a ham radio equipment, or equipment generating large switching surges around the unit.

■ WIRING

- In order to prevent potential electric shock, wire the unit after turning off the power supply and making sure that the power is not supplied to the cable.
- In order to enable the operator to turn off the power input immediately, install a switch or a circuit breaker according to the relevant requirements in IEC 60947-2 and properly indicate it.
- Be sure to confirm the name and polarity of each terminal before wiring to the terminal block.
- Do not connect anything to unused terminals.
- Be sure to attach the terminal cover to prevent electric shock.


■ HANDLING CAUTIONS

- The unit is designed to function as soon as power is supplied, however, a warm up for 10 minutes is required for satisfying complete performance described in the data sheet.
- Use the unit within the noted supply power voltage and rated load.
- Clean the surface of the unit with wet soft cloth. Do not use organic solvent such like benzine, thinner and alcohol. Doing so may result in deformation or discoloration of the unit.
- When abnormality is found such like smokes, unusual smell and abnormal noises coming from the unit, immediately cut the power supply and stop using it.

1.4 COMPONENT IDENTIFICATION

■ FRONT VIEW

• With Front Panel




NOTE

- The engineering unit sticker label position is our recommended position.
- When an engineering unit is specified by the Ordering Information Sheet, the unit(s) will be shipped with the sticker label put on the above position.


• Without Front Panel

COMPONENT	FUNCTION	COMPONENT	FUNCTION
Polarity indicator	Turns on when negative value is displayed.	4-digit display	Indicates present value, setting value and scaling error. Range: 0 to 9999



BUTTON	FUNCTION
DISP/↓	Used to move on to the display setting mode; or to shift through setting items in each setting mode.
SCALE/↑	Used to move on to the scaling setting mode; or to shift through setting items in each setting mode.
SHIFT	Used to move on to the setting standby status of each setting mode and to shift through display digits in each setting item.
UP	Used to change setting values in a setting standby mode.

■ TOP VIEW




NOTE

- Contents of the specification label depend on the specifications.
- The tag No. label sticker position is our recommended position.
- When a tag No. is specified, the unit(s) will be shipped with the tag No. sticker label put on the above position. Max. 17 alphanumeric characters can be specified. Please consult us.

1.5 INSTALLATION


1.5.1 EXTERNAL DIMENSIONS

■ TOP VIEW




unit: mm [inch]


■ FRONT VIEW




■ SIDE VIEW



■ REAR VIEW



1.5.2 PANEL CUTOUT DIMENSIONS




unit: mm

Panel thickness: 1.6 to 8.0 mm


1.5.3 INSTALLATION

(1) Remove the mounting brackets.


- Flip a tab of a bracket.
- Then pull the bracket toward the terminal block to remove it.



(2) Insert the unit into the panel cutout.



(3) Push the mounting brackets into the grooves on both sides of the rear module, until they hit the panel's rear side.



1.6 WIRING INSTRUCTIONS


1.6.1 CAUTION IN WIRING

- For safety, make sure that wiring is performed by qualified personnel only.
- In order to prevent potential electric shock, wire the unit after turning off the power supply and making sure that the power is not supplied to the cable.
- Be sure to confirm the name and polarity of each terminal before wiring to it.
- Do not connect anything to unused terminals.
- We offer a series of lightning surge protectors for protection against induced lightning surges. Please contact us to choose appropriate models.

1.6.2 RECOMMENDED SOLDERLESS TERMINAL

- Use solderless terminals for M3. Refer to the drawings below.

unit: mm [inch]



Applicable wire size: 0.25 to 1.65 mm²


Torque: 0.6 N·m

Recommended manufacturer: Japan Solderless Terminal MFG. Co., Ltd., Nichifu Co., Ltd.


IMPORTANT

- Insulated solderless terminals are recommended.
- In using non-insulated solderless terminals, cover them with insulating caps or tubes.
- Ring tongue terminals are recommended rather than spade tongue terminals to prevent from falling off.

1.6.3 TERMINAL ASSIGNMENT




1.6.4 WIRING INPUT SIGNAL




Connect DC voltage or current signal wires.

IMPORTANT

- Be sure to confirm the input polarity in wiring. Wrong connection may result in malfunction of the unit.
- In order to prevent potential electric shock, wire the unit after cutting the input signal and making sure that the power is not supplied to the cable.
- Take measures to reduce noise as much as possible, e.g. by using shielded twisted pair wires for the input signal.
Ground the input shield to the most stable earth to prevent noise troubles.
- Do not connect anything to unused terminals.



1.6.5 WIRING HOLD INPUT




Displayed value is held with an external HOLD command input.
Connect the contact across HOLD to COM as shown in the following figure.
Close the contact to hold the value.

Detecting voltage	Approx. 2.1 V DC, 0.03 mA
Detecting level	≤ 0.8 V


IMPORTANT

- Be sure to confirm the input polarity in wiring.
- The HOLD input is not isolated from the internal circuit.




■ WIRING EXAMPLES


(a) Transistor



(b) Photo-Coupler




(c) Relay



Terminals 3 and 4 are NOT isolated from the internal circuit.

1.6.6 WIRING POWER




Connect power according to the power input code. The power specifications are shown in the following table.

CODE	RATING	PERMISSIBLE RANGE
K3	100 to 120 V AC	85 to 132 V AC, 47 – 66 Hz approx. 1.6 VA
L3	200 to 240 V AC	170 to 264 V AC, 47 – 66 Hz approx. 1.0 VA
R	24 V DC	±20% approx. 0.5 W


IMPORTANT

- For safety, make sure that wiring is performed by qualified personnel only.
- In order to prevent potential electric shock, wire the unit after turning off the power supply and making sure that the power is not supplied to the cable.
- Use wires as thick as possible and twist them from the end.
- For DC power, confirm the polarity.



1.6.7 ATTACHING/REMOVING TERMINAL COVER

Attach the terminal cover for safety after wiring.



2. BASIC SETTING AND OPERATION


2.1 BASIC SETTING

This section describes flow and procedure of the basic setting.

The following shows the flow and procedure to set the input to 4 – 20 mA DC and the display to 0.0 – 100.0% as an example.

2.1.1 BASIC SETTING FLOW

The basic setting is as shown in the following flowchart.




2.1.2 MOUNTING/REMOVING FRONT PANEL


- Set parameters with the buttons inside the front panel. Remove the panel in setting.
- Mount the panel after configuration.

■ REMOVING FRONT PANEL

(1) Hold up the front panel.




(2) Remove the panel from downside.




■ MOUNTING FRONT PANEL

(1) Insert the front panel hook into the case upside slots of the unit.



(2) Push the panel hook into the case downside slots of the unit.



NOTE

- Be sure to confirm the direction of the front panel in mounting.
- Make sure that there is no misalignment or space between the unit and the panel after mounting.

2.1.3 BASIC SETTING PROCEDURE

The following shows the procedure to set the display to 0.0 – 100.0% with the input code A/ 4 – 20 mA input as an example. Set values (after calculating if necessary) meeting signals of equipment to use. Refer to 3. SETTING DISPLAY SCALING for details of setting.

■ PARAMETER LIST FOR BASIC SETTING

Parameters used in the basic setting are as shown in the following table.

PARAMETER	SETTING VALUE	SETTING
Display scaling value A	0000 ^{*1}	0% display: 0.0%
Display scaling value B	1000 ^{*1}	100% display: 100.0%
Decimal point position	888.8	1 decimal place (10 ⁻¹)

*1 The decimal point position depends on the decimal point position setting.

■ BASIC SETTING PROCEDURE

The basic setting procedure is as follows.

1 Confirm the wiring, turn on the power and move on to Scaling Setting Mode (measurement stopped).

- Hold down SCALE/↑ button for 3 seconds or more.

2 Set display scaling value A.

- Press SHIFT button to shift the display into the setting standby mode.
- Press SHIFT button to go to the next digit and UP button to change the blinking value.

3 Set display scaling value B.

- Press Disp/↓ or SCALE/↑ button to apply the new setting and go to the next or previous parameter setting.
- Press SHIFT button to shift the display into the setting standby mode.
- Press SHIFT button to go to the next digit and UP button to change the blinking value.

4 Set decimal point position.

- Press Disp/↓ or SCALE/↑ button to apply the new setting and go to the next or previous parameter setting.
- Press SHIFT button to shift the display into the setting standby mode and UP button to select the decimal point position.

5 Return to Measuring Mode (measurement started).

- Hold down Disp/↓ or SCALE/↑ button for 1 second or more to apply the new setting and return to Measuring Mode.

2.2 BASIC SETTING OPERATION AND INSTRUCTIONS

This section describes basic operation and instructions when setting parameters.

2.2.1 BASIC SETTING OPERATION

Parameters can be grouped into three setting types, “numerical value setting”, “setting value selection” and “decimal point position selection”. Basic operation of each type is as shown below.

■ NUMERICAL VALUE SETTING

1 Press SHIFT button to shift the display into the setting standby mode.

- The 4th digit starts blinking.



2 Press SHIFT and UP buttons to set a numerical value.

- Press SHIFT button to go to the next digit.
- Press UP button to change the blinking value.



3 Press DISP/↓ or SCALE/↑ button to apply the new setting.

- The next or previous parameter setting is indicated.



*1 Display depends on the settings.

NOTE

■ SHIFTING DIGITS

Each time pressing SHIFT button, the blinking digit moves to the right.



■ SETTING A NUMERICAL VALUE

- Each time pressing UP button, the numeral is incremented by 1.
- The negative sign (-) must be set together with the 4th digit. For example, set '-04.00' instead of '-4.00'.

- 4th digit



- Other digits




■ SETTING VALUE SELECTION

1 Press SHIFT button to shift the display into the setting standby mode.

- The current set value starts blinking.




2 Press UP button to select your desired setting value.



3 Press DISP/↓ or SCALE/↑ button to apply the new setting.

- The next or previous parameter setting is indicated.




*1 Display depends on the settings.

■ DECIMAL POINT POSITION SELECTION

1 Press SHIFT button to shift the display into the setting standby mode.

- The current set value starts blinking.



2 Press UP button to select a desired decimal point position.



3 Press DISP/↓ or SCALE/↑ button to apply the new setting.

- The next or previous parameter setting is indicated.




*1 Display depends on the settings.

NOTE

■ MOVING THE DECIMAL POINT

Pressing UP button moves the decimal point one place to the left.



■ DECIMAL POINT POSITION

"No decimal point" to "3 decimal places" can be selected in the decimal point position setting.

SETTING VALUE	FUNCTION	SETTING VALUE	FUNCTION
[0000]	No decimal point	[0000]	2 decimal places (10^{-2})
[0000]	1 decimal place (10^{-1})	[0000]	3 decimal places (10^{-3})

2.2.2 INSTRUCTIONS ON BASIC OPERATION

■ IF THE FRONT BUTTONS ARE LEFT UNTouched...

- The indication turns on with applying the last changes after approximately 1 minute while it is in the setting standby mode.
- The display goes back automatically to Measuring Mode after approximately 1 minute in one of the other modes.

■ TO ABORT A SETTING...

- Hold down SHIFT button for 3 seconds or more to return to Measuring Mode without applying the last changes while the display is in the setting standby mode.
- If you get lost in a setting mode, you can execute initialization. Refer to 11.2 INITIALIZING SETTING VALUES.

3. SETTING DISPLAY SCALING

■ DISPLAY SCALING


Set display scaling within the range of -9999 to 9999 for measurement range (conformance range).

The display scaling values include A and B. A decimal point can be set in any position.


- Display scaling value A is a display value for the measurement range 0%.
- Display scaling value B is a display value for the measurement range 100%.
- Decimal point position can be set in common for both display scaling value A and B.

e.g. Input code 'A3' ±19.99 mA DC, to display ±19.99 mA DC input as 0.0 – 100.0%

Measurement range 0%	-19.99 mA DC
Measurement range 100%	+19.99 mA DC
Input signal 0%	-19.99 mA DC
Input signal 100%	+19.99 mA DC
Display scaling value A	0.0%
Display scaling value B	100.0%
Decimal point position	888.8 (1 decimal place)



When the input signal is other than the measurement range (e.g. using 0 – 10 mA DC input with the input code 'A3' ±19.99 mA DC), obtain the values parallel shifted from the desired display values for the input signal to the measurement range 0% and 100%. Set the obtained values as display scaling value A and B.




The next paragraph describes how to calculate the display scaling value A and B when the input is other than the measurement range.

■ CALCULATION OF DISPLAY SCALING WITH INPUT OTHER THAN MEASUREMENT RANGE

Refer to the following examples to calculate the display scaling value A and B when the input is other than the measurement range.

Example 1: 40DV-A3-x

Measurement range	$\pm 19.99 \text{ mA DC}$
Input signal	0 – 20 mA DC
Desired display value	0.0 – 100.0%



Calculate the display scaling value A and B with the following formulas.

$$SA = \frac{Rz \times Dspan + Dz \times Is - Ds \times Iz}{Ispan}$$

Rz Measurement range 0%

Rs Measurement range 100%

Iz Input signal 0%

Is Input signal 100%

Dz Desired display value 0%

Ds Desired display value 100%

Ispan Input span ($Is - Iz$)

Dspan Display span ($Ds - Dz$)

SA Display scaling value A

SB Display scaling value B

$$SB = \frac{Rs \times Dspan + Dz \times Is - Ds \times Iz}{Ispan}$$

(1) Display scaling value A (SA)

In the above formulas, omit the decimal point for the desired display values.

$$Ispan = 20 - 0 = 20$$

$$Dspan = 1000 - 0 = 1000$$

$$SA = \frac{(-19.99 \times 1000) + (0 \times 20) - (1000 \times 0)}{20}$$


$$= \frac{-19990 + 0 - 0}{20} = \frac{-19990}{20} = -999.5 \approx -1000$$

(2) Display scaling value B (SB)

$$SB = \frac{(19.99 \times 1000) + (0 \times 20) - (1000 \times 0)}{20}$$


$$= \frac{19990 + 0 - 0}{20} = \frac{19990}{20} = 999.5 \approx 1000$$

From the above calculations, the display scaling value A is -1000, and B is 1000.



Example 2: 40DV-V3-x

Measurement range $\pm 19.99 \text{ V DC}$
 Input signal $0 - 5 \text{ V DC}$
 Desired display value $-5.00 \text{ to } +5.00 \text{ m}$



Calculate the display scaling value A and B with the following formulas.

$$SA = \frac{Rz \times Dspan + Dz \times Is - Ds \times Iz}{Ispan}$$

$$SB = \frac{Rs \times Dspan + Dz \times Is - Ds \times Iz}{Ispan}$$

Rz	Measurement range 0%
Rs	Measurement range 100%
Iz	Input signal 0%
Is	Input signal 100%
Dz	Desired display value 0%
Ds	Desired display value 100%
Ispan	Input span ($Is - Iz$)
Dspan	Display span ($Ds - Dz$)
SA	Display scaling value A
SB	Display scaling value B

(1) Display scaling value A (SA)

In the above formulas, omit the decimal point for the desired display values.


$$\begin{aligned} Ispan &= 5 - 0 = 5 \\ Dspan &= 500 - (-500) = 1000 \end{aligned}$$

$$\begin{aligned} SA &= \frac{(-19.99 \times 1000) + (-500 \times 5) - (500 \times 0)}{5} \\ &= \frac{-19990 + (-2500) - 0}{5} = \frac{-22490}{5} = -4498 \end{aligned}$$

(2) Display scaling value B (SB)

$$\begin{aligned} SB &= \frac{(19.99 \times 1000) + (-500 \times 5) - (500 \times 0)}{5} \\ &= \frac{19990 + (-2500) - 0}{5} = \frac{17490}{5} = 3498 \end{aligned}$$

From the above calculations, the display scaling value A is -4498, and B is 3498.




IMPORTANT

Setting the calculated display scaling value A or B below -9999 or over 9999 is not available. Change the display digit number in such a case.

■ PROCEDURE TO SET DISPLAY SCALING

- Flow in setting display scaling

3-step settings are necessary to set display scaling.



- Operating procedure to set display scaling

Following pages describe operating procedures in each step to set the display scaling to 0.0 – 100.0% with the input code 'A' 4 – 20 mA DC input as an example.

IMPORTANT



- To distinguish from the display scaling value B, the first decimal point blinks in setting the display scaling value A.
- Both normal scaling (display scaling value A < display scaling value B) and inverted scaling (display scaling value A > display scaling value B) can be set within the range of -9999 to 9999.

■ Normal Scaling

The display value increases when the input signal increases.

■ Inverted Scaling

The display value decreases when the input signal increases.



3.1 STEP 1. DISPLAY SCALING VALUE A

3.1.1 DISPLAY SCALING LIST

Display scaling default values per input code and setting ranges (display ranges) are as shown in the following tables.

■ CURRENT INPUT

INPUT SIGNAL	DEFAULT VALUE	SETTING RANGE
A1: $\pm 199.9 \mu\text{A}$ DC	Display scaling value A: <input type="text" value="1999"/> Display scaling value B: <input type="text" value="1999"/>	<input type="text" value="19999"/> to <input type="text" value="99999"/>
A2: $\pm 1.999 \text{ mA}$ DC	Display scaling value A: <input type="text" value="1999"/> Display scaling value B: <input type="text" value="1999"/>	
A3: $\pm 19.99 \text{ mA}$ DC	Display scaling value A: <input type="text" value="1999"/> Display scaling value B: <input type="text" value="1999"/>	
A4: $\pm 199.9 \text{ mA}$ DC	Display scaling value A: <input type="text" value="1999"/> Display scaling value B: <input type="text" value="1999"/>	
A5: $\pm 1.999 \text{ A}$ DC	Display scaling value A: <input type="text" value="1999"/> Display scaling value B: <input type="text" value="1999"/>	
A: 4.00 – 20.00 mA DC	Display scaling value A: <input type="text" value="0400"/> Display scaling value B: <input type="text" value="2000"/>	

■ VOLTAGE INPUT

INPUT SIGNAL	DEFAULT VALUE	SETTING RANGE
V1: $\pm 199.9 \text{ mV}$ DC	Display scaling value A: <input type="text" value="1999"/> Display scaling value B: <input type="text" value="1999"/>	<input type="text" value="19999"/> to <input type="text" value="99999"/>
V2: $\pm 1.999 \text{ V}$ DC	Display scaling value A: <input type="text" value="1999"/> Display scaling value B: <input type="text" value="1999"/>	
V3: $\pm 19.99 \text{ V}$ DC	Display scaling value A: <input type="text" value="1999"/> Display scaling value B: <input type="text" value="1999"/>	
V4: $\pm 199.9 \text{ V}$ DC	Display scaling value A: <input type="text" value="1999"/> Display scaling value B: <input type="text" value="1999"/>	
V5: $\pm 600 \text{ V}$ DC	Display scaling value A: <input type="text" value="0600"/> Display scaling value B: <input type="text" value="0600"/>	
6: 1.00 – 5.00 V DC	Display scaling value A: <input type="text" value="0100"/> Display scaling value B: <input type="text" value="0500"/>	

3.1.2 OPERATING PROCEDURE



NOTE

The left figure shows a display example (default value of input code 'A'). The display depends on the specifications and settings.

1 Confirm the wiring, and turn on the power.

- All the indications turn on for approximately 3 seconds and then the display moves on to Measuring Mode.

NOTE

Indication 'S.ERR' may blink, which shows the input out of the permissible range and does not show the unit failure.

- Immediately after power on (all indicators on)



- Measuring Mode



*1 Display depends on the settings and input.

2 Hold down SCALE/↑ button for 3 seconds or more to move on to Scaling Setting Mode.

- The display scaling value A is indicated.
- The first decimal point starts blinking.



NOTE

Skip to Step 6 if the default value is acceptable.


3 Press SHIFT button to shift the display into the setting standby mode.

- The forth digit starts blinking, to which you can apply changes.



4 Press SHIFT and UP buttons to set to '00.00'.

- Press SHIFT button to go to the next digit and UP button to change the blinking value.



NOTE

- '00.00' is a display example. Set any value within the range of -9999 to 9999.
- The decimal point position depends on the decimal point position setting. Disregard the decimal point here.
- The negative sign (-) must be set together with the 4th digit. For example, set '-04.00' instead of '-4.00'.

5 Press DISP/↓ or SCALE/↑ button to apply the new setting.

- And the next parameter setting is indicated.

NOTE

- Press DISP/↓ button, and the display scaling value B will be indicated.
- Press SCALE/↑ button, and the decimal point position will be indicated.


6 ■ TO GO ON TO SET THE DISPLAY SCALING VALUE B,
Skip to Step 3 in "3.2 STEP 2. DISPLAY SCALING VALUE B".

■ TO QUIT,

Hold down DISP/↓ or SCALE/↑ button for 1 second or more to return to Measuring Mode.

3.2 STEP 2. DISPLAY SCALING VALUE B

3.2.1 OPERATING PROCEDURE



NOTE

The left figure shows a display example (default value of input code 'A'). The display depends on the specifications and settings.

1 Confirm the wiring, and turn on the power.

- All the indications turn on for approximately 3 seconds and then the display moves on to Measuring Mode.

NOTE

Indication 'S.ERR' may blink, which shows the input out of the permissible range and does not show the unit failure.

- Immediately after power on (all indicators on)



- Measuring Mode



*1 Display depends on the settings and input.

2 Hold down SCALE/↑ button for 3 seconds or more to move on to Scaling Setting Mode.

- The display scaling value A is indicated.
- The first decimal point starts blinking.



3 Press DISP/↓ or SCALE/↑ button to go to the display scaling value B setting.

- The display scaling value B is indicated.



NOTE

Skip to Step 7 if the default value is acceptable.

4 Press SHIFT button to shift the display into the setting standby mode.

- The forth digit starts blinking, to which you can apply changes.



5 Press SHIFT and UP buttons to set to '10.00'.

- Press SHIFT button to go to the next digit and UP button to change the blinking value.



NOTE

- '10.00' is a display example. Set any value within the range of -9999 to 9999.
 - The decimal point position depends on the decimal point position setting. Disregard the decimal point here.
 - The negative sign (-) must be set together with the 4th digit. For example, set '-04.00' instead of '-4.00'.
-

6 Press DISP/↓ or SCALE/↑ button to apply the new setting.

- And the next parameter setting is indicated.

NOTE

- Press DISP/↓ button, and the decimal point position will be indicated.
 - Press SCALE/↑ button, and the display scaling value A will be indicated.
-

**7 ■ TO GO ON TO SET THE DECIMAL POINT POSITION,
Skip to Step 3 in "3.3 STEP 3. DECIMAL POINT POSITION".**

■ TO QUIT,

Hold down DISP/↓ or SCALE/↑ button for 1 second or more to return to Measuring Mode.

3.3 STEP 3. DECIMAL POINT POSITION

3.3.1 DECIMAL POINT POSITION LIST

Default values of decimal point position are as shown in the following tables.


■ CURRENT INPUT

INPUT SIGNAL	DEFAULT VALUE
A1: $\pm 199.9 \mu\text{A}$ DC	[8888] 1 decimal place (10^{-1})
A2: $\pm 1.999 \text{ mA}$ DC	[8888] 3 decimal places (10^{-3})
A3: $\pm 19.99 \text{ mA}$ DC	[8888] 2 decimal places (10^{-2})
A4: $\pm 199.9 \text{ mA}$ DC	[8888] 1 decimal place (10^{-1})
A5: $\pm 1.999 \text{ A}$ DC	[8888] 3 decimal places (10^{-3})
A: 4.00 – 20.00 mA DC	[8888] 2 decimal places (10^{-2})

■ VOLTAGE INPUT

INPUT SIGNAL	DEFAULT VALUE
V1: $\pm 199.9 \text{ mV}$ DC	[8888] 1 decimal place (10^{-1})
V2: $\pm 1.999 \text{ V}$ DC	[8888] 3 decimal places (10^{-3})
V3: $\pm 19.99 \text{ V}$ DC	[8888] 2 decimal places (10^{-2})
V4: $\pm 199.9 \text{ V}$ DC	[8888] 1 decimal place (10^{-1})
V5: $\pm 600 \text{ V}$ DC	[8888] no decimal point
6: 1.00 – 5.00 V DC	[8888] 2 decimal places (10^{-2})

3.3.2 OPERATING PROCEDURE



NOTE

The left figure shows a display example (default value of input code 'A'). The display depends on the specifications and settings.

1 Confirm the wiring, and turn on the power.

- All the indications turn on for approximately 3 seconds and then the display moves on to Measuring Mode.

NOTE

Indication 'S.ERR' may blink, which shows the input out of the permissible range and does not show the unit failure.

- Immediately after power on (all indicators on)



- Measuring Mode



*1 Display depends on the settings and input.

2 Hold down S_{CALE/↑} button for 3 seconds or more to move on to Scaling Setting Mode.

- The display scaling value A is indicated.
- The first decimal point starts blinking.



3 Press D_{ISP/↓} or S_{CALE/↑} button to go to the decimal point position setting.

- The decimal point position is indicated.



NOTE

Skip to Step 7 if the default value is acceptable.

4 Press **SHIFT** button to shift the display into the setting standby mode.

- The indication starts blinking, to which you can apply changes.



5 Press **UP** button to select the decimal point position.

- Select 1 decimal place (10^{-1}).
- Press **UP** button to move the decimal point.



NOTE

The right figure shows a display example. Select one among “no decimal point”, and “1 decimal place” to “3 decimal places”.

6 Press **DISP/↓** or **SCALE/↑** button to apply the new setting.

- And the next parameter setting is indicated.

NOTE

- Press **DISP/↓** button, and the display scaling value A will be indicated.
- Press **SCALE/↑** button, and the display scaling value B will be indicated.

7 Hold down **DISP/↓** or **SCALE/↑** button for 1 second or more to return to Measuring Mode.

4. OPERATION

Make sure that 0.0 – 100.0% is correctly indicated according to the input 4 – 20 mA DC provided.

IMPORTANT

Before operating, make sure that the wiring is correct, the input and the power supply are within the specification range.

- 1 Apply 4 mA input (0%) and make sure that 0.0% is indicated.




*1 Display depends on the settings and input.

NOTE

■ WHEN THE FOLLOWING IS INDICATED...

- When 'S.ERR' is indicated, the input is not applied correctly. Check the input wiring, equipment and signal.



- 2 Apply 12 mA input (50%) and make sure that 50.0% is indicated.



- 3 Apply 20 mA input (100%) and make sure that 100.0% is indicated.




5. PARAMETER CONFIGURATION

■ MODE

Parameters can be grouped in several modes.
The 40DV has modes as shown in the following table.

MODE	FUNCTION	MEASUREMENT
Measuring	Normal measurement state where the unit takes in input. When the power is supplied, the unit operates in Measuring Mode.	Measuring
Scaling Setting	Basic settings such like display scaling value A and B, and decimal point position can be performed.	Measuring stopped
Display Setting	Moving average and brightness can be set. Settings can be initialized. Also the firm-ware version can be confirmed.	

■ MODE TRANSITION



■ TRANSITION FROM MEASURING MODE TO EACH MODE

To Scaling Setting Mode	Hold down SCALE/↑ button for 3 seconds or more.
To Display Setting Mode	Hold down Disp/↓ button for 3 seconds or more.

■ TRANSITION FROM EACH MODE TO MEASURING MODE

Hold down Disp/↓ or SCALE/↑ button for 1 second or more to return to Measuring Mode.


6. AVERAGING INPUT

Moving average processing of measured values is configurable. The number of samples in processing the moving average can be selected in the following table. This operation averages sampled values, and then, averages with a new sample added and the oldest one omitted. Such operation is repeated as shown in the following figure. For instance, when 'A 4' is selected, the moving average processing with 4 samples (400 millisecond intervals) is repeated. Moving average is used to remove periodic varied noise superimposed on the input signal and suppress the display flickering.

■ NUMBER OF SAMPLES


DISPLAY	FUNCTION	DEFAULT VALUE
[R _{OFF}]	No moving averaging	[R _{OFF}]
[R ₂]	Moving average with 2 samples (200 millisecond intervals)	
[R ₄]	Moving average with 4 samples (400 millisecond intervals)	
[R ₈]	Moving average with 8 samples (800 millisecond intervals)	

■ EXAMPLE OF MOVING AVERAGE WITH 4 SAMPLES



- (1) The moving average operation starts immediately after the power is on or the moving average is set. Until the sampling No. reaches the set value, all samples are averaged every 100 milliseconds.
- (2) After the sampling No. reaches the set value, a new sample is added to be averaged with the oldest one omitted. Such operation is repeated.

6.1 OPERATING PROCEDURE



NOTE

The following figures are display examples. The displays depend on the settings.

- 1 Hold down D_{ISP/↓} button for 3 seconds or more to move on to Display Setting Mode.

- The moving average sampling No. is indicated.



NOTE

'AOFF', 'A 2', 'A 4' or 'A 8' is indicated depending on the setting.

- 2 Press S_{HIFT} or U_P button to select.

- Select one among 'AOFF', 'A 2', 'A 4' and 'A 8'.



- 3 Press D_{ISP/↓} or S_{CALE/↑} button to apply the new setting.

- And the next parameter setting is indicated.

NOTE

- Press D_{ISP/↓} button, and the brightness 'C 1', 'C 2', 'C 3', 'C 4' or 'C 5' will be indicated depending on the setting.
- Press S_{CALE/↑} button, and the version indication will be indicated.

- 4 Hold down D_{ISP/↓} or S_{CALE/↑} button for 1 second or more to return to Measuring Mode.


7. ADJUSTING BRIGHTNESS OF DISPLAY

The brightness of the display can be adjusted (figures below). The brightness can be selected in the following table.


■ DISPLAY BRIGHTNESS

DISPLAY	FUNCTION	DEFAULT VALUE
[L1]	Brightness level 1 (dark)	[L5]
[L2]	Brightness level 2	
[L3]	Brightness level 3	
[L4]	Brightness level 4	
[L5]	Brightness level 5 (bright)	

■ ADJUSTMENT IMAGE



7.1 OPERATING PROCEDURE



NOTE

The following figures are display examples. The displays depend on the settings.

- 1** Hold down DISP/↓ button for 3 seconds or more to move on to Display Setting Mode.

- The moving average sampling No. is indicated.




NOTE

'AOFF', 'A 2', 'A 4' or 'A 8' is indicated depending on the setting.

- 2** Press DISP/↓ or SCALE/↑ button to go to the brightness setting.

- The brightness is indicated.



NOTE

'C 1', 'C 2', 'C 3', 'C 4' or 'C 5' is indicated depending on the setting.

- 3** Press SHIFT or UP button to select.

- Select one among 'C 1', 'C 2', 'C 3', 'C 4' and 'C 5'.



4 Press DISP/↓ or SCALE/↑ button to apply the new setting.

- And the next parameter setting is indicated.

NOTE

- Press DISP/↓ button, and the initialization 'ROFF' will be indicated.
 - Press SCALE/↑ button, and the moving average sampling No. 'AOFF' 'A 2' 'A 4' or 'A 8' will be indicated depending on the setting.
-


5 Hold down DISP/↓ or SCALE/↑ button for 1 second or more to return to Measuring Mode.

8. HOLDING DISPLAY


Displayed value is held with an external HOLD command input. Connect the contact across HOLD to COM as shown in the following figures. Close the contact to hold the value.

■ WIRING EXAMPLES


(a) Transistor



(b) Photo-Coupler



(c) Relay



Terminals 3 and 4 are NOT isolated from the internal circuit.

NOTE

- While the HOLD command is input, the display keeps the value at the HOLD command turning on, even though the input is out of range.
- In supplying power with the HOLD command on, 0 is indicated.

9. USER CALIBRATION

The 40DV does not have a function to calibrate (adjust) the input signal. Set the display scaling to compensate the deviation between the desired and actual display values.

Correction value 0% = desired display value 0% – actual display value 0% + desired display value 0%

Correction value 100% = desired display value 100% – actual display value 100% + desired display value 100%

Calculate the display scaling values using the correction values. Refer to 3. SETTING DISPLAY SCALING to set them.

Example 1: setting the display to 0.0 – 100.0% for the input 4 – 20 mA DC with the input code 'A' Actual display 0.2 – 99.8%.

Calculate correction value 0 and 100%.

Correction value 0% = 0 – 2 + 0 = -2

Correction value 100% = 1000 – 998 + 1000 = 1002

As the measurement range is the same as the input, set the display scaling as follows:

Display scaling value A = -0002

Display scaling value B = 1002

Example 2: setting the display to 0.0 – 100.0% for the input 0 – 20 mA DC with the input code 'A3'. Actual display 0.2 – 99.8%.

Calculate correction value 0 and 100%.

Correction value 0% = 0 – 2 + 0 = -2

Correction value 100% = 1000 – 998 + 1000 = 1002

As the measurement range is different from the input, calculate the display scaling value A and B. Replace the desired display values and the display span with the correction values and their span.

$$\begin{aligned} SA &= \frac{-19.99 \times 1004 + (-2) \times 20 - 1002 \times 0}{20} \\ &= \frac{-20069.96 - 40 - 0}{20} = \frac{-20109.96}{20} = -1005.498 \approx -1005 \end{aligned}$$

$$\begin{aligned} SB &= \frac{19.99 \times 1004 + (-2) \times 20 - 1002 \times 0}{20} \\ &= \frac{20069.96 - 40 - 0}{20} = \frac{20029.96}{20} = 1001.498 \approx 1001 \end{aligned}$$

From the above calculations, set the display scaling as follows:

Display scaling value A = -1005

Display scaling value B = 1001

10. INSPECTION / CLEANING

To use the unit in the normal and best conditions, inspect and clean the unit routinely or periodically.

- When the front panel have dirt, wipe them with wet soft cloth. Do not use organic solvent such like benzine, thinner and alcohol. Doing so may result in deformation or discoloration of the unit.
- Make sure that abnormality such like smokes, unusual smell or abnormal noises is not found. Using the unit continuously with such abnormality may result in a fire or electric shock.
- Check the terminal screws periodically. In checking the screws, for safety, interrupt electricity to the power and input.
- Make sure periodically that the mounting brackets are fixed tightly. Loosened brackets may cause drop of the unit.

11. TROUBLESHOOTING


11.1 ERROR MESSAGES

DISPLAY	ERROR MESSAGE	WHAT TO DO
[S.ERR] blinking	The input signal is out of the permissible range.	Set the input signal within the permissible range.
[9999] or [-9999] blinking	The value after scaling is out of the permissible display range.	Set the input signal within the permissible range.

NOTE

While an external HOLD command is input, the display keeps the value at the HOLD command turning on, even though the input is out of range.

■ INPUT AND ERROR CORRELATION (e.g. ± 1.999 V input)




11.2 INITIALIZING SETTING VALUES

To restart setting from the default state, initialization can be used. Refer to attached 12.3 PARAMETER LIST for the default values.

IMPORTANT

- Currently set parameters will be lost after an initialization. It is recommended to record the parameters before initialization.
- Even if the unit is shipped with the specified parameters with the option code '/SET', such parameters will be lost after an initialization. Be careful that the initialization does not recover the ex-factory settings.

11.2.1 OPERATING PROCEDURE



- 1 Hold down D button for 3 seconds or more to move on to
Display Setting Mode.

- The moving average sampling No. is indicated.



NOTE

'AOFF', 'A 2', 'A 4' or 'A 8' is indicated depending on the setting.

- 2 Press D or S button to go to the initialization.

- 'ROFF' is indicated.



- 3 Press S or U button to select 'REST'.



4 Press DISP/↓ or SCALE/↑ button to execute the initialization.

- The settings are initialized and then the next parameter setting is indicated.

NOTE

- Press DISP/↓ button, and the version indication will be indicated.
 - Press SCALE/↑ button, and the brightness 'C 5' will be indicated.
-

5 Hold down DISP/↓ or SCALE/↑ button for 1 second or more to return to Measuring Mode.


11.3 CONFIRMING FIRMWARE VERSION

The firmware version of the unit can be confirmed.

Confirm the version in the following cases:

- The display is different from the one described in the operating manual.
- The firmware version is necessary to consult us for troubles.

11.3.1 OPERATING PROCEDURE



- 1 Hold down DISP/↓ button for 3 seconds or more to move on to
Display Setting Mode.

- The moving average sampling No. is indicated.



NOTE

'AOFF', 'A 2', 'A 4' or 'A 8' is indicated depending on the setting.

- 2 Press DISP/↓ or SCALE/↑ button to go to the version indication.

- The firmware version number is indicated.



NOTE

The displays depend on the firmware version number.

- 3 Hold down DISP/↓ or SCALE/↑ button for 1 second or more to return to Measuring Mode.

12. APPENDICES

12.1 SPECIFICATIONS

■ GENERAL SPECIFICATIONS

Construction	Panel flush mounting	
Connection	M3 screw terminals (torque 0.6 N·m)	
Screw terminal	Nickel-plated steel	
Housing material	Flame-resistant resin (gray)	
Isolation	Input to power	
Setting (front button)	Scaling setting mode	Display scaling value A, display scaling value B, decimal point position
	Display setting mode	Moving average, brightness, initialization, version indication
A/D conversion	$\Sigma - \Delta$	
Sampling rate	10 times/sec. (100 msec.)	
Averaging	None or moving average	

■ DISPLAY

Display	4 digits of 20.3 mm (0.8 inch) height, 7-segment, red LED
Display range	-9999 to 9999
Scaling range for measurement range (conformance range)	-9999 to 9999 counts
Decimal point position	10^{-1} , 10^{-2} , 10^{-3} or none
Zero indication	Higher-digit zeros are suppressed
Over-range indication	'-9999' or '9999' blinking for display values out of the display range. 'S.ERR' blinks surpassing the permissible range.

■ INPUT SPECIFICATIONS

DC current	Input code: A1	Measurement range (conformance range)	$\pm 199.9 \mu\text{A DC}$
		Input range	Approx. -219 – +219 μA
		Input resistance	1 k Ω
	Input code: A2	Measurement range (conformance range)	$\pm 1.999 \text{ mA DC}$
		Input range	Approx. -2.19 – +2.19 mA
		Input resistance	100 Ω
	Input code: A3	Measurement range (conformance range)	$\pm 19.99 \text{ mA DC}$
		Input range	Approx. -21.9 – +21.9 mA
		Input resistance	10 Ω
	Input code: A4	Measurement range (conformance range)	$\pm 199.9 \text{ mA DC}$
		Input range	Approx. -219 – +219 mA
		Input resistance	1 Ω
	Input code: A5	Measurement range (conformance range)	$\pm 1.999 \text{ A DC}$
		Input range	Approx. -2.19 – +2.19 A
		Input resistance	0.1 Ω
	Input code: A	Measurement range (conformance range)	4.00 – 20.00 mA DC
		Input range	Approx. 2.4 – 21.6 mA
		Input resistance	10 Ω

DC voltage	Input code: V1	Measurement range (conformance range)	$\pm 199.9 \text{ mV DC}$
		Input range	Approx. -219 – +219 mV
		Input resistance	$\geq 100 \text{ M}\Omega$
	Input code: V2	Measurement range (conformance range)	$\pm 1.999 \text{ V DC}$
		Input range	Approx. -2.19 – +2.19 V
		Input resistance	$\geq 100 \text{ M}\Omega$
	Input code: V3	Measurement range (conformance range)	$\pm 19.99 \text{ V DC}$
		Input range	Approx. -21.9 – +21.9 V
		Input resistance	$10 \text{ M}\Omega \pm 5\%$
	Input code: V4	Measurement range (conformance range)	$\pm 199.9 \text{ V DC}$
		Input range	Approx. -219 – +219 V
		Input resistance	$10 \text{ M}\Omega \pm 5\%$
	Input code: V5	Measurement range (conformance range)	$\pm 600 \text{ V DC}$
		Input range	Approx. -659 – +659 V
		Input resistance	$10 \text{ M}\Omega \pm 5\%$
	Input code: 6	Measurement range (conformance range)	1.00 – 5.00 V DC
		Input range	Approx. 0.6 – 5.4 V
		Input resistance	$10 \text{ M}\Omega \pm 5\%$
Hold input	Dry contact input		
	Detecting level	$\leq 0.8 \text{ V}$	
	Sensing	Approx. 2.1 V DC, 0.03 mA	

■ INSTALLATION

Power consumption	AC power	K3: 100 – 120 V AC	Operational voltage range 85 – 132 V, 47 – 66 Hz Approx. 1.6 VA
		L3: 200 – 240 V AC	Operational voltage range 170 – 264 V, 47 – 66 Hz Approx. 1.0 VA
	DC power	R: 24 V DC	Operational voltage range 24 V $\pm 20\%$ Ripple 10% p-p max. Approx. 0.5 W
Operating temperature		-10 to +55°C (14 to 131°F)	
Operating humidity		30 to 90% RH (non-condensing)	
Mounting		Panel flush mounting	
Weight		160 g (0.35 lb)	

■ PERFORMANCE

Accuracy (for each input code)	Input code: A1	$\pm 0.1\%$ rdg ± 1 digit
	Input code: A2	$\pm 0.1\%$ rdg ± 1 digit
	Input code: A3	$\pm 0.1\%$ rdg ± 1 digit
	Input code: A4	$\pm 0.1\%$ rdg ± 1 digit
	Input code: A5	$\pm 0.3\%$ rdg ± 1 digit
	Input code: A	$\pm 0.1\%$ rdg ± 1 digit
	Input code: V1	$\pm 0.1\%$ rdg ± 1 digit
	Input code: V2	$\pm 0.1\%$ rdg ± 1 digit
	Input code: V3	$\pm 0.1\%$ rdg ± 1 digit
	Input code: V4	$\pm 0.1\%$ rdg ± 1 digit
	Input code: V5	$\pm 0.15\%$ rdg ± 1 digit
	Input code: 6	$\pm 0.1\%$ rdg ± 1 digit
	“1 digit” is multiplied by scaling-multiple ^{*1} . Even in case the scaling-multiple is less than 1, multiply by 1.	
Temp. coefficient	$\pm(0.01\% \text{ rdg} + 0.3 \text{ digits})/\text{ }^{\circ}\text{C}$ “0.3 digits” is multiplied by scaling-multiple ^{*1} . Even in case the scaling-multiple is less than 1, multiply by 1.	
Line voltage effect	± 1 digit over voltage range	
Insulation resistance	$\geq 100 \text{ M}\Omega$ with 500 V DC	
Dielectric strength	1500 V AC @ 1 minute (input to power to ground)	

*1 Calculate scaling-multiple with the following formula.

Scaling-multiple = I (display scaling value B – display scaling value A) ÷ (default display scaling value B – default display scaling value A) I

■ STANDARDS & APPROVALS

EU conformity ^{*2}	EMC Directive EMI EN 61000-6-4 EMS EN 61000-6-2 Low Voltage Directive EN 61010-1 Measurement Category I (input) Installation Category II (power) Pollution degree 2 Input to power: Reinforced insulation (300 V) RoHS Directive
-----------------------------	---

*2 CE is not available with the input code ‘V5’.

12.2 MODEL NUMBERING

Code number: **40DV-[1]-[2][3]**

[1] INPUT

Current

- A1: $\pm 199.9 \mu\text{A}$ DC (input resistance $1 \text{ k}\Omega$)
- A2: $\pm 1.999 \text{ mA}$ DC (input resistance 100Ω)
- A3: $\pm 19.99 \text{ mA}$ DC (input resistance 10Ω)
- A4: $\pm 199.9 \text{ mA}$ DC (input resistance 1Ω)
- A5: $\pm 1.999 \text{ A}$ DC (input resistance 0.1Ω)
- A: $4.00 - 20.00 \text{ mA}$ DC (input resistance 10Ω)

Voltage

- V1: $\pm 199.9 \text{ mV}$ DC (input resistance $\geq 100 \text{ M}\Omega$)
- V2: $\pm 1.999 \text{ V}$ DC (input resistance $\geq 100 \text{ M}\Omega$)
- V3: $\pm 19.99 \text{ V}$ DC (input resistance $10 \text{ M}\Omega \pm 5\%$)
- V4: $\pm 199.9 \text{ V}$ DC (input resistance $10 \text{ M}\Omega \pm 5\%$)
- V5: $\pm 600 \text{ V}$ DC (input resistance $10 \text{ M}\Omega \pm 5\%$) (CE not available)
- 6: $1.00 - 5.00 \text{ V}$ DC (input resistance $10 \text{ M}\Omega \pm 5\%$)

[2] POWER INPUT

AC Power

- K3: $100 - 120 \text{ V}$ AC (operational voltage range $85 - 132 \text{ V}$, $47 - 66 \text{ Hz}$)
- L3: $200 - 240 \text{ V}$ AC (operational voltage range $170 - 264 \text{ V}$, $47 - 66 \text{ Hz}$)

DC Power

- R: 24 V DC (operational voltage range $24 \text{ V} \pm 20\%$, ripple 10% p-p max.)

[3] OPTIONS

Blank: None

/Q: With options (specify the specification)

■ SPECIFICATIONS OF OPTION: Q

COATING (For the detail, refer to our web site.)

Moving parts and indicators are not coated.

/C01: Silicone coating

/C02: Polyurethane coating

/C03: Rubber coating

EX-FACTORY SETTING

/SET: Preset according to the Ordering Information Sheet (No. ESU-9532)


12.3 PARAMETER LIST

MODE	PARAMETER	SETTING RANGE	DISPLAY	DEFAULT VALUE	DECIMAL POINT POSITION	UNIT
Measuring	Present value	-9999 – 9999	----	----	*1	User-defined
Scaling setting	Display scaling value A	-9999 – 9999	[9999] to [9999]	A1: [1999] A2: [1999] A3: [1999] A4: [1999] A5: [1999] A: [0400] V1: [1999] V2: [1999] V3: [1999] V4: [1999] V5: [0600] 6: [0100]	*1	User-defined
	Display scaling value B	-9999 – 9999	[9999] to [9999]	A1: [1999] A2: [1999] A3: [1999] A4: [1999] A5: [1999] A: [2000] V1: [1999] V2: [1999] V3: [1999] V4: [1999] V5: [0600] 6: [0500]	*1	User-defined
	Decimal point position	No decimal point, or 10^{-1} to 10^{-3}	[8888], [8888], [8888], [8888]	A1: [8888] A2: [8888] A3: [8888] A4: [8888] A5: [8888] A: [8888] V1: [8888] V2: [8888] V3: [8888] V4: [8888] V5: [8888] 6: [8888]	---	---
Display setting	Moving average	None, 2, 4, 8	[RaFE], [R...2], [R...4], [R...8]	[RaFE]	---	Sample
	Brightness	1 (dark) to 5 (bright)	[L...1], [L...2], [L...3], [L...4], [L...5]	[L...5]	---	---
	Initialization	OFF, initialization	[RaFE], [RESET]	[RaFE]	---	---
	Version indication	----	----	----	----	----

*1 Conforms to decimal point position setting.

12.4 PARAMETER MAP


12.4.1 SCALING SETTING MODE



NOTE

The display depends on the specifications, settings and input.

12.4.2 DISPLAY SETTING MODE



NOTE

- The display depends on the specifications, settings and input.
- Version indication is for indication only, not for setting.

12.5 CHARACTER SET

■ NUMERALS

0	1	2	3	4	5	6	7	8	9
0	1	2	3	4	5	6	7	8	9

■ ALPHABET

A	B	C	D	E	F	G	H	I	J
R	b	C	d	E	F	G	H	i	U
K	L	M	N	O	P	Q	R	S	T
P	L	ñ	n	o	p	q	r	s	t
U	v	w	x	y	z				
U	v	w	x	y	z				