# INSTRUCTION MANUAL

## SELF-SYNCH TRANSMITTER (field-programmable)

# MODEL

JS

# BEFORE USE ....

Thank you for choosing us. Before use, please check contents of the package you received as outlined below. If you have any problems or questions with the product, please contact our sales office or representatives.

## ■ PACKAGE INCLUDES:

 $Signal \ conditioner \ (body + base \ socket) .....(1)$ 

## MODEL NO.

Confirm Model No. marking on the product to be exactly what you ordered.

### ■INSTRUCTION MANUAL

This manual describes necessary points of caution when you use this product, including installation, connection, hardware setting and basic maintenance procedures.

When you need to change software settings, please refer to the Operation Manual for Model PU-2x (EM-9255), Section A.

# **POINTS OF CAUTION**

## ■ POWER INPUT RATING & OPERATIONAL RANGE

• Locate the power input rating marked on the product and confirm its operational range as indicated below: AC power: Rating ±10%, 50/60 ±2 Hz, approx. 3VA

## ■ GENERAL PRECAUTIONS

• Before you remove the unit from its base socket or mount it, turn off the power supply and input signal for safety.

#### ENVIRONMENT

- Indoor use.
- When heavy dust or metal particles are present in the air, install the unit inside proper housing with sufficient ventilation.
- Do not install the unit where it is subjected to continuous vibration. Do not subject the unit to physical impact.
- Environmental temperature must be within -5 to +55°C (23 to 131°F) with relative humidity within 30 to 90% RH in order to ensure adequate life span and operation.

#### ■ WIRING

- Do not install cables close to noise sources (relay drive cable, high frequency line, etc.).
- Do not bind these cables together with those in which noises are present. Do not install them in the same duct.

## ■ ADJUSTMENTS

• Before using zero adjustment with self-synch is required. Refer to the adjustments section.

## ■ AND ....

• The unit is designed to function as soon as power is supplied, however, a warm up for 10 minutes is required for satisfying complete performance described in the data sheet.

# **COMPONENT IDENTIFICATION**



## ■ HOW TO OPEN THE FRONT COVER:

Hang your finger on the hook at the top of the front cover and pull.



# **INSTALLATION**

Detach the yellow clamps located at the top and bottom of the unit for separate the body from the base socket.

#### ■ DIN RAIL MOUNTING

Set the base socket so that its DIN rail adaptor is at the bottom. Hang the upper hook at the rear side of base socket on the DIN rail and push in the lower. When removing the socket, push down the DIN rail adaptor utilizing a minus screwdriver and pull.



#### ■ WALL MOUNTING

Refer to "EXTERNAL DI-MENSIONS."

Shape and size of the base socket are slightly different with various socket types.

# **TERMINAL CONNECTIONS**

Connect the unit as in the diagram below or refer to the connection diagram on the top of the unit.

## EXTERNAL DIMENSIONS unit: mm (inch)



• When mounting, no extra space is needed between units.

## ■ CONNECTION DIAGRAM



\* The output increases when the self-synch rotates clockwise For changing the operation to counterclockwise, reverse the connection of S2 and S3.

\*\*Be sure that the polarity of the power input to the JS matches to the self-synch input polarity. When the connetion is reversed, the JS output will be shifted by 180°.

CHECKING

nal 8 – R2.

scribed specifications.

behind the front cover.

rent output values.

1) Terminal wiring: Check that all cables are correctly con-

2) Input signal and power input voltage: Check wiring

across JS and self-synch as follows; terminal 3 - S1, ter-

minal 4 - S2, terminal 5 - S3, terminal 7 - R1, and termi-

Be sure that the connection for R1 and R2 of the self-

synch. When the connection is reversed, the signal condi-

3) Output: Check that the load resistance meets the de-

This unit is calibrated at the factory to meet the ordered specifications. The angle, offset, zero and span are adjusted

with using the Programming Unit (model: PU-2x). Also, manual adjustments can be done with the potentiometers

Refer to the Operation Manual for Model PU-2x for expla-

• Be sure to disconnect the Programming Unit before you

• The output signal is held when the Programming Unit is

connected. You need to disconnect when confirming cur-

■ WARNING ON USE OF THE PROGRAMMING UNIT

nected according to the connection diagram.

tioner output will be shifted by 180°.

ADJUSTMENT PROCEDURE

nations how to use the programmer.

turn on/off power supply to the unit.

## ■ HOW TO CALIBRATE THE OUTPUT SIGNAL

Use a signal source and measuring instruments of sufficient accuracy level. Turn the power supply on and warm up for more than 10 minutes.

#### Input offset

- 1) Switch the JS into operation and apply 0% input.
- 2) Turn the Offset Adj. until the JS output is adjusted to 0%. If there is no change in output when you turn the adjustment, turn it in the other direction until the output is adjusted.



## Fine Output Calibration

#### Using the Programming Unit (ITEM 19, 20)

- ITEM 19 is for Zero, and ITEM 20 is for Span.
- 1) Turn the unit into Program mode (ITEM 01).
- 2) Apply simulated 0% input. Increase/decrease values (default: 0%) at ITEM 19 until the output signal is calibrated to actual 0%.
- 3) Apply simulated 100% input. Increase/decrease value (default: 100%) at ITEM 20 until the output signal is calibrated to actual 100%.
- 4) Apply simulated 0% input again and check 0% output.
- 5) When 0% value is changed, repeat the above procedure 2() 4).

The 0% value may be shifted when the output span is greater than the input span (gain > 1).

#### • Fine Output Calibration via the Front Potentiometers

- 1) ZERO: Apply 0% input and adjust output to 0%.
- 2) SPAN: Apply 100% input and adjust output to 100%.
- 3) Check ZERO adjustment again with 0% input.
- 4) When ZERO value is changed, repeat the above procedure 1) 3.

## Using Linearization Table

Please have the PU-2x Operation Manual ready at hand. Max. 16 calibration points defined by sets of input and output values can be programmed. Use only necessary number of points, arranged in order from the smallest input value. Enable use of the linearization table (ITEM 10: SR-2: curved) in order to activate the settings.

 $X\left(nn\right):Input\ Signal\ in\ \%$  $Y\left(nn\right):Output\ Signal\ in\ \%$ X or Y : -15.00 to +115.00%+100% Y05 Y04 OUTPUT Y03 Y02 -15% X01 Y01<sup>X02</sup> X03 X04 X05 +115% -5% INPUT

Figure 1. Linearization Table

[GROUP 01]				
ITEM	MDFY.	DATA EXAMPLE		
60	Р	X (01) : XXX.XX		
61	Р	Y (01) : XXX.XX		
62	Р	X (02) : XXX.XX		
63	Р	Y (02) : XXX.XX		
64	Р	X (03) : XXX.XX		
65	Р	Y (03) : XXX.XX		
66	Р	X (04) : XXX.XX		
67	Р	Y (04) : XXX.XX		
68	Р	X (05) : XXX.XX		
69	Р	Y (05) : XXX.XX		
70	Р	X (06) : XXX.XX		
71	Р	Y (06) : XXX.XX		
72	Р	X (07) : XXX.XX		
73	Р	Y (07) : XXX.XX		
74	Р	X (08) : XXX.XX		
75	Р	Y (08) : XXX.XX		
76	Р	X (09) : XXX.XX		
77	Р	Y (09) : XXX.XX		
78	Р	X (10) : XXX.XX		
79	Р	Y (10) : XXX.XX		
80	Р	X (11) : XXX.XX		
81	Р	Y (11) : XXX.XX		
82	Р	X (12) : XXX.XX		
83	Р	Y (12) : XXX.XX		
84	Р	X (13) : XXX.XX		
85	Р	Y (13) : XXX.XX		
86	Р	X (14) : XXX.XX		
87	Р	Y (14) : XXX.XX		
88	Р	X (15) : XXX.XX		
89	Р	Y (15) : XXX.XX		
90	Р	X (16) : XXX.XX		
91	Р	Y (16) : XXX.XX		

**Modification Code** 

S: Modifiable at any time.

P: Modifiable only when the MAINTENANCE SWITCH is in the "PRG" mode.

# **PROGRAMMABLE ITEMS**

The following items can be monitored and programmed. For detailed explanations, please refer to the Operation Manual for Model PU-2x (EM-9255), Section A.

## [GROUP 01]

ITEM	MDFY.	DATA INPUT	DISPLAY	CONTENTS
01	S			MAINTENANCE SWITCH (lock command)
		0	MTSW: MON.MODE	MONITOR mode: data monitoring only
		1	MTSW: PRG.MODE	PROGRAM mode: "P" marked data modifiable
02	Р	Alphabets & No.	TG: XXXXXXXXXX	Tag name entry (10 characters max.)
03	Р	Number (%)	OUTPER XXX.XX	Output status monitor (%) & simulation output
04	D	No input	OUTANG XXX.XX	Output angle monitor (degree)
05	D	No input	INPANG XXX.XX	Input angle monitor (degree)
06	D	No input	XVALUE XXX.XX	X-axis monitor (voltage: V)
07	D	No input	YVALUE XXX.XX	Y-axis monitor (voltage: V)
08	D	No input	INPOFS XXX.XX	Input offset setting monitor (degree)
10	Р			LINEARIZATION *1
		1	SR-1: straight	Without
		2	SR-2: curved	With (ITEM 60 to 91 for data input)
14	Р	Actual value	ANGOFS XXX.X	Input offset angle (0%, degrees) *2
15	Р	Actual value	ANGRNG XXX.X	Input range scaling (100%, degrees) *2
19	Р	Percentage	FINZER	Fine zero adjustment
				Initial status shows actual bias (%). When data is entered, out-
				put (%) is shown.
20	Р	Percentage	FINSPN	Fine span adjustment
				Initial status shows actual gain (%). When data is entered, out-
				put (%) is shown.

\*1. After setting ITEM 10, following ITEMs are reset to the default value.

ITEM 14 (Angle offset): 0.0

ITEM 15 (Angle range): 360.0

ITEM 19 (Zero fine adjustment): 0.00

ITEM 20 (Span fine adjustment): 100.00

\*2. After setting ITEM 14 or 15, it is required to perform offset adjustment for the JS unit, which can be conducted with the multiturn screwdriver adjustment over the modular jack of the unit.

#### LINEARIZATION TABLE

60	Р	Percentage	X (01) : XXX.XX	Input 1	
61	Р	Percentage	Y (01) : XXX.XX	Output 1	
:	:	:	:	:	
:	:	:	:	:	
91	Р	Percentage	Y (16) : XXX.XX	Output 16	

Modification Code

D: No modification (writing) possible. Used only for monitoring (reading).

S: Modifiable at any time.

P: Modifiable only when the MAINTENANCE SWITCH is in the "PRG" mode.

## MAINTENANCE

Regular calibration procedure is explained below:

## ■ CALIBRATION

Warm up the unit for at least 10 minutes. Apply 0%, 25%, 50%, 75% and 100% input signal. Check that the output signal for the respective input signal remains within accuracy described in the data sheet. When the output is out of tolerance, recalibrate the unit according to the "ADJUST-MENT PROCEDURE" explained earlier.

# LIGHTNING SURGE PROTECTION

We offer a series of lightning surge protector for protection against induced lightning surges. Please contact us to choose appropriate models.