

**SELF-SYNCH TRANSMITTER**  
(PC programmable)
MODEL **M2EXS****CONTENTS**

BEFORE USE .....	2
POINTS OF CAUTION.....	2
COMPONENT IDENTIFICATION .....	2
INSTALLATION .....	3
TERMINAL CONNECTIONS .....	3
EXTERNAL VIEWS .....	4
DIP SWITCH .....	4
SCREEN DISPLAY.....	5
PROGRAMMING .....	6
ERROR MESSAGES.....	18
WIRING INSTRUCTIONS.....	18
CHECKING .....	18
MAINTENANCE.....	19
LIGHTNING SURGE PROTECTION .....	19

## BEFORE USE ....

Thank you for choosing us. Before use, please check contents of the package you received as outlined below.

If you have any problems or questions with the product, please contact our sales office or representatives.

### ■ PACKAGE INCLUDES:

Signal conditioner (body + base socket).....(1)

### ■ MODEL NO.

Confirm Model No. marking on the product to be exactly what you ordered.

### ■ OPERATING MANUAL

This manual describes detailed operation regarding settings.

The M2EXS is programmable using a PC. For detailed information on the PC configuration, refer to the M2ECFG users manual (EM-5147).

The M2ECFG Configurator Software is downloadable at our web site.

## POINTS OF CAUTION

### ■ CONFORMITY WITH EU DIRECTIVES

- This equipment is suitable for Pollution Degree 2 and Installation Category II (transient voltage 2500V). Reinforced insulation (signal input or output to power input: 300V) and basic insulation (signal input to output: 300V) are maintained. Prior to installation, check that the insulation class of this unit satisfies the system requirements.
- Altitude up to 2000 meters.
- The equipment must be mounted inside a panel.
- The equipment must be installed such that appropriate clearance and creepage distances are maintained to conform to CE requirements. Failure to observe these requirements may invalidate the CE conformance.
- The actual installation environments such as panel configurations, connected devices, connected wires, may affect the protection level of this unit when it is integrated in a panel system. The user may have to review the CE requirements in regard to the whole system and employ additional protective measures\* to ensure the CE conformity.
  - \* For example, installation of noise filters and clamp filters for the power source, input and output connected to the unit, etc.
- Install lightning surge protectors for those wires connected to remote locations.

### ■ POWER INPUT RATING & OPERATIONAL RANGE

- Locate the power input rating marked on the product and confirm its operational range as indicated below:
  - 100 – 120V AC rating: 85 – 132V, 47 – 66 Hz, ≤ 5VA
  - 200 – 240V AC rating: 170 – 264V, 47 – 66 Hz, ≤ 7VA

### ■ GENERAL PRECAUTIONS

- Before you remove the unit from its base socket or mount it, turn off the power supply and input signal for safety.

### ■ ENVIRONMENT

- Indoor use.
- When heavy dust or metal particles are present in the air, install the unit inside proper housing with sufficient ventilation.
- Do not install the unit where it is subjected to continuous vibration. Do not subject the unit to physical impact.
- Environmental temperature must be within -5 to +55°C (23 to 131°F) with relative humidity within 10 to 85% RH in order to ensure adequate life span and operation.
- Be sure that the ventilation slits are not covered with cables, etc.


### ■ WIRING

- Do not install cables close to noise sources (relay drive cable, high frequency line, etc.).
- Do not bind these cables together with those in which noises are present. Do not install them in the same duct.

### ■ AND ....

- The unit is designed to function as soon as power is supplied, however, a warm up for 10 minutes is required for satisfying complete performance described in the data sheet.
- With voltage output, do not leave the output terminals shortcircuited for a long time. The unit is designed to endure it without breakdown, however, it may shorten appropriate life duration.
- The edge of the display may be hidden by the frame and invisible depending on the view angle.

## COMPONENT IDENTIFICATION




## INSTALLATION

Loosen the fixing screw in front of the unit in order to separate the body from the base socket.


### ■ FIXING SCREW

The fixing screw can be pushed into the body when it is not in use. Tighten the knob until the body is securely attached to the base socket. Push it into the body and turn it clockwise to lock. Push the knob and turn it counterclockwise to unlock so that the knob pops out.



### ■ DIN RAIL MOUNTING

Set the base socket so that its DIN rail adaptor is at the bottom. Position the upper hook at the rear side of base socket on the DIN rail and push in the lower. When removing the socket, push down the DIN rail adaptor utilizing a minus screwdriver and pull.




### ■ WALL MOUNTING

Refer to "EXTERNAL DIMENSIONS."

## TERMINAL CONNECTIONS


Connect the unit as in the diagram below or refer to the connection diagram on the side of the unit.

### ■ EXTERNAL DIMENSIONS unit: mm (inch)



• When mounting, no extra space is needed between units.


### ■ CONNECTION DIAGRAM



\*1. The output increases when the self-synch rotates clockwise. For changing the operation to counterclockwise and increase, set the ITEM 10 'Rotating direction' to CCW.

\*2. The power input of the unit has polarity. Be sure that the connection for R1 and R2 of the self-synch. When the connection is reversed, the signal conditioner output will be shifted by 180°.

## EXTERNAL VIEWS



COMPONENT	FUNCTION
Display	Indicates present values, setting values and abnormal information. Two types of present values are displayed respectively at the upper and lower parts according to setting.
Mode Button	Shifts from Measuring mode to each setting mode. The destination changes depending on how long the button is held down. Pressing Mode button for $\geq 2$ seconds returns to Measuring mode from each setting mode..
Set Button	Shifts the setting value of each setting parameter item to a setting changeable state. When at setting changeable state, used to move through the digits of setting value for input/output scaling and to enter (save) the setting value.
Up Button	Shifts through setting parameter items and to increase or select the setting value.
Down Button	Shifts through setting parameter items and to decrease or select the setting value.
Configurator Jack	Used to perform configuration with M2E configurator software (model: M2ECFG). When using the software, set the Lockout setting of the unit to 'Lock'.

## DIP SWITCH

The internal DIP switch for output setting is required to select output types before setting a precise output range using front buttons or setting with a PC.

Refer to the "PROGRAMMING" for the operation with front buttons. Refer to the users manual (EM-5147) of M2E Configurator Software (model: M2ECFG) for setting with PC.

Output Range	SW1							
	1	2	3	4	5	6	7	8
0 – 20 mA	OFF	ON	OFF	OFF	OFF	OFF	ON	OFF
-5 – +5 V	OFF	OFF	ON	OFF	ON	OFF	OFF	ON
-10 – +10 V	OFF	OFF	ON	OFF	OFF	ON	OFF	ON

**!** CAUTION: DO NOT set DIP switches while power is supplied. Otherwise, the unit may fail.


## SCREEN DISPLAY

### ■ DISPLAY IN MEASURING MODE

#### • Double tiered display


The unit can display any two items selected out of input engineering value, input scaling value, % value\*, output engineering value, and output scaling value.

\* Percent value for input.



#### • Single tiered display

When there is only one item selected, the value can be displayed in large characters.



Refer to the settings of Advanced mode for details.


### ■ DISPLAY IN EACH SETTING MODE

In each setting mode, setting parameter item name, item No., and setting value are indicated.


During setting, '(Setting)' is indicated next to 'DATA'.

If the power is mistakenly shut down during setting, the set value is discarded and returns to the value before setting change.

Setting display previously displayed before power shut-down is indicated at next power up.



The long parameter item name is scrolled and displayed.



### ■ DISPLAY TIMEOUT


When there is no operation within the preset display timeout period, the display is cleared (display off).

Pressing Mode, Set, Up, or Down button or occurrence of an error restores the display from display off.

Set to '0' to keep the display 'always on'.

# PROGRAMMING

## ■ SETTING FLOWCHART



## ■ OPERATION IN EACH SETTING MODE

### • Basic operation

Mode Button:	In measuring mode, holding down Mode button for $\geq 2$ seconds, $\geq 4$ seconds, $\geq 6$ seconds or $\geq 8$ seconds enables to move on to each setting mode. Holding down Mode button for $\geq 2$ seconds at each setting item display enables to return to measuring mode. Holding down Mode button for $\geq 2$ seconds while changing settings ('(Setting)' is displayed next to 'DATA') enables to discard setting value in changing, and to return to the state before change settings ('(Setting)' next to 'DATA') is off).
Set Button:	Pressing Set button at each setting parameter enables to blink setting value and changing settings is ready ('(Setting)' is displayed next to 'DATA'). Pressing Set button while changing settings enables to enter (save) setting value and change from blinking to on.
Up Button:	Press Up button to move through setting parameters. Selecting setting value while changing settings, increasing a setting value to set value. Keeping pressing Up button enables to increase the value continuously.
Down Button:	Press Down button to move through setting parameters. Selecting setting value while changing settings, decreasing a setting value to set value. Keeping pressing Down button enables to decrease the value continuously.

Note: DO NOT press 2 or more buttons simultaneously.

### • Operation of input setting parameter

[06] Angle offset is set by teach.


The present input value is displayed by pressing set button. With input value desired as 0% is entered, pressing set button again enables to fix the setting.

[07] Angle span sets width used.

Angle for 0% = [06], angle for 100% = [06] + [07]

### • Input/output scaling setting parameter


For input/output scaling setting parameter, set values digit by digit. Pressing Set button enables to move blinking digit. Adjust blinking digit to set numerical value with Up and Down button. Blinking digit moves from most significant digit with pressing Set button. At least significant digit, pressing Set button again enables to turn on and determine the setting value. During setting, press and hold Mode button for  $\geq 2$  seconds to discard the setting value.



### • Lockout setting

'Lockout setting' is available for the unit. When unlocking the lockout setting, indicate 'Lockout Setting' of 'ITEM 01' in each setting mode and set 'Unlock'. To enable lockout setting again, set 'Lock'. Even when lockout setting is enabled, it is available to confirm the each setting value. 'DATA (Locked)' is indicated in that case.

■ BASIC SETTING MODE





## • Parameters

MODE	ITEM	SETTING PARAMETER	RANGE	UNIT	INITIAL VALUE
Basic setting	01	Lockout setting	Lock / Unlock	—	Lock
	06	Angle offset	—	Deg.	0.00
	07	Angle span	60.00 – 359.99	Deg.	270.00
	10	Rotating direction	CW / CCW	—	CW
	14	0 % input scaling	-99999 – 999999	—	0.00
	15	100 % input scaling	-99999 – 999999	—	100.00
	16	Input decimal point	No decimal point The number of decimal places : 1 – 5	—	2 places of decimals
	17	Output range	0 – 20 mA -5 – +5 V -10 – +10 V	—	0 – 20 mA
	18	0 % output setting	0.000 – 19.000 -5.000 – 4.750 -10.000 – 9.000	mA V V	4.000
	19	100 % output setting	1.000 – 20.000 -4.750 – 5.000 -9.000 – 10.000	mA V V	20.000
	20	0 % output scaling	-99999 – 999999	—	0.00
	21	100 % output scaling	-99999 – 999999	—	100.00
	22	Output decimal point	No decimal point The number of decimal places : 1 – 5	—	2 places of decimals
	23	Overrange output < 0 %	-5.00 – 0.00	%	-5.00
	24	Overrange output > 100 %	100.00 – 105.00	%	105.00
26	Loop test	-5.00 – 105.00	%	Cancel	

**[01] Lockout setting**

Set Lock / Unlock of lockout setting.

SETTING VALUE	DESCRIPTION	INITIAL VALUE
Lock	Lockout setting enable	Lock
Unlock	Lockout setting disable	

Even when setting is 'Lock', it is available to move on to each setting mode and confirm the setting value of each setting parameter. In each setting parameter display, when 'Lock', 'DATA (Locked)' is indicated, when 'Unlock', 'DATA' is indicated.

**[06] Angle offset**

Set the position for 0% input entered to the unit. Setting is performed by teach. Press set button to display the present input value. With input value desired as 0% is entered, pressing set button again enables to fix the setting. The value entered the setting is displayed as 'INPUT' in measuring mode.

**[07] Angle span**

Set the Angle span.

SETTING RANGE	INITIAL VALUE
60 – 359.99	270.00

**[10] Rotating direction**

Set the rotating direction of input value.

SETTING VALUE	DESCRIPTION	INITIAL VALUE
CW	Clockwise	CW
CCW	Counter-clockwise	

**[14] 0 % input scaling**

Set the display value of 0 % input.

SETTING RANGE	INITIAL VALUE
-99999 – 999999	0

**[15] 100 % input scaling**

Set the display value of 100 % input.

SETTING RANGE	INITIAL VALUE
-99999 – 999999	100.00

**[16] Input decimal point**

Set the decimal point position of [14] 0 % and [15] 100 % input scaling.

SETTING VALUE	DESCRIPTION	INITIAL VALUE
oooooo	Decimal point: None	2 places of decimals
ooooo.o	Number of decimal places: 1	
oooo.oo	Number of decimal places: 2	
ooo.ooo	Number of decimal places: 3	
oo.oooo	Number of decimal places: 4	
o.ooooo	Number of decimal places: 5	

**[17] Output range**

Set the range of output signal of the unit.

SETTING VALUE	DESCRIPTION	INITIAL VALUE
0 – 20 mA	Output: 0 – 20 mA DC	0 – 20 mA
-5 – +5 V	Output: -5 – +5 V DC	
-10 – +10 V	Output: -10 – +10 V DC	

When output range is changed, turn the power off, and then set the output setting DIP SW on the side of the unit. Setting is as follows. Output setting value is changed to initial value.

OUTPUT RANGE	SW1							
	1	2	3	4	5	6	7	8
0 – 20 mA	OFF	ON	OFF	OFF	OFF	OFF	ON	OFF
-5 – +5 V	OFF	OFF	ON	OFF	ON	OFF	OFF	ON
-10 – +10 V	OFF	OFF	ON	OFF	OFF	ON	OFF	ON

**[18] 0 % output setting**

Set the 0 % output setting.

OUTPUT RANGE	SETTING RANGE	MIN. SPAN	INITIAL VALUE
0 – 20 mA	0.000 – 19.000	1.000	4.000
-5 – +5 V	-5.000 – 4.750	0.250	-5.000
-10 – +10 V	-10.000 – 9.000	1.000	-10.000

Set as follows.

[18] 0 % output setting < [19] 100 % output setting

The value is indicated by 'OUTPUT' at measuring mode.

**[19] 100 % output setting**

Set the 100 % output setting.

OUTPUT RANGE	SETTING RANGE	MIN. SPAN	INITIAL VALUE
0 – 20 mA	1.000 – 20.000	1.000	20.000
-5 – +5 V	-4.750 – 5.000	0.250	5.000
-10 – +10 V	-9.000 – 10.000	1.000	10.000

Set as follows.

[18] 0 % output setting < [19] 100 % output setting

The value is indicated by 'OUTPUT' at measuring mode.

**[20] 0 % output scaling**

Set the display value of [18] 0 % output setting.

SETTING RANGE	INITIAL VALUE
-99999 – 999999	0.00

**[21] 100 % output scaling**

Set the display value of [19] 100 % output setting.

SETTING RANGE	INITIAL VALUE
-99999 – 999999	100.00

**[22] Output decimal point**

Set decimal point position for [20] 0 % and [21] 100 % output scaling.

SETTING VALUE	DESCRIPTION	INITIAL VALUE
oooooo	Decimal point: None	2 places of decimals
ooooo.o	Number of decimal places: 1	
oooo.oo	Number of decimal places: 2	
ooo.ooo	Number of decimal places: 3	
oo.oooo	Number of decimal places: 4	
o.ooooo	Number of decimal places: 5	

**[23] Overrange output < 0 %**

Set the output range not greater than 0 %.

Available range between -5.00 to 0.00 %.

**[24] Overrange output > 100 %**

Set the output range not less than 100 %.


Available range between 100.00 to 105.00 %.

**[26] Loop test**

As pressing Set button enables to blink 'Cancel', changing to 'Set' by pressing Up or Down and pressing 'Set' allows to indicate Loop Test display.

Present value is indicated. Increase or decrease it by pressing Up and Down button. Press and hold them enables to change value continuously.\*1


Pressing and holding Mode button more than 2 seconds or turning off the power enable to exit loop test.



\*1. While loop test is performing, actual input is disregarded.

While loop test is performing and 'Display timeout' is enabled to display off, return to the display on by pressing a front button.

## ■ OPTION MODE



\*1. Refer to [60] Unit (INP Scaling) or [61] Unit (OUT Scaling) for usable unit.

### • Parameters

MODE	ITEM	SETTING PARAMETER	RANGE	UNIT	INITIAL VALUE
Option	60	Unit (INP Scaling)	Choose from 68 types	—	%
	61	Unit (OUT Scaling)	Choose from 68 types	—	%
	67	Filter time constant	0 - 30	sec.	0
	71	Output Zero fine adjust	-5.000 - 5.000	%	0.000
	72	Output Span fine adjust	95.000 - 105.000	%	100.000
	01	Lockout setting	Lock / Unlock	—	Lock

**[60] Unit (INP Scaling)**

Set the unit to display input scaling.

Available units are following 68 types.

DC, AC, mV, V, kV,  $\mu$ A, mA, A, kA, mW, W, kW, var, kvar, Mvar, VA, Hz,  $\Omega$ , k $\Omega$ , M $\Omega$ , cm, mm, m, m/sec, mm/min, cm/min, m/min, m/h, m/s<sup>2</sup>, inch, L, L/s, L/min, L/h, m<sup>3</sup>, m<sup>3</sup>/sec, m<sup>3</sup>/min, m<sup>3</sup>/h, Nm<sup>3</sup>/h, N·m, N/m<sup>2</sup>, g, kg, kg/h, N, kN, Pa, kPa, MPa, t, t/h, °C, °F, K, %RH, J, kJ, MJ, rpm, sec, min, min<sup>-1</sup>, pH, %, ppm, deg, (blank), User

Selecting 'User' enables to move on to user's unit setting display. A unit can be created by using any characters. Up to 13 characters available.\*1 Up and Down button enables to move on selected characters. Set button enables to select a character. While setting, pressing Mode button enables to delete a character, pressing and holding Mode button enables to discard the settings. Pressing and holding Set button enables to determine the setting and return to setting display of [60] Unit (INP Scaling). The unit is indicated by 'INPUT (Scaling)' at measuring mode display.

If turning power off while setting, it returns to setting display of [60] Unit (INP Scaling) (The setting value is discarded).

\*1. Settable characters

0-9 A-Z a-z ! " # \$ % & ' ( ) = -  
+ \* ^ | @ ` [ ] { } ; : < > ? \_ , . /

Initial value: %

**[61] Unit (OUT Scaling)**

Set the unit to display output scaling.

Available units are following 68 types.

DC, AC, mV, V, kV,  $\mu$ A, mA, A, kA, mW, W, kW, var, kvar, Mvar, VA, Hz,  $\Omega$ , k $\Omega$ , M $\Omega$ , cm, mm, m, m/sec, mm/min, cm/min, m/min, m/h, m/s<sup>2</sup>, inch, L, L/s, L/min, L/h, m<sup>3</sup>, m<sup>3</sup>/sec, m<sup>3</sup>/min, m<sup>3</sup>/h, Nm<sup>3</sup>/h, N·m, N/m<sup>2</sup>, g, kg, kg/h, N, kN, Pa, kPa, MPa, t, t/h, °C, °F, K, %RH, J, kJ, MJ, rpm, sec, min, min<sup>-1</sup>, pH, %, ppm, deg, (blank), User

Selecting 'User' enables to move on to user's unit setting display. A unit can be created by using any characters. Up to 13 characters available.\*1 Up and Down button enables to move on selected characters. Set button enables to select a character. While setting, pressing Mode button enables to delete a character, pressing and holding Mode button enables to discard the settings. Pressing and holding Set button enables to determine the setting and return to setting display of [61] Unit (OUT Scaling). The unit is indicated by 'OUTPUT (Scaling)' at measuring mode display.

If turning power off while setting, it returns to setting display of [61] Unit (OUT Scaling) (The setting value is discarded).

\*1. Settable characters

0-9 A-Z a-z ! " # \$ % & ' ( ) = -  
+ \* ^ | @ ` [ ] { } ; : < > ? \_ , . /

Initial value: %

**[67] Filter time constant**

Set filter time constant of the first order lag filter.

The first order lag filter is available with setting time. When '0' is set to this parameter, the first order lag filter is not available (Response time:  $\leq 0.5$  sec. (0  $\rightarrow$  90 %)).

The first order lag filter is equivalent to general CR filter.

The setting time constant is the time to follow until about 63 %, when input varies from 0 % to 100 %.

It is available to set the range between 0 – 30 seconds.

Initial value: 0

**[71] Output Zero fine adjust**

Perform fine adjustment of output signal. Available range between -5.000 – +5.000 %.

Initial value: 0.000

**[72] Output Span fine adjust**

Perform fine adjustment of output signal. Available range between 95.000 – 105.000 %.

Initial value: 100.000


**[01] Lockout setting**

Set Lock / Unlock of lockout setting.

SETTING VALUE	DESCRIPTION	INITIAL VALUE
Lock	Lockout setting enable	Lock
Unlock	Lockout setting disable	

Even when setting is 'Lock', it is available to move on to each setting mode and confirm the setting value of each setting parameter. In each setting parameter display, when 'Lock', 'DATA (Locked)' is indicated, when 'Unlock', 'DATA' is indicated.

■ ADVANCED MODE



\*1. For detail, refer to the [90] Display setting.

• Parameters

MODE	ITEM	SETTING PARAMETER	RANGE	UNIT	INITIAL VALUE
Advanced	90	Display setting	Upper: choose from 5 types Lower: choose from 6 types	—	Upper: INPUT Lower: PERCENT
	91	Brightness	1 (darkest) - 4 (brightest)	—	4
	92	Display timeout	0 (always on), 1 - 60	min.	10
	93	Reset all settings	OFF / RESET	—	OFF
	94	Version indication	—	—	—
	01	Lockout setting	Lock / Unlock	—	Lock

**[90] Display setting**

Set display setting in measuring mode. Display is divided, indicating item can be set for each upper and lower. Pressing Set button once is setting for upper, pressing again for lower, pressing once more for setting determined.

**Upper**

SETTING VALUE	DESCRIPTION	INITIAL VALUE
INPUT	Input engineering unit value	INPUT (engineering value)
INPUT (Scaling)*1	Input scaling	
PERCENT	Percent value*3	
OUTPUT	Output engineering unit value	
OUTPUT (Scaling)*2	Output scaling	

\*1. Display at measuring mode is INP (Scaling).

\*2. Display at measuring mode is OUT (Scaling).

\*3. Display the value converted as 0.00 to 100.00 % based on input setting value.

**Lower**

SETTING VALUE	DESCRIPTION	INITIAL VALUE
INPUT	Input engineering unit value	PERCENT (percent value)*3
INPUT (Scaling)*1	Input scaling	
PERCENT	Percent value*3	
OUTPUT	Output engineering unit value	
OUTPUT (Scaling)*2	Output scaling	
None	No display	

\*1. Display at measuring mode is INP (Scaling).

\*2. Display at measuring mode is OUT (Scaling).

\*3. Display the value converted as 0.00 to 100.00 % based on input setting value.

**[91] Brightness**

Adjust brightness of display. It is available to set the range between 1 (darkest) – 4 (brightest).

Initial value: 4

**[92] Display timeout**

Set the time to off the display when there is no operation within a certain time.

It is available to set the range between 0 – 60 minutes.

Set '0' to display 'always on'.

When error is occurred at display off, the display returns from off.

Initial value: 10

**[93] Reset all settings**

Return settings to initial value.

SETTING VALUE	DESCRIPTION
OFF	Not initialized.
RESET	Initialize all settings*1

\*1. When setting value is initialized, each parameters currently set are over written by initial value. 'COMPLETE' is indicated when initializing setting value is completed. Notice that it does not return to the setting value, which is specified by the option Ex-factory setting (/SET). Configure initialized value again with DIP switch with power off for output setting.

**[94] Version indication**

Indicate firmware version.


**[01] Lockout setting**

Set Lock / Unlock of lockout setting.

SETTING VALUE	DESCRIPTION	INITIAL VALUE
Lock	Lockout setting enable	Lock
Unlock	Lockout setting disable	

Even when setting is 'Lock', it is available to move on to each setting mode and confirm the setting value of each setting parameter. In each setting parameter display, when 'Lock', 'DATA (Locked)' is indicated, when 'Unlock', 'DATA' is indicated.

■ LINEARIZATION MODE



• Parameters

MODE	ITEM	SETTING PARAMETER	RANGE	UNIT	INITIAL VALUE
Linearization	100	User's table linearization	Disable / Enable	—	Disable
	101	Number of points	2 – 32	—	2
	102 – 165	Table	-5.00 – 105.00	%	X001 -5.00 Y001 -5.00 X002 105.00 Y002 105.00
	01	Lockout setting	Lock / Unlock	—	Lock



**[100] User's table linearization**

SETTING VALUE	DESCRIPTION	INITIAL VALUE
Disable	Linearization disable	Disable
Enable	Linearization enable	

When Enable is selected, input is converted to output by using user's table.

**[101] Number of points**

Set number of points for user's table.

It is available to set the range between 2 – 32 points.

Initial value: 2


**[102 – 165] Table**

For the conversion by using user's table, conversion input is searched from the table in which X corresponds to input (unit: %) and Y corresponds to output (unit: %) are paired, and Y, which corresponds output of matched table, is the output.


The range is available between -5 to +105 (%) for both X and Y. For X, it is required to set in ascending order from X001. Be sure that if it is set with other than ascending order, correct conversion is not carried out.

Initial value: X001 -5.00  
 Y001 -5.00  
 X002 105.00  
 Y002 105.00

[E.g.]



When the input is not defined in the user's table, two nearest value for each positive and negative are selected in written X. These two data are linearly interpolated and Y is obtained and output it.



**[01] Lockout setting**

Set Lock / Unlock of lockout setting.

SETTING VALUE	DESCRIPTION	INITIAL VALUE
Lock	Lockout setting enable	Lock
Unlock	Lockout setting disable	

Even when setting is 'Lock', it is available to move on to each setting mode and confirm the setting value of each setting parameter. In each setting parameter display, when 'Lock', 'DATA (Locked)' is indicated, when 'Unlock', 'DATA' is indicated.

## ERROR MESSAGES

DISPLAY	ERROR DESCRIPTION	WHAT TO DO
OVER RANGE U	The input exceeds 105 %.	Return the input signal not exceed 105 %.
OVER RANGE D	The input exceeds lower limit of -5 %.	Return the input signal -5 % or more.
SCALING ERROR U	Input or output scaling value exceeds 999999 (upward).	Return the input or output signal not exceed 999999.
SCALING ERROR D	Input or output scaling value exceeds -999999 (downward).	Return the input or output signal not lower than -999999.
EEPROM I ERROR	Internal data error	Repair is needed if the display does not recover after the power is reset.
EEPROM R ERROR	Memory reading error	'Reset all settings' in advanced mode.*1
EEPROM W ERROR	Memory writing error	'Reset all settings' in advanced mode.*1

\*1. All setting parameters are initialized. Repair is needed if it does not recover.

Indicated errors vary as follows depending on setting value of display setting.

Error is indicated blinking at upper or lower.

When multiple error occurs, only high priority error is displayed.

Order of priority is EEPROM ERROR, OVER RANGE, SCALING ERROR in descending order.

ERROR MESSAGES		DISPLAY SETTING				
		INPUT ENGINEERING UNIT VALUE	INPUT SCALING VALUE	PERCENT VALUE	OUTPUT ENGINEERING UNIT VALUE	OUTPUT SCALING VALUE
OVER RANGE U		✓	✓	—	✓	✓
OVER RANGE D						
SCALING ERROR U (INPUT)		✓	✓	—	—	—
SCALING ERROR D (INPUT)						
SCALING ERROR U (OUTPUT)		—	—	—	✓	✓
SCALING ERROR D (OUTPUT)						
EEPROM I ERROR		✓				
EEPROM R ERROR						
EEPROM W ERROR						

## WIRING INSTRUCTIONS

### ■ SCREW TERMINAL


Torque: 0.8 N·m

### ■ SOLDERLESS TERMINAL

Refer to the drawing below for recommended ring tongue terminal size. Spade tongue type is also applicable.

Applicable wire size: 0.25 to 1.65 mm<sup>2</sup> (AWG 22 to 16)

Recommended manufacturer: Japan Solderless Terminal MFG.Co.Ltd, Nichifu Co.,ltd



## CHECKING

- 1) Terminal wiring: Check that all cables are correctly connected according to the connection diagram.
- 2) Check DIP switch setting.
- 3) Input signal and power input voltage: Check wiring across M2EXS and self-synch as follows; terminal 1 – S1, terminal 2 – S2, terminal 4 – S3, terminal 10– R1, and terminal 11 – R2.  
Be sure that the connection for R1 and R2 of the self-synch. When the connection is reversed, the signal conditioner output will be shifted by 180°.
- 4) Output: Check that the load resistance meets the described specifications.

---

## MAINTENANCE

Regular calibration procedure is explained below:

### ■ CALIBRATION

Warm up the unit for at least 10 minutes. Apply 0%, 25%, 50%, 75% and 100% input signal. Check that the output signal for the respective input signal remains within accuracy described in the data sheet. When the output is out of tolerance, recalibrate the unit as explained in the users manual of the M2ECFG configurator software. Or follow the procedure shown below.

#### • INPUT FINE ADJUSTMENT

Set the input signal to 0%, and adjust the input to 0% by [06] Angle offset.

#### • OUTPUT FINE ADJUSTMENT

- 1) Set the simulated input to 0%, and adjust the output signal to 0% by [71] Output Zero fine adjust.
- 2) Set the simulated input to 100%, and adjust the output signal to 100% by [72] Output Span fine adjust.
- 3) Again set the simulated input to 0%, confirm the output signal.
- 4) If output signal is shifted, repeat the procedure from 1) to 3).

---

## LIGHTNING SURGE PROTECTION

We offer a series of lightning surge protector for protection against induced lightning surges. Please contact us to choose appropriate models.