

**Model 53U / 54U / 54UL / 54UC Multi Power Monitor**

**Model R7LWTU / R7CWTU / R7MWTU / R7EWTU Multi Power Module**

**Model R9LWTU / R9CWTU / R9MWTU / R9EWTU Multi Power Unit**

**Model L53U Multi Power Transducer**

**Model M5XWTU / M5XWT / M50XWTU / M50EXWTU  
Multi Power Transducer**

**PC CONFIGURATOR SOFTWARE**

**Model: PMCFG Ver. 1.21**

# Users Manual

# CONTENTS

<b>1. INTRODUCTION .....</b>	<b>4</b>
1.1 GENERAL DESCRIPTION.....	4
1.2 PC REQUIREMENTS.....	4
1.3 INSTALLING & DELETING THE PROGRAM .....	6
<b>2. BASIC OPERATIONS .....</b>	<b>7</b>
2.1 STARTING THE PMCFG.....	7
2.2 MODIFYING PARAMETERS.....	8
2.2.1 READING PARAMETERS FROM DEVICE (UPLOAD).....	8
2.2.2 MODIFYING PARAMETERS ON THE SCREEN .....	10
2.2.3 WRITING PARAMETERS TO DEVICE (DOWNLOAD) .....	10
2.3 PROTECTING PARAMETERS.....	11
2.4 SAVING FILES .....	12
2.4.1 READING PARAMETERS SAVED AS FILE.....	12
2.4.2 SAVING PARAMETERS IN A FILE .....	12
2.5 REPORT.....	13
2.5.1 DISPLAYING PARAMETERS.....	13
2.5.2 COMPARING PARAMETERS .....	13
2.5.3 CSV FILE .....	13
2.6 MONITORING MEASURED VALUES .....	14
2.6.1 For 53U, L53U, 54U, 54UC, 54UL, R7MWTU, R7CWTU, R7LWTU, R7EWTU, M5XWTU, M5XWT, M50XWTU, and M50EXWTU .....	14
2.6.2 For R9MWTU, R9CWTU, R9LWTU and R9EWTU .....	16
2.7 NETWORK LOOP TEST .....	18
2.8 PRESET .....	18
2.9 ANALOG OUTPUT LOOP TEST .....	19
2.10 RESTARTING DEVICE.....	19
2.11 SWITCHING LANGUAGE .....	19
<b>3. PARAMETER LIST.....</b>	<b>20</b>
<b>4. BASIC PARAMETERS .....</b>	<b>38</b>
4.1 MODEL.....	38
4.2 INPUT.....	40
<b>5. FUNCTION PARAMETERS.....</b>	<b>42</b>
5.1 DEMAND UPDATE INTERVAL.....	42
5.2 ALARM .....	43
5.3 TARIFF .....	45
5.4 PASSCODE .....	45
5.5 OTHER SETTINGS .....	46
5.5.1 INPUT .....	46
5.5.2 ENERGY .....	46
5.5.3 CALCULATION METHOD .....	47

5.6	CONVERSION VALUE .....	48
5.6.1	CONVERSION VALUE COEFFICIENT .....	48
5.6.2	CONVERSION VALUE DISPLAY UNIT .....	48
<b>6.</b>	<b>OPTION PARAMETERS .....</b>	<b>49</b>
6.1	DISPLAY .....	49
6.1.1	LCD BACKLIGHT .....	49
6.1.2	DISPLAY .....	50
6.1.3	MY DEFAULT .....	51
6.1.4	AUTO OFF .....	51
6.1.5	DISPLAY BRIGHTNESS .....	51
6.1.6	DISPLAY FORMAT .....	51
6.1.7	ACTIVE DISPLAY .....	53
6.2	EXTENSION BAR .....	53
6.3	$\Sigma$ DISPLAY .....	54
6.4	DISPLAY EXPRESSION .....	56
6.5	SHORT CUT .....	56
<b>7.</b>	<b>EXTERNAL INTERFACE PARAMETERS .....</b>	<b>57</b>
7.1	DISCRETE INPUT .....	57
7.2	DISCRETE OUTPUT .....	57
7.3	ENERGY .....	58
7.4	ANALOG OUTPUT .....	60
7.5	MODBUS .....	63
7.6	ADVANCED MODBUS SETTING .....	64
7.7	CC-Link .....	64

# 1. INTRODUCTION

## 1.1 GENERAL DESCRIPTION

The PMCFG is used to program parameters for the models 53U, 54U, 54UL or 54UC Multi Power Monitor, R7CWTU, R7MWTU, or R7EWTU Multi Power Modules, R9MWTU, R9CWTU or R9EWTU Multi Power Units, L53U Multi Power Transducer, and M5XWTU, M5XWT, M50XWTU, or M50EXWTU Multi Power Transducer (referred hereunder as 'device'). The following major functions are available:

- Edit parameters
- Download parameters to the device, upload parameters from the device
- Save parameters as files, read parameters from files
- Compare parameters edited on the screen with the ones stored in the device
- Monitoring measured values
- Loop test (only for R7xWTU, R9xWTU M5XWTU, M5XWT, M50XWTU and M50EXWTU)

Note: For R7LWTU and R9LWTU, only "monitoring measured values" and "loop test" functions are selectable.

## 1.2 PC REQUIREMENTS

The following PC performance is required for adequate operation of the software program.

PC	IBM PC compatible
OS	Windows 10 (32-bit/64-bit) Windows 11 (64-bit) The software may not function adequately in certain conditions.
CPU	Must meet the relevant Windows OS' requirements.
Memory	Must meet the relevant Windows OS' requirements.
Communication port	At least one COM port (COM1 through COM16) or LAN port is required.

For connecting the devices to a PC, the our products detailed in the table below are required.

DEVICES	NETWORK	REQUIRED PRODUCTS
53U R7LWTU R7CWTU R7MWTU R7EWTU R9LWTU R9CWTU R9MWTU R9EWTU L53U M5XWTU M5XWT M50XWTU M50EXWTU	RS-232-C	PC configurator cable (model: MCN-CON or COP-US)
53U (with Modbus) 54U (with Modbus) R7MWTU R9MWTU L53U (with Modbus) M5XWTU (with Modbus) M5XWT (with Modbus) M50XWTU M50EXWTU	RS-485	RS-232-C/RS-485 converter (model: R2K-1) or Transmission level converter (model: LK-1)

53U (with Modbus) 54U (with Modbus) R7MWTU R7EWTU R9MWTU R9EWTU L53U (with Modbus) M5XWTU (with Modbus) M5XWT (with Modbus) M50XWTU M50EXWTU	Ethernet	Ethernet communication adaptor (model: GR8-EM, 72EM-M4 or 72EM2-M4) (R7EWTU, R9EWTU do not require Communication Adaptor)
54U 54UL 54UC	Infrared	Infrared communication adaptor (model: COP-IRU)


### CONNECTING THE DEVICE TO THE PC

The RS-232-C/RS-485 Converter (model: R2K-1 or LK1) or the Communication Adaptor (model: 72EM-M4 or 72EM2-M4) is used to interface the device on the Modbus network to the PC.

In order to locally program the device, the non-isolated PC Configurator Cable (model: MCN-CON or COP-US) is required to connect it to the PC. The RS-485 cable must be removed when the device is connected with the PC Configurator Cable.

The 54U, 54UC and 54UL can be connected to the PC via the infrared port using the Infrared Communication Adaptor (model: COP-IRU).


#### ■ LOCAL CONNECTION



Remove RS-485 cable (Modbus) from 53U and/or L53U when connected to PC Configurator Cable. The RS-485 and PC Configurator Cable cannot operate at once.


When communicating with 53U with analog output by using configurator cable, it is required to press and hold the 'IU->' button to switch to the communication mode. After communication is completed, pressing and holding the 'IU->' button enable to return to the measurement view. For L53U without option code 'A', it is required to turn on the mode selector. Analog output level is fixed while in the communication mode.

#### ■ NETWORK CONNECTION (RS-485)



Set individual node address to each device. Modbus setting for all connected devices must be identical (baud rate, parity, stop bit). Remove the PC Configurator Cable from 53U and/or L53U. The RS-485 and the PC Configurator Cable cannot operate at once.

## ■ NETWORK CONNECTION (Ethernet)




Setting multiple master stations (PCs) is possible with Ethernet (Modbus/TCP) configuration, however, only one (1) PC is allowed to communicate to the devices when programming with the PMCFG. Accessing the devices from multiple stations may cause unexpected effects.

Set Modbus parameters for the devices as follows:  
 Node address: Individual number  
 Baud rate: 19200 bps or 38400 bps  
 identical to the 72EM-M4 or 72EM2-M4 setting  
 Parity: Odd  
 Stop bit: 1 bit

Set the 72EM-M4 or 72EM2-M4 as follows:  
 RS-485 baud rate: See above  
 Read timeout: 500  
 Write timeout: 2000

## ■ LOCAL CONNECTION (infrared)



When using infrared communication, press and hold the 'IU->' button of 54U, 54UL or 54UC to switch to infrared communication mode. After communication is completed, pressing and holding the 'IU->' button enable to return to the measurement view.


DO NOT set multiple devices to the infrared communication mode at once.  
 Interference may cause unexpected results.

## 1.3 INSTALLING & DELETING THE PROGRAM

### INSTALL

The program is provided as compressed archive. Decompress the archive and execute 'setup.msi' to start up the PMCFG installer program. Follow instructions on the Windows.

Log on as administrator but you still need to clarify your administrative right before proceeding. When User Account Control window appears, choose 'Continue' or 'Yes'.



'PMCFG' is shown instead of 'Program name'.

### DELETE

Uninstall a program, or Uninstall or change a program. Select the PMCFG X.X (X.X refers version number) from the program list and click Uninstall button.

## 2. BASIC OPERATIONS

### 2.1 STARTING THE PMCFG

Open Program > MG > PMCFG to start up it on a Windows PC. The following window appears on the screen.

PMCFG Version 1.19.66

Upload Download Protect Report Save File Open File Monitor Reboot Language

Model 53U- 1\*\*1 Modbus, Do x1, Di x1 Ver.1.02 or earlier

Input

System 3-phase / 4-wire, unbalanced load (3CT)

VT rating CT rating

Primary 110 V Primary 5 A

Secondary 110 V Secondary 5 A

Bar 100% 300 V Bar 100% 5 A

Function

Demand Current Internal timer 30 min.

Power Internal timer 30 min.

Alarm Tariff Others Conv. Value

Operation

Display Ext. Bar Sigma Disp. Expression Short Cut Passcode

External Interface

Di Do / Po Ao Modbus CC-Link

## 2.2 MODIFYING PARAMETERS

In order to modify parameters stored in the device, first (1) upload the device parameters, (2) modifying a part of or all of them on the screen, and then (3) download the new parameters to the device.

### 2.2.1 READING PARAMETERS FROM DEVICE (UPLOAD)

Reading parameters from device. Click Upload button to open the following dialog box.

The 'Connect' dialog box shows the following settings:

- CONFIG
- Infrared
- Modbus-RTU (RS-485)
- Modbus/TCP (TCP/IP)
- COM port: M-SYSTEM COP-US (COM4)
- Buttons: Connect, Cancel

Text below the radio buttons: For 53U, the Modbus settings also apply to CONFIG communications, so you must select Modbus-RTU and adjust the transfer rate, parity bit, stop bit, and device address (node address) to the Modbus settings. (except when the Modbus settings are the same as the default values)

In order to connect to the device via the configuration cable, check CONFIG and select COM port to use, then click Connect button.

53U	The Modbus settings also apply to CONFIG communications, so you must select Modbus-RTU and adjust the transfer rate, parity bit, stop vit, and device address (node address) to the Modbus setting, then click Conect button.
53U (with analog output)	hold down [ IU ►] button to switch the device to the communication mode before starting uploading. Note: The analog output is fixed during 53U is in communication mode, regardless of variation of input.
L53U without option code '/A'	Set Mode Selector of the L53U to ON and click 'Connect' button. Note: The analog output is fixed during 53U is in communication mode, regardless of variation of input.

In order to connect to the 54U, 54UC or 54UL via the Infrared Communication Adaptor, hold down [ IU ►] button to switch the device to the infrared communication mode, check Infrared and select Infrared Communication Adaptor before starting uploading.

The 'Connect' dialog box shows the following settings:

- CONFIG
- Infrared
- Modbus-RTU (RS-485)
- Modbus/TCP (TCP/IP)
- COM port: M-System COP-IRU USB IR Adaptor (COM5)
- Buttons: Connect, Cancel

Note: The analog output is fixed during 54Ux is in communication mode, regardless of variation of input.

In order to connect to the device via the RS-485, check Modbus-RTU (RS-485) and enter COM port to use, baud rate, parity bit, stopbit, and device address (node address), the click Connect button.

The 'Connect' dialog box shows the following settings:

- CONFIG
- Infrared
- Modbus-RTU (RS-485)
- Modbus/TCP (TCP/IP)
- COM port: USB Serial Device (COM5)
- Transfer rate: 38400 bps
- Device address: 1
- Parity bit: Odd
- Stop bit: 1 bit
- Buttons: Connect, Cancel



In order to connect to the device via the Modbus/TCP, check Modbus/TCP (TCP/IP), enter IP address of the Modbus/TCP device to Station address, port number to Port (standard port number of the Modbus/TCP is 502) and Device address (node address), then click Connect button.



The image shows a 'Connect' dialog box with a close button (X) in the top right corner. On the left, there are four radio button options: 'CONFIG', 'Infrared', 'Modbus-RTU (RS-485)', and 'Modbus/TCP (TCP/IP)'. The 'Modbus/TCP (TCP/IP)' option is selected. To the right of these options are three input fields: 'Station address' containing '192.168.0.1', 'Device address' containing '1', and 'Port' which is a dropdown menu showing '502'. In the top right corner of the dialog, there are two buttons: 'Connect' (highlighted in blue) and 'Cancel'.


Once all parameters confirmed, click [Connect] to start reading parameters stored in the connected device to show them on the screen.

If an error message appears, confirm the hardware connection and network configuration and its parameters to retry.


## 2.2.2 MODIFYING PARAMETERS ON THE SCREEN

The initial window shows only basic parameters on the screen. Buttons such as [Alarm], [Energy] and [Advanced] are used to go into more detailed settings for respective categories.

In the example shown below, the device input has been changed to: 3-phase/4-wire, unbalanced load, VT ratio 6600/110V, CT ratio 100/5A.



Choose from the menu options or enter appropriate values.



Detailed description on each parameter and control button are given in the later pages of this manual.


## 2.2.3 WRITING PARAMETERS TO DEVICE (DOWNLOAD)

Clicking [Download] opens the Connect dialog box just as [Upload] button did. Specify the relevant device address. Specify also the COM port and Modbus communication parameters depending upon the network configuration and the device's communication parameters.

Click [Connect] to start downloading new parameters.

When the Modbus register writing protection is activated, a dialog box requesting Modbus passcode entry will appear on the screen.

Once downloading begins, a bargraph appears on the screen to indicate progress. When it disappears without any error messages, the new setting becomes valid.



---

### Caution !

Modbus parameters are not enabled by downloading. The device must be restarted (power supply turned off and on).

---

## 2.3 PROTECTING PARAMETERS

This function is usable with Firmware Version 1.01 or later of the 53U, all available versions of the 54U, 54UL, 54UC, R7xWTU, R9xWTU and L53U.

In order to protect parameter changes by the front keys of the 54U, 53U, 54UC and 54UL, Passcode (4-digit number) is used. It is also possible to lock local key operations to go to Setting mode.

In order to protect parameter changes via Modbus (CONFIG port or RS-485), Modbus Register Writing Protection Passcode is used. The code consists of 9-digit number.

Clicking [Protection] opens the Connect dialog box just as [Upload] button did. Specify the relevant device address.

Specify also the COM port and Modbus communication parameters depending upon the network configuration and the device's communication parameters.

Click [Connect] to open Protect Setting dialog box.

Modbus passcode is selectable between 1 and 999 999 999. In order to change, enter the current passcode and new passcode (twice). If there is no passcode setting or if you do not want to activate the protection, leave relevant field blank. Click [OK].

---

**Caution !**

Once a passcode is set, no parameter changes via Modbus are available unless the correct passcode is entered.  
BE SURE NOT TO FORGET the passcode.


---

## 2.4 SAVING FILES

Parameter set on the screen can be saved as a file on the hard disk. A file can be called up on the screen. You can store backup setting data by utilizing these functions in combination with [Upload] [Download] functions.


### 2.4.1 READING PARAMETERS SAVED AS FILE

Clicking [Open File] calls up the Windows-standard Open dialog box. Select a parameter file to show a stored parameter setting.



### 2.4.2 SAVING PARAMETERS IN A FILE


Clicking [Save File] calls up the Windows-standard Save As dialog box. Enter a desired file name to File Name field and click [Save] to store a parameter setting.



## 2.5 REPORT

### 2.5.1 DISPLAYING PARAMETERS

Clicking [Report] opens Parameter Report window showing all parameters presently edited on the screen.



### 2.5.2 COMPARING PARAMETERS

Parameters presently edited on the screen and those stored in the connected device or in a file can be compared side by side.

Click [Device] in order to upload the parameters in the device, or [File] to upload those in a file. Parameters are compared and listed on the screen side by side.

The rows showing differences between two sets of parameters are highlighted in red background. Cells for matching parameters are filled in white, or light gray. Gray characters shows parameters not supported by the other one.

The total number of non-matching cases is mentioned in the bottom of the window frame.

### 2.5.3 CSV FILE

The parameter list can be exported as a CSV text format file for use in another application software such as Microsoft Excel.

Click [Export Csv] button at the top left of the screen and go through standard Windows Save As procedure.

Input the file name and click [Save] button then the CSV file with the name is created. The CSV file format is in the following:

- Each row for one parameter
- Each row (parameter) consists of 3 or 4 separated data
- Data is arranged in order of 'Parameter group,' 'Parameter identification,' 'Parameter edited' and 'Parameter to compare.'

If you have not uploaded a parameter set for comparing, 'Parameter to compare' is not exported.

[Example]


```
"Display" , "Operation mode" , "All key operations are available"  
"Display" , "Data display view" , "0"  
"Display" , "Energy display view" , "EP / Active energy, incoming"
```

## 2.6 MONITORING MEASURED VALUES

All the measured values of a particular device can be displayed on the PC screen.

Clicking [Monitor] opens the Connect dialog box (See Figure in Section 2.2.3). Specify the relevant device address, COM port and Modbus communication parameters and click [Connect].

### 2.6.1 For 53U, L53U, 54U, 54UC, 54UL, R7MWTU, R7CWTU, R7LWTU, R7EWTU, M5XWTU, M5XWT, M50XWTU, and M50EXWTU



Once the PC has started communicating with the connected device, display values are updated in approx. 0.5 seconds intervals.

### DEVICE INFORMATION

Tag No.	Tag number
Modbus passcode	Modbus register writing protection status Protection enabled : Modbus registers are write-protected. Protection disabled : Modbus registers are not protected. Not supported : This function is not supported.
Model	Model number
Serial	Serial number
Firmware version	Firmware version number
Support information	our support information

### INSTANTANEOUS & DEMAND VALUES

[Real time], [Max] and [Min] tabs are selectable to switch the view between the instantaneous values, the maximum values and the minimum values respectively.

Unit: Voltage (V), current (A), active power (W), reactive power (var), apparent power (VA), power factor (cosφ), frequency (Hz)

### ENERGY AND COUNTER VALUES

Display the counter values. Clicking on TAB, the energy's high tariff (peak time) and low tariff (off-peak time) and the pulse counter value are sequentially displayed.

Unit: Hour (hour), active energy (kWh), Reactive energy (kvarh), apparent energy (kVAh)

## HARMONIC DISTORTION VALUES

The left-bottom table shows the total harmonic distortion (THD) for each measurand. Clicking on a row in this table switches the measurand displayed in the right-bottom table, where the detailed harmonic distortion values from 1st to 31st are shown.

Unit: %

Harmonic distortion is not displayed when the M5XWT is connected.

## VECTOR CHART

The chart shows the vector chart for input voltage and current.

U1N, U2N, and U3N show the vector of phase 1, phase 2, and phase 3 (R phase, S phase, T phase) voltages.

I1, I2, and I3 show the vector of line 1, line 2, and line 3 (R line, S line, T line) currents.

In three-phase/3-wire, each phase voltage vector is displayed with the virtual midpoint as the neutral point (origin).

In M5XWTU and M5XWT (as shown in the previous page), in three-phase/3-wire, U1N shows the voltage between line 1-2, and U3N shows the voltage between line 3-1.

For M50XWTU and M50EXWTU, trend value, maximum value, minimum value and energy for each circuit are switchable with tab.

In addition, clicking vector chart, circuit to display the vector chart can be switched.

The screenshot displays the PMCFG Version 1.16.59 interface. On the left, there is a 'Utility' button and a 'Device Information' section. The 'Vector Chart' shows a circular plot with vectors for U1N, U2N, U3N, I1, I2, and I3. Below the chart is a 'Harmonics' table with columns for 'Latest' and 'Max'. At the bottom left is an 'Analog Output' section. The main window is divided into two tables, one of which is highlighted with a red border.

Trend		Max	Min	Energy
	Voltage	Frequency		
1-N	110.00	60.00		
2-N	109.99			
3-N	110.06			
1-2	190.53			
2-3	190.55			
3-1	190.61			

Circuit A		Circuit B		Circuit C		
	Sigma	Current	Active power	React. power	App. power	Power factor
1-N	0.000	0.0	0.0	0.0	0.0	1.0000
2-N	0.000	0.0	0.0	0.0	0.0	1.0000
3-N	0.000	0.0	0.0	0.0	0.0	1.0000
1-2	4.997	264.4	482.9	550.6	0.4811	
2-3	5.002	264.3	482.6	550.2	0.4805	
3-1	5.005	264.7	483.1	550.8	0.4807	

Harmonics	Latest	Max
A current 1	0.0	0.0
A current 2	0.0	0.0
A current 3	0.0	0.0
C current 1	0.0	0.2
C current 2	0.0	0.2
C current 3	0.2	0.3
Voltage 1-2	0.0	0.0
Voltage 2-3	0.0	0.0
Voltage 3-1	0.0	0.0

## UTILITY

By clicking [Utility] button at left top, the following window appears. The buttons in the window reset counters, edit Tag Number or execute a Network loop test. For detail, refer to the following.

The Utility dialog box contains the following buttons:

- Energy
- Max/Min
- Demand
- Counter
- Tag No.
- Loop Test
- Preset
- Clear Alarm

Energy	Reset all the energy counts to zero.
Max/Min	Reset all the maximum and minimum values to the present values
Demand	Reset all the demand values to zero.
Counter	Resets all counters to 0. Only for R7LWTU, R7CWTU, R7EWTU and R7MWTU.
Tag No.	Open Tag Number Setting dialog box. Max. 16 characters.

Loop test	Executes a network (LONWORKS, CC-Link, Modbus) loop test with arbitrarily changed measurand. Only for R7LWTU, R7CWTU, R7MWTU, R7EWTU, M5XWTU, M5XWT, M50XWTU, and M50EXWTU.
Clear alarm	Clears the latched alarm

## ANALOG OUTPUT LOOP TEST

Performs loop test for analog output. Details are described below.

Unit: Voltage output (V), current output (mA)

### 2.6.2 For R9MWTU, R9CWTU, R9LWTU and R9EWTU

	1ch	2ch	3ch	4ch	5ch	6ch	7ch	8ch
00:00 to 01:00	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
01:00 to 02:00	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
02:00 to 03:00	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
03:00 to 04:00	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
04:00 to 05:00	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
05:00 to 06:00	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
06:00 to 07:00	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
07:00 to 08:00	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
08:00 to 09:00	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
09:00 to 10:00	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
10:00 to 11:00	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
11:00 to 12:00	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
12:00 to 13:00	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
13:00 to 14:00	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
14:00 to 15:00	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
15:00 to 16:00	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
16:00 to 17:00	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
17:00 to 18:00	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
18:00 to 19:00	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
19:00 to 20:00	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
20:00 to 21:00	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
21:00 to 22:00	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
22:00 to 23:00	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
23:00 to 00:00	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
Latest	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
Reset	Reset	Reset	Reset	Reset	Reset	Reset	Reset	Reset
Detail	Detail	Detail	Detail	Detail	Detail	Detail	Detail	Detail
Active power	0	0	0	0	0	0	0	0
Current 1	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000
Current 2	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000
Current 3	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000
Power factor	1.0000	1.0000	1.0000	1.0000	1.0000	1.0000	1.0000	1.0000
Active in	111.1	222.2	333.3	444.4	555.5	666.6	777.7	888.8
Reactive LAG	1111.1	2222.2	3333.3	4444.4	5555.5	6666.6	7777.7	8888.8
Reset	Reset	Reset	Reset	Reset	Reset	Reset	Reset	Reset
Detail	Detail	Detail	Detail	Detail	Detail	Detail	Detail	Detail

## ENERGY

Energy per hour for maximum past 24 hours is displayed. When resetting, data for 24 hours and latest value are set to '0'. [Basic Module] and [Extension Module] tabs are selectable to switch the view. When extension unit is R9WTU-ED16, both red-boxed area show counter value.

Unit: Energy (kWh)

## MOMENTARY VALUE

Power, current and power factor are shown. Also, active energy and reactive energy are shown, when resetting these energies are set to '0'.


Unit: Active power (W), current (A), power factor (cosφ), active energy (kWh), reactive energy (kvarh)

By clicking [Device Info] button at top, the following window appears. In this window, the device information is shown and TAG No. can be changed.


Tag No.	8967452367452301
Modbus passcode	Protection disabled
Model	R9
Serial	2F018370
Firmware version	1.40
Support information	0



By clicking [...] button at right top, the following window appears. In this window, date/time can be set.



By clicking [Detail] button at bottom, the following window appears. In this window, momentary value, maximum/minimum value, average value and harmonic distortion are displayed. Clicking button enables resetting of maximum/minimum value.



Note: Notice that resetting of maximum/minimum value affects display of other channels because voltage and voltage THD are common measurement items among each channel.

## 2.7 NETWORK LOOP TEST

For R9xWTU in the monitor view, for others in the utility view, clicking Loop Test button enables to execute network loop test. With network loop test it is available to set some measured value by device to any given value. Also, it is available to confirm the communication of open network by checking to read set value at communication destination of open network such as LonWorks, CC-Link and Modbus.

	Voltage	Current	Active power	React. power	App. power	Power factor
Sigma	0.34	0.015	0	0	0	1.0000
1-N	0.21	0.007	0	0	0	1.0000
2-N	0.36	0.022	0	0	0	1.0000
3-N	0.47	0.016	0	0	0	1.0000
1-2	0.25					
2-3	0.38	N. current	Frequency			
3-1	0.43	0.000	0.00			

R7xWTU, M5XWTU, and M5XWT

	Voltage	Current	Active power	React. power	App. power	Power factor
Sigma	0.00	0.000	0	0	0	1.0000
1-N	0.00	0.000	0	0	0	1.0000
2-N	0.00	0.000	0	0	0	1.0000
3-N	0.00	0.000	0	0	0	1.0000
1-2	0.00					
2-3	0.00	N. current	Frequency			
3-1	0.00	0.000	0.00			

R9xWTU

	Voltage	Frequency
1-N	110.02	60.00
2-N	109.99	
3-N	110.06	
1-2	190.52	
2-3	190.59	
3-1	190.59	

Circuit	Voltage	Current	Active power	React. power	App. power	Power factor
Sigma	792.4	1448.1	1550.7	0.4803		
1-N	5.000	264.4	482.7	550.4	0.4803	
2-N	4.999	263.2	482.8	549.9	0.4787	
3-N	4.998	264.6	482.5	550.3	0.4809	
Sigma	0.00	0.0	0.0	0.0	1.0000	
1-N	0.000	0.0	0.0	0.0	1.0000	
2-N	0.000	0.0	0.0	0.0	1.0000	
3-N	0.000	0.0	0.0	0.0	1.0000	

M50XWTU, M50EXWTU

Above figure shows loop test views. By clicking Loop Test button, the current channel become loop test mode, clicking measured value enables to change to any given value. Clicking Normal enables to exit loop test mode and show measured value corresponding to the input of the device of current channel. This function is available only for all R7xWTU, M5XWTU, M5XWT, M50XWTU, M50EXWTU, and Ver. 1.40 or later of R9xWTU.

## 2.8 PRESET

For R9xWTU in the monitor view, for R7xWTU in the utility view, clicking preset button enables to preset accumulated value (energy and counter value) to any given value.

Time	Active in	Active out	Reactive LAG	Reactive LEAD
72.0	1.0000	2.0000	0.0000	0.0000
Apparent	Reactive LAG in	Reactive LEAD in	Reactive LAG out	Reactive LEAD out
0.0000	0.0000	0.0000	0.0000	0.0000

R7xWTU, M5XWTU and M5XWT

	1ch	2ch	3ch	4ch	5ch	6ch	7ch	8ch
Active in	111.1	222.2	333.3	444.4	555.5	666.6	777.7	888.8
Reactive LAG	1111.1	2222.2	3333.3	4444.4	5555.5	6666.6	7777.7	8888.8

R9xWTU

Circuit	Time	Active in	Active out	Reactive LAG	Reactive LEAD
Circuit A	79.94	3594.9990	3.9905	94.1292	0.2794
	72.0	1.0000	2.0000	0.0000	0.0000
Apparent	Reactive LAG in	Reactive LEAD in	Reactive LAG out	Reactive LEAD out	
3567.0309	93.9247	0.1992	0.1945	0.8800	
Reactive in	Reactive out	Conversion	Reactive in-out		
94.1341	0.2745	355.4900	94.4087		
Circuit C	Time	Active in	Active out	Reactive LAG	Reactive LEAD
	79.94	2.5259	1.0248	0.1536	0.1365
Apparent	Reactive LAG in	Reactive LEAD in	Reactive LAG out	Reactive LEAD out	
4.4213	0.1286	0.0995	0.0250	0.0369	
Reactive in	Reactive out	Conversion	Reactive in-out		
0.2281	0.0620	0.5000	0.2901		

M50XWTU, M50EXWTU

Above figure shows preset views. Clicking accumulated value enables to change to any given value. This function is available only for all 53U, 54U, 54UC, 54UL, L53U, R7xWTU, M5XWTU, M5XWT, M50XWTU, M50EXWTU, and Ver.1.30 or later of R9xWTU.

## 2.9 ANALOG OUTPUT LOOP TEST

For L53U and M5XWTU in the monitor view, clicking Loop Test enables to change analog output value to any given value.

The screenshot shows the PMCFG Version 1.10.39 interface. On the left, there's a 'Communicating' section with 'Utility' selected. Below it, 'Device Information' includes Tag No., Modbus password (Protection disabled), Model (L53U), Serial, and Firmware version (2.00). A 'Vector Chart' shows a circle with a blue dot at the center. The main area contains several data tables: 'Instantaneous' (Voltage, Current, Active power, React. power, App. power, Power factor), 'Demand' (Current, Current 1-3, N. current, Active power, React. power, App. power), 'High tariff (peak time) 1', 'Low tariff (off-peak time) 1', and 'Counter Energy'. A 'Harmonics' table is also present. At the bottom left, an 'Analog Output' table shows Ao1, Ao2, Ao3, and Ao4 all set to 4.00. A 'Loop Test' button is visible next to it. On the right, a 'Loop Test' dialog box is open, with 'Normal' selected and 'Close' button.

By clicking Loop Test button in the loop test views, the device status become analog fixed output mode, clicking analog output value enables to change to any given value. Clicking Normal enables to exit analog fixed output mode. This function is available only for M5XWTU and Ver.2.00 or later of L53U.

## 2.10 RESTARTING DEVICE

Clicking [Reboot] opens the dialog box for connecting with the device.

Click [Connect] with appropriate setting to restart the connected device.

This function is used to enable the settings that cannot be enabled unless the device is restarted, such as Modbus setting or CC-Link setting.

This function can be used for all devices except for 54UL, R7LWTU, and R9LWTU.

## 2.11 SWITCHING LANGUAGE

Click [Language] to switch the display language between English and Japanese.

The program starts up in English mode as initial state when the OS is other than Japanese version. You can switch to Japanese only when the OS supports Japanese language.

### 3. PARAMETER LIST

Supported parameters depend upon model types. Supported ones are marked with 'X' in the following tables.

		53U-1xx9 (Ver.2.31 or earlier) 53U-1xx9 (Ver.2.40 or later)	53U-1xx8 (Ver.2.31 or earlier) 53U-1xx8 (Ver.2.40 or later)	53U-1xx7 (Ver.2.31 or earlier) 53U-1xx7 (Ver.2.40 or later)	53U-1xx6 (Ver.2.31 or earlier) 53U-1xx6 (Ver.2.40 or later)	53U-1xx5 (Ver.2.31 or earlier) 53U-1xx5 (Ver.2.40 or later)	53U-1xx4 (Ver.2.31 or earlier) 53U-1xx4 (Ver.2.40 or later)	53U-1xx3 (Ver.2.31 or earlier) 53U-1xx3 (Ver.2.40 or later)	53U-1xx2 (Ver.2.31 or earlier) 53U-1xx2 (Ver.2.40 or later)	53U-1xx1 (Ver.2.00 to 2.31) 53U-1xx1 (Ver.2.40 or later)	53U-1xx1 (Ver.1.02 or earlier)
Basic Parameters	System	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	VT ratio primary / secondary	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	VT bar 100%	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	CT ratio primary / secondary	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	CT bar 100%	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Demand update interval, current	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Demand update interval, power	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
Alarm	Power ON delay time	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Latching	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Current alarm I1...I3	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Neutral current alarm IN	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Delta voltage alarm U12...U31	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Phase voltage alarm U1N...U3N	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Active power alarm P	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Reactive power alarm Q	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Apparent power alarm S	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Power factor alarm PF	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Frequency alarm F	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Average current alarm I1...I3	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Average neutral current alarm IN AVG	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Average active power alarm P AVG	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Average reactive power alarm Q AVG	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Average apparent power alarm S AVG	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Current THD alarm THDI1...THD13	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Neutral current THD alarm THDIN	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Delta voltage THD alarm THDU12...THDU31	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Phase voltage THD alarm THDU1N...THDU3N	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Phase angle between voltages alarm UT12...UT31		✓	✓	✓	✓	✓	✓	✓	✓	✓	
Tariff	Tariff	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Conversion value	Conversion value coefficient										
	Conversion value display unit										

\*1. -1 setting (cyclic) not selectable.

\*2. Frequency can be set to 50Hz or 60Hz fixed with the firmware version 2.40 or later.

\*3. Limit patterns are available.

\*4. Clear alarm and Tariff switching are not available.

		53U-1xx9 (Ver.2.31 or earlier) 53U-1xx9 (Ver.2.40 or later)	53U-1xx8 (Ver.2.31 or earlier) 53U-1xx8 (Ver.2.40 or later)	53U-1xx7 (Ver.2.31 or earlier) 53U-1xx7 (Ver.2.40 or later)	53U-1xx6 (Ver.2.31 or earlier) 53U-1xx6 (Ver.2.40 or later)	53U-1xx5 (Ver.2.31 or earlier) 53U-1xx5 (Ver.2.40 or later)	53U-1xx4 (Ver.2.31 or earlier) 53U-1xx4 (Ver.2.40 or later)	53U-1xx3 (Ver.2.31 or earlier) 53U-1xx3 (Ver.2.40 or later)	53U-1xx2 (Ver.2.31 or earlier) 53U-1xx2 (Ver.2.40 or later)	53U-1xx1 (Ver.2.00 to 2.31) 53U-1xx1 (Ver.2.40 or later)	53U-1xx1 (Ver.1.02 or earlier)
Display	Backlight operating mode	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Backlight OFF timer	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Backlight brightness	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Update rate		✓	✓	✓	✓	✓	✓	✓	✓	✓
	Data display view	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Energy display view	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Key operation lock	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	My default data display view	*1	✓	✓	✓	✓	✓	✓	✓	✓	✓
	My default energy display view	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	My default, use preset timer	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Auto off setting										
	Display brightness										
	Energy volume display range										
	Energy display range										
	Current display range										
	Voltage display range										
	Power factor display range										
Frequency display range											
Active display											
Other	Low-end cutout voltage	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Low-end cutout current	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Frequency input	✓	*2	*2	*2	*2	*2	*2	*2	*2	*2
	Energy tariff function	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Power factor PF sign	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Reactive power Q sign	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Phase reactive power Qn	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Apparent power S	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Measurement mode, Power factor at simplified measurement										
Extension Bar	Current bar										
	Voltage bar										
	Active power bar										
	Reactive power bar										
	Apparent power bar										
	Power factor bar										
	Frequency bar										
	Total harmonic distortion bar										
Phase angle between voltages bar											
Σ View	Σ1, Line 1...3		*3	*3	*3	*3	*3	*3	*3	*3	*3
	Σ1, Line 4										
	Σ2, Line 1...3		*3	*3	*3	*3	*3	*3	*3	*3	*3
	Σ2, Line 4										
	Σ3, Line 1...3		*3	*3	*3	*3	*3	*3	*3	*3	*3
	Σ3, Line 4										
	Σ4, Line 1...3		*3	*3	*3	*3	*3	*3	*3	*3	*3
	Σ4, Line 4										
Σ5, Line 1...4											
Σ6, Line 1...4											

\*1. -1 setting (cyclic) not selectable.

\*2. Frequency can be set to 50Hz or 60Hz fixed with the firmware version 2.40 or later.

\*3. Limit patterns are available.

\*4. Clear alarm and Tariff switching are not available.

		53U-1xx9 (Ver.2.31 or earlier)	53U-1xx9 (Ver.2.40 or later)	53U-1xx8 (Ver.2.31 or earlier)	53U-1xx8 (Ver.2.40 or later)	53U-1xx7 (Ver.2.31 or earlier)	53U-1xx7 (Ver.2.40 or later)	53U-1xx6 (Ver.2.31 or earlier)	53U-1xx6 (Ver.2.40 or later)	53U-1xx5 (Ver.2.31 or earlier)	53U-1xx5 (Ver.2.40 or later)	53U-1xx4 (Ver.2.31 or earlier)	53U-1xx4 (Ver.2.40 or later)	53U-1xx3 (Ver.2.31 or earlier)	53U-1xx3 (Ver.2.40 or later)	53U-1xx2 (Ver.2.31 or earlier)	53U-1xx2 (Ver.2.40 or later)	53U-1xx1 (Ver.2.00 to 2.31)	53U-1xx1 (Ver.2.40 or later)	53U-1xx1 (Ver.1.02 or earlier)
Expression	Input line indication	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Phase direction indication	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Power format		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
DI	Di function	*4	✓			✓	✓			✓	✓									
	Di contact type	✓	✓			✓	✓			✓	✓									
DO	Do 1 function, contact type, energy detail	✓	✓			✓	✓	✓	✓	✓	✓									
	Do 2 function, contact type, energy detail						✓	✓	✓	✓										
	Do 3 function, contact type, energy detail																		✓	✓
	Do 4 function, contact type, energy detail																			✓
AO	Ao 1 function, zero/span, linearization, I/O 0%/100%, table							✓	✓	✓	✓	✓	✓							
	Ao 2 function, zero/span, linearization, I/O 0%/100%, table							✓	✓	✓	✓	✓	✓							
	Ao 3 function, zero/span, linearization, I/O 0%/100%, table							✓	✓											
	Ao 4 function, zero/span, linearization, I/O 0%/100%, table							✓	✓											
Modbus	Device address	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Baud rate	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Parity bit	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Stop bit	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Mode																			
	RUN LED Time out																			
	Long register	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Protocol operation timer	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
CC-Link	Node address																			
	Transfer rate																			
Shortcut	Clear alarm		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓

\*1. -1 setting (cyclic) not selectable.

\*2. Frequency can be set to 50Hz or 60Hz fixed with the firmware version 2.40 or later.

\*3. Limit patterns are available.

\*4. Clear alarm and Tariff switching are not available.

	54U-1xx6A (Ver.2.00 to 2.20)	54U-1xx5/9 (Ver.2.00 to 2.20)	54U-1xx4 (Ver.2.00 to 2.20)	54U-1xx3/8 (Ver.3.00 or later)	54U-1xx2/7 (Ver.3.00 or later)	54U-1xx1 (Ver.3.00 or later)	54U-1xx3/8 (Ver.2.00 to 2.20)	54U-1xx2/7 (Ver.2.00 to 2.20)	54U-1xx1 (Ver.2.00 to 2.20)	54U-1xx3 (Ver.1.03 or earlier)	54U-1xx2 (Ver.1.03 or earlier)	54U-1xx1 (Ver.1.03 or earlier)	
Basic Parameters	System	*4	*4	*4	*4	*4	*4	*4	*4	*4	*4	*4	
	VT ratio primary / secondary	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
	VT bar 100%												
	CT ratio primary / secondary	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
	CT bar 100%												
	Demand update interval, current	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Alarm	Demand update interval, power	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
	Power ON delay time	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
	Latching	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
	Current alarm I1...I3	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
	Neutral current alarm IN						✓	✓	✓				
	Delta voltage alarm U12...U31	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
	Phase voltage alarm U1N...U3N	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
	Active power alarm P	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
	Reactive power alarm Q	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
	Apparent power alarm S	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
	Power factor alarm PF	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
	Frequency alarm F	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
	Average current alarm I1...I3	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
	Average neutral current alarm IN AVG						✓	✓	✓				
	Average active power alarm P AVG	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
	Average reactive power alarm Q AVG	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
	Average apparent power alarm S AVG	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
	Current THD alarm THDI1...THD13	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
	Neutral current THD alarm THDIN						✓	✓	✓				
	Delta voltage THD alarm THDU12...THDU31	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
	Phase voltage THD alarm THDU1N...THDU3N	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
	Phase angle between voltages alarm UT12...UT31	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
	Tariff	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
	Display	Backlight operating mode	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
		Backlight OFF timer	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
		Backlight brightness	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
		Update rate				✓	✓	✓	✓	✓	✓	✓	✓
Data display view		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
Energy display view		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
Key operation lock		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
My default data display view		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
My default energy display view		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
My default, use preset timer		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
Auto off setting													
Display brightness													
Energy volume display range													
Energy display range													
Current display range													
Voltage display range													
Power factor display range													
Frequency display range													
Active display													

\*3. Clear alarm and Tariff switching are not available.

\*4. 3-phase / 4-wire not selectable.

		54U-1xx6A (Ver.2.00 to 2.20)	54U-1xx5/9 (Ver.2.00 to 2.20)	54U-1xx4 (Ver.2.00 to 2.20)	54U-1xx3/8 (Ver.3.00 or later)	54U-1xx2/7 (Ver.3.00 or later)	54U-1xx1 (Ver.3.00 or later)	54U-1xx3/8 (Ver.2.00 to 2.20)	54U-1xx2/7 (Ver.2.00 to 2.20)	54U-1xx1 (Ver.2.00 to 2.20)	54U-1xx3 (Ver.1.03 or earlier)	54U-1xx2 (Ver.1.03 or earlier)	54U-1xx1 (Ver.1.03 or earlier)
Other	Low-end cutout voltage	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Low-end cutout current	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Frequency input	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Energy tariff function	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Power factor PF sign	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Reactive power Q sign	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Phase reactive power Qn	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Apparent power S	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Measurement mode, Power factor at simplified measurement												
Conversion value	Conversion value coefficient												
	Conversion value display unit												
Extension Bar	Current bar	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Voltage bar	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Active power bar	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Reactive power bar	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Apparent power bar	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Power factor bar	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Frequency bar	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Total harmonic distortion bar	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Phase angle between voltages bar	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Σ View	Σ1, Line 1...3	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Σ1, Line 4	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Σ2, Line 1...3	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Σ2, Line 4	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Σ3, Line 1...3	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Σ3, Line 4	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Σ4, Line 1...3	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Σ4, Line 4	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Σ5, Line 1...4	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Σ6, Line 1...4	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
Expression	Input line indication												
	Phase direction indication												
	Power format					✓	✓	✓	✓	✓	✓	✓	✓
Di	Di function	*3	*3	*3	✓	✓	✓	✓	✓	✓			
	Di contact type	✓	✓	✓	✓	✓	✓	✓	✓	✓			
Do	Do 1 function, contact type, energy detail	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Do 2 function, contact type, energy detail											✓	✓
	Do 3 function, contact type, energy detail												✓
	Do 4 function, contact type, energy detail												✓
Ao	Ao 1 function, zero/span, linearization, I/O 0%/100%, table		✓	✓		✓	✓		✓	✓		✓	✓
	Ao 2 function, zero/span, linearization, I/O 0%/100%, table		✓	✓		✓	✓		✓	✓		✓	✓
	Ao 3 function, zero/span, linearization, I/O 0%/100%, table		✓	✓		✓	✓		✓	✓		✓	✓
	Ao 4 function, zero/span, linearization, I/O 0%/100%, table		✓	✓		✓	✓		✓	✓		✓	✓

\*3. Clear alarm and Tariff switching are not available.

\*4. 3-phase / 4-wire not selectable.



		54U-1xx6/A (Ver.2.00 to 2.20)	54U-1xx5/9 (Ver.2.00 to 2.20)	54U-1xx4 (Ver.2.00 to 2.20)	54U-1xx3/8 (Ver.3.00 or later)	54U-1xx2/7 (Ver.3.00 or later)	54U-1xx1 (Ver.3.00 or later)	54U-1xx3/8 (Ver.2.00 to 2.20)	54U-1xx2/7 (Ver.2.00 to 2.20)	54U-1xx1 (Ver.2.00 to 2.20)	54U-1xx3 (Ver.1.03 or earlier)	54U-1xx2 (Ver.1.03 or earlier)	54U-1xx1 (Ver.1.03 or earlier)
Modbus	Device address		✓	✓			✓			✓	✓		
	Baud rate			✓			✓			✓			
	Parity bit			✓			✓			✓			
	Stop bit			✓			✓			✓			
	Mode												
	RUN LED Time out												
	Long register			✓			✓			✓			
	Protocol operation timer			✓			✓			✓			
CC-Link	Node address												
	Transfer rate												
Shortcut	Clear alarm			✓	✓	✓	✓	✓	✓	✓			

\*3. Clear alarm and Tariff switching are not available.

\*4. 3-phase / 4-wire not selectable.

	54U-2xx6/A	54U-2xx5/9	54U-2xx4	54U-2xx3/8	54U-2xx2/7	54U-2xx1	54U-1xx6/A (Ver.3.00 or later)	54U-1xx5/9 (Ver.3.00 or later)	54U-1xx4 (Ver.3.00 or later)
Basic Parameters	System	✓	✓	✓	✓	✓	*4	*4	*4
	VT ratio primary / secondary	✓	✓	✓	✓	✓	✓	✓	✓
	VT bar 100%								
	CT ratio primary / secondary	✓	✓	✓	✓	✓	✓	✓	✓
	CT bar 100%								
	Demand update interval, current	✓	✓	✓	✓	✓	✓	✓	✓
Alarm	Demand update interval, power	✓	✓	✓	✓	✓	✓	✓	✓
	Power ON delay time	✓	✓	✓	✓	✓	✓	✓	✓
	Latching	✓	✓	✓	✓	✓	✓	✓	✓
	Current alarm I1...I3	✓	✓	✓	✓	✓	✓	✓	✓
	Neutral current alarm IN	✓	✓	✓	✓	✓	✓	✓	✓
	Delta voltage alarm U12...U31	✓	✓	✓	✓	✓	✓	✓	✓
	Phase voltage alarm U1N...U3N	✓	✓	✓	✓	✓	✓	✓	✓
	Active power alarm P	✓	✓	✓	✓	✓	✓	✓	✓
	Reactive power alarm Q	✓	✓	✓	✓	✓	✓	✓	✓
	Apparent power alarm S	✓	✓	✓	✓	✓	✓	✓	✓
	Power factor alarm PF	✓	✓	✓	✓	✓	✓	✓	✓
	Frequency alarm F	✓	✓	✓	✓	✓	✓	✓	✓
	Average current alarm I1...I3	✓	✓	✓	✓	✓	✓	✓	✓
	Average neutral current alarm IN AVG	✓	✓	✓	✓	✓	✓	✓	✓
	Average active power alarm P AVG	✓	✓	✓	✓	✓	✓	✓	✓
	Average reactive power alarm Q AVG	✓	✓	✓	✓	✓	✓	✓	✓
	Average apparent power alarm S AVG	✓	✓	✓	✓	✓	✓	✓	✓
	Current THD alarm THDI1...THD13	✓	✓	✓	✓	✓	✓	✓	✓
	Neutral current THD alarm THDIN	✓	✓	✓	✓	✓	✓	✓	✓
	Delta voltage THD alarm THDU12...THDU31	✓	✓	✓	✓	✓	✓	✓	✓
	Phase voltage THD alarm THDU1N...THDU3N	✓	✓	✓	✓	✓	✓	✓	✓
	Phase angle between voltages alarm UT12...UT31	✓	✓	✓	✓	✓	✓	✓	✓
Tariff	✓	✓	✓	✓	✓	✓	✓	✓	
Display	Backlight operating mode	✓	✓	✓	✓	✓	✓	✓	✓
	Backlight OFF timer	✓	✓	✓	✓	✓	✓	✓	✓
	Backlight brightness	✓	✓	✓	✓	✓	✓	✓	✓
	Update rate	✓	✓	✓	✓	✓	✓	✓	✓
	Data display view	✓	✓	✓	✓	✓	✓	✓	✓
	Energy display view	✓	✓	✓	✓	✓	✓	✓	✓
	Key operation lock	✓	✓	✓	✓	✓	✓	✓	✓
	My default data display view	✓	✓	✓	✓	✓	✓	✓	✓
	My default energy display view	✓	✓	✓	✓	✓	✓	✓	✓
	My default, use preset timer	✓	✓	✓	✓	✓	✓	✓	✓
	Auto off setting								
	Display brightness								
	Energy volume display range								
	Energy display range								
	Current display range								
	Voltage display range								
	Power factor display range								
Frequency display range									
Active display									

\*4. 3-phase / 4-wire not selectable.

		54U-1xxx4 (Ver.3.00 or later)	54U-1xxx5/9 (Ver.3.00 or later)	54U-1xx6A (Ver.3.00 or later)	54U-2xx1	54U-2xx2/7	54U-2xx3/8	54U-2xx4	54U-2xx5/9	54U-2xx6A
Other	Low-end cutout voltage	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Low-end cutout current	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Frequency input	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Energy tariff function	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Power factor PF sign	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Reactive power Q sign	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Phase reactive power Qn	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Apparent power S	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Measurement mode, Power factor at simplified measurement									
Conversion value	Conversion value coefficient									
	Conversion value display unit									
Extension Bar	Current bar	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Voltage bar	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Active power bar	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Reactive power bar	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Apparent power bar	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Power factor bar	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Frequency bar	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Total harmonic distortion bar	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Phase angle between voltages bar	✓	✓	✓	✓	✓	✓	✓	✓	✓
Σ View	Σ1, Line 1...3	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Σ1, Line 4	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Σ2, Line 1...3	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Σ2, Line 4	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Σ3, Line 1...3	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Σ3, Line 4	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Σ4, Line 1...3	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Σ4, Line 4	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Σ5, Line 1...4	✓	✓	✓	✓	✓	✓	✓	✓	✓
Σ6, Line 1...4	✓	✓	✓	✓	✓	✓	✓	✓	✓	
Expression	Input line indication									
	Phase direction indication									
	Power format	✓	✓	✓	✓	✓	✓	✓	✓	✓
DI	Di function				✓	✓	✓			
	Di contact type				✓	✓	✓			
DO	Do 1 function, contact type, energy detail	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Do 2 function, contact type, energy detail	✓	✓	✓				✓	✓	✓
	Do 3 function, contact type, energy detail									
	Do 4 function, contact type, energy detail									
Ao	Ao 1 function, zero/span, linearization, I/O 0%/100%, table		✓	✓		✓	✓		✓	✓
	Ao 2 function, zero/span, linearization, I/O 0%/100%, table		✓	✓		✓	✓		✓	✓
	Ao 3 function, zero/span, linearization, I/O 0%/100%, table		✓	✓		✓	✓		✓	✓
	Ao 4 function, zero/span, linearization, I/O 0%/100%, table		✓	✓		✓	✓		✓	✓

\*4. 3-phase / 4-wire not selectable.

		54U-2xx6/A	54U-2xx5/9	54U-2xx4	54U-2xx3/8	54U-2xx2/7	54U-2xx1	54U-1xx6/A (Ver.3.00 or later)	54U-1xx5/9 (Ver.3.00 or later)	54U-1xx4 (Ver.3.00 or later)
Modbus	Device address			✓			✓			✓
	Baud rate			✓			✓			✓
	Parity bit			✓			✓			✓
	Stop bit			✓			✓			✓
	Mode									
	RUN LED time out									
	Long register			✓			✓			✓
	Protocol operation timer			✓			✓			✓
CC-Link	Node address									
	Transfer rate									
Shortcut	Clear alarm			✓	✓	✓	✓	✓	✓	✓

\*4. 3-phase / 4-wire not selectable.

	54UC-2xx2	54UC-2xx1	54UC-1xx2 (Ver.300 or later)	54UC-1xx1 (Ver.3.00 or later)	54UC-1xx2 (Ver.1.00 or earlier)	54UC-1xx1 (Ver.1.00 or earlier)	54UL-2xx2	54UL-2xx1	54UL-1xx2 (Ver.300 or later)	54UL-1xx1 (Ver.3.00 or later)	54UL-1xx2 (Ver.1.02 or earlier)	54UL-1xx1 (Ver.1.02 or earlier)
Basic Parameters	System	✓	✓	*4	*4	*4	✓	✓	*4	*4	*4	*4
	VT ratio primary / secondary	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	VT bar 100%											
	CT ratio primary / secondary	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	CT bar 100%											
	Demand update interval, current	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Alarm	Demand update interval, power	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Power ON delay time	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Latching	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Current alarm I1...I3	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Neutral current alarm IN			✓	✓	✓	✓	✓		✓	✓	✓
	Delta voltage alarm U12...U31	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Phase voltage alarm U1N...U3N	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Active power alarm P	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Reactive power alarm Q	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Apparent power alarm S	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Power factor alarm PF	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Frequency alarm F	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Average current alarm I1...I3	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Average neutral current alarm IN AVG			✓	✓	✓	✓	✓		✓	✓	✓
	Average active power alarm P AVG	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Average reactive power alarm Q AVG	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Average apparent power alarm S AVG	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Current THD alarm THDI1...THD13	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Neutral current THD alarm THDIN			✓	✓	✓	✓	✓		✓	✓	✓
	Delta voltage THD alarm THDU12...THDU31	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Phase voltage THD alarm THDU1N...THDU3N	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Phase angle between voltages alarm UT12...UT31	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Tariff	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Display	Backlight operating mode	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
		Backlight OFF timer	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
		Backlight brightness	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
		Update rate	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Data display view		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
Energy display view		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
Key operation lock		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
My default data display view		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
My default energy display view		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
My default, use preset timer		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
Auto off setting												
Display brightness												
Energy volume display range												
Energy display range												
Current display range												
Voltage display range												
Power factor display range												
Frequency display range												
Active display												

\*4. 3-phase / 4-wire not selectable.

		54UC-2xx2	54UC-2xx1	54UC-1xx2 (Ver.300 or later)	54UC-1xx1 (Ver.3.00 or later)	54UC-1xx2 (Ver.1.00 or earlier)	54UC-1xx1 (Ver.1.00 or earlier)	54UL-2xx2	54UL-2xx1	54UL-1xx2 (Ver.300 or later)	54UL-1xx1 (Ver.3.00 or later)	54UL-1xx2 (Ver.1.02 or earlier)	54UL-1xx1 (Ver.1.02 or earlier)
Other	Low-end cutout voltage	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Low-end cutout current	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Frequency input	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Energy tariff function	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Power factor PF sign	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Reactive power Q sign	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Phase reactive power Qn	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Apparent power S	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Measurement mode, Power factor at simplified measurement												
Conversion value	Conversion value coefficient												
	Conversion value display unit												
Extension Bar	Current bar	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Voltage bar	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Active power bar	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Reactive power bar	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Apparent power bar	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Power factor bar	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Frequency bar	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Total harmonic distortion bar	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Phase angle between voltages bar	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Σ View	Σ1, Line 1...3	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Σ1, Line 4	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Σ2, Line 1...3	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Σ2, Line 4	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Σ3, Line 1...3	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Σ3, Line 4	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Σ4, Line 1...3	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Σ4, Line 4	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Σ5, Line 1...4	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Σ6, Line 1...4	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
Expression	Input line indication												
	Phase direction indication												
	Power format	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Di	Di function	✓		✓		✓		✓		✓		✓	
	Di contact type	✓		✓		✓		✓		✓		✓	
Do	Do 1 function, contact type, energy detail	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Do 2 function, contact type, energy detail		✓		✓		✓		✓		✓		✓
	Do 3 function, contact type, energy detail												
	Do 4 function, contact type, energy detail												
Ao	Ao 1 function, zero/span, linearization, I/O 0%/100%, table												
	Ao 2 function, zero/span, linearization, I/O 0%/100%, table												
	Ao 3 function, zero/span, linearization, I/O 0%/100%, table												
	Ao 4 function, zero/span, linearization, I/O 0%/100%, table												

\*4. 3-phase / 4-wire not selectable.

		54UC-2xx2	54UC-2xx1	54UC-1xx2 (Ver.300 or later)	54UC-1xx1 (Ver.3.00 or later)	54UC-1xx2 (Ver.1.00 or earlier)	54UC-1xx1 (Ver.1.00 or earlier)	54UL-2xx2	54UL-2xx1	54UL-1xx2 (Ver.300 or later)	54UL-1xx1 (Ver.3.00 or later)	54UL-1xx2 (Ver.1.02 or earlier)	54UL-1xx1 (Ver.1.02 or earlier)
Modbus	Device address												
	Baud rate												
	Parity bit												
	Stop bit												
	Mode												
	RUN LED time out												
	Long register												
	Protocol operation timer												
CC-Link	Node address	✓	✓	✓	✓	✓	✓						
	Transfer rate	✓	✓	✓	✓	✓	✓						
Shortcut	Clear alarm	✓		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓

\*4. 3-phase / 4-wire not selectable.

		R7LWTU	R7CWTU	R7MWTU	R7EWTU	R9LWTU	R9CWTU	R9MWTU	R9EWTU
Basic Parameters	System		✓	✓	✓		✓	✓	✓
	VT ratio primary / secondary		✓	✓	✓		✓	✓	✓
	VT bar 100%								
	CT ratio primary / secondary		✓	✓	✓		✓	✓	✓
	CT bar 100%								
	Demand update interval, current		✓	✓	✓		✓	✓	✓
	Demand update interval, power		✓	✓	✓		✓	✓	✓
Alarm	Power ON delay time								
	Latching								
	Current alarm I1...I3								
	Neutral current alarm IN								
	Delta voltage alarm U12...U31								
	Phase voltage alarm U1N...U3N								
	Active power alarm P								
	Reactive power alarm Q								
	Apparent power alarm S								
	Power factor alarm PF								
	Frequency alarm F								
	Average current alarm I1...I3								
	Average neutral current alarm IN AVG								
	Average active power alarm P AVG								
	Average reactive power alarm Q AVG								
	Average apparent power alarm S AVG								
	Current THD alarm THDI1...THD13								
	Neutral current THD alarm THDIN								
	Delta voltage THD alarm THDU12...THDU31								
	Phase voltage THD alarm THDU1N...THDU3N								
Phase angle between voltages alarm UT12...UT31									
Tariff	Tariff		✓	✓	✓				
Display	Backlight operating mode								
	Backlight OFF timer								
	Backlight brightness								
	Backlight update rate								
	Data display view								
	Energy display view								
	Key operation lock								
	My default data display view								
	My default energy display view								
	My default, use preset timer								
	Auto off setting								
	Display brightness								
	Energy volume display range								
	Energy display range								
	Current display range								
	Voltage display range								
	Power factor display range								
Frequency display range									
Active display									

Configure the R7LWTU and R9LWTU with LonWORKS Management Tool (e.g LonMaker)



		R7LWTU	R7CWTU	R7MWTU	R7EWTU	R9LWTU	R9CWTU	R9MWTU	R9EWTU
Other	Low-end cutout voltage		✓	✓	✓		✓	✓	✓
	Low-end cutout current		✓	✓	✓		✓	✓	✓
	Frequency input		✓	✓	✓				
	Energy tariff function								
	Power factor PF sign		✓	✓	✓		✓	✓	✓
	Reactive power Q sign		✓	✓	✓		✓	✓	✓
	Phase reactive power Qn		✓	✓	✓		✓	✓	✓
	Apparent power S		✓	✓	✓		✓	✓	✓
	Measurement mode, Power factor at simplified measurement								
Conversion value	Conversion value coefficient								
	Conversion value display unit								
Extension Bar	Current bar								
	Voltage bar								
	Active power bar								
	Reactive power bar								
	Apparent power bar								
	Power factor bar								
	Frequency bar								
	Total harmonic distortion bar								
	Phase angle between voltages bar								
Σ View	Σ1, Line 1...3								
	Σ1, Line 4								
	Σ2, Line 1...3								
	Σ2, Line 4								
	Σ3, Line 1...3								
	Σ3, Line 4								
	Σ4, Line 1...3								
	Σ4, Line 4								
	Σ5, Line 1...4								
Σ6, Line 1...4									
Expression	Input line indication								
	Phase direction indication								
	Power format								
Di	Di function								
	Di contact type								
Do	Do 1 function, contact type, energy detail								
	Do 2 function, contact type, energy detail								
	Do 3 function, contact type, energy detail								
	Do 4 function, contact type, energy detail								
Ao	Ao 1 function, zero/span, linearization, I/O 0%/100%, table								
	Ao 2 function, zero/span, linearization, I/O 0%/100%, table								
	Ao 3 function, zero/span, linearization, I/O 0%/100%, table								
	Ao 4 function, zero/span, linearization, I/O 0%/100%, table								

Configure the R7LWTU and R9LWTU with LonWORKS Management Tool (e.g LonMaker)

		R7LWTU	R7CWTU	R7MWTU	R7EWTU	R9LWTU	R9CWTU	R9MWTU	R9EWTU
Modbus	Device address								
	Baud rate								
	Parity bit			✓				✓	
	Stop bit			✓				✓	
	Mode			✓				✓	
	IP address				✓				✓
	Subnet mask				✓				✓
	Default gateway				✓				✓
	Port				✓				✓
	Connection timeout				✓				✓
	RUN LED time out			✓	✓			✓	✓
	Long register								
	Protocol operation timer								
	CC-Link	Node address							
Transfer rate									
Shortcut	Clear alarm								

Configure the R7LWTU and R9LWTU with LonWORKS Management Tool (e.g LonMaker)

		L53U-1xx1	L53U-1xx2	L53U-1xx3	L53U-1xx4	L53U-1xx5	L53U-1xx6	L53U-1xx7	M5XWTLU-1x1	M5XWTLU-1x2	M5XWTLU-1x3	M5XWTLU-1x3	M50XWTLU-2x3	M50EXWTLU-2x3
Basic Parameters	System	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	VT ratio primary / secondary	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	VT bar 100%													
	CT ratio primary / secondary	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	CT bar 100%													
	Demand update interval, current	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
Demand update interval, power	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓		
Alarm	Power ON delay time	✓	✓	✓	✓	✓	✓	✓		✓				
	Latching	✓	✓	✓	✓	✓	✓	✓		✓				
	Current alarm I1...I3	✓	✓	✓	✓	✓	✓	✓		✓				
	Neutral current alarm IN	✓	✓	✓	✓	✓	✓	✓		✓				
	Delta voltage alarm U12...U31	✓	✓	✓	✓	✓	✓	✓		✓				
	Phase voltage alarm U1N...U3N	✓	✓	✓	✓	✓	✓	✓		✓				
	Active power alarm P	✓	✓	✓	✓	✓	✓	✓		✓				
	Reactive power alarm Q	✓	✓	✓	✓	✓	✓	✓		✓				
	Apparent power alarm S	✓	✓	✓	✓	✓	✓	✓		✓				
	Power factor alarm PF	✓	✓	✓	✓	✓	✓	✓		✓				
	Frequency alarm F	✓	✓	✓	✓	✓	✓	✓		✓				
	Average current alarm I1...I3	✓	✓	✓	✓	✓	✓	✓		✓				
	Average neutral current alarm IN AVG	✓	✓	✓	✓	✓	✓	✓		✓				
	Average active power alarm P AVG	✓	✓	✓	✓	✓	✓	✓		✓				
	Average reactive power alarm Q AVG	✓	✓	✓	✓	✓	✓	✓		✓				
	Average apparent power alarm S AVG	✓	✓	✓	✓	✓	✓	✓		✓				
	Current THD alarm THDI1...THD13	✓	✓	✓	✓	✓	✓	✓		✓				
	Neutral current THD alarm THDIN	✓	✓	✓	✓	✓	✓	✓		✓				
	Delta voltage THD alarm THDU12...THDU31	✓	✓	✓	✓	✓	✓	✓		✓				
	Phase voltage THD alarm THDU1N...THDU3N	✓	✓	✓	✓	✓	✓	✓		✓				
Phase angle between voltages alarm UT12...UT31	✓	✓	✓	✓	✓	✓	✓							
Tariff	Tariff	✓	✓	✓	✓	✓	✓	✓						
Display	Backlight operating mode													
	Backlight OFF timer													
	Backlight brightness													
	Backlight update rate													
	Data display view													
	Energy display view													
	Key operation lock													
	My default data display view													
	My default energy display view													
	My default, use preset timer													
	Auto off setting													✓
	Display brightness													✓
	Energy volume display range													✓
	Energy display range													✓
	Current display range													✓
	Voltage display range													✓
	Power factor display range													✓
Frequency display range													✓	
Active display													✓	

		L53U-1xx1	L53U-1xx2	L53U-1xx3	L53U-1xx4	L53U-1xx5	L53U-1xx6	L53U-1xx7	M5XWTTU-1x1	M5XWTTU-1x2	M5XWTTU-1x3	M5XWT-1x3	M50XWTTU-2x3	M50EXWTTU-2x3
Other	Low-end cutout voltage	✓	✓	✓	✓	✓	✓	✓					✓	
	Low-end cutout current	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Frequency input	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Energy tariff function	✓	✓	✓	✓	✓	✓	✓						
	Power factor PF sign	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Reactive power Q sign	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Phase reactive power Qn	✓	✓	✓	✓	✓	✓	✓						✓
	Apparent power S	✓	✓	✓	✓	✓	✓	✓						✓
	Measurement mode, Power factor at simplified measurement									✓	✓	✓	✓	✓
Conversion value	Conversion value coefficient												✓	✓
	Conversion value display unit													✓
Extension Bar	Current bar													
	Voltage bar													
	Active power bar													
	Reactive power bar													
	Apparent power bar													
	Power factor bar													
	Frequency bar													
	Total harmonic distortion bar													
Σ View	Phase angle between voltages bar													
	Σ1, Line 1...3													
	Σ1, Line 4													
	Σ2, Line 1...3													
	Σ2, Line 4													
	Σ3, Line 1...3													
	Σ3, Line 4													
	Σ4, Line 1...3													
Σ4, Line 4														
Expression	Σ5, Line 1..4													
	Σ6, Line 1..4													
	Input line indication													
DI	Phase direction indication													
	Power format													
Do	Di function	✓			✓	✓								
	Di contact type	✓			✓	✓								
	Do 1 function, contact type, energy detail	✓			✓	✓	✓	✓		✓			✓	✓
	Do 2 function, contact type, energy detail						✓	✓					✓	✓
Ao	Do 3 function, contact type, energy detail													
	Do 4 function, contact type, energy detail													
	Ao 1 function, zero/span, linearization, I/O 0%/100%, table		✓	✓	✓	✓	✓	✓	✓					
	Ao 2 function, zero/span, linearization, I/O 0%/100%, table		✓	✓	✓	✓	✓	✓						
Ao	Ao 3 function, zero/span, linearization, I/O 0%/100%, table		✓	✓										
	Ao 4 function, zero/span, linearization, I/O 0%/100%, table		✓	✓										

		M50EXWTU-2x3	M50XWTU-2x3	M5XWT-1x3	M5XWTU-1x3	M5XWTU-1x2	M5XWTU-1x1	L53U-1xx7	L53U-1xx6	L53U-1xx5	L53U-1xx4	L53U-1xx3	L53U-1xx2	L53U-1xx1
Modbus	Device address	✓	✓	✓	✓			✓	✓	✓	✓	✓	✓	✓
	Baud rate	✓	✓	✓	✓			✓	✓	✓	✓	✓	✓	✓
	Parity bit	✓	✓	✓	✓			✓	✓	✓	✓	✓	✓	✓
	Stop bit	✓	✓	✓	✓			✓	✓	✓	✓	✓	✓	✓
	Mode													
	RUN LED time out													
	Long register		✓	✓	✓			✓	✓	✓	✓	✓	✓	✓
	Protocol operation timer		✓	✓	✓			✓	✓	✓	✓	✓	✓	✓
CC-Link	Node address													
	Transfer rate													
Shortcut	Clear alarm													

## 4. BASIC PARAMETERS

The initial window when you start up the PMCFG contains basic parameters as described below.

### 4.1 MODEL

Choose an appropriate device type to be configured on the PMCFG.

Selection

53U-	1xx1	Modbus, Do x1, Di x1	Ver.1.02 or earlier
			Ver.2.00 to 2.31
			Ver.2.40 or later
	1xx2	Ao 4-20mA x4	Ver.2.31 or earlier
			Ver.2.40 or later
	1xx3	Ao 1-5V x4	Ver.2.31 or earlier
			Ver.2.40 or later
	1xx4	Ao 4-20mA x2, Do x1, Di x1	Ver.2.31 or earlier
			Ver.2.40 or later
1xx5	Ao 1-5V x2, Do x1, Di x1	Ver.2.31 or earlier	
		Ver.2.40 or later	
1xx6	Ao 4-20mA x2, Do x2	Ver.2.31 or earlier	
		Ver.2.40 or later	
1xx7	Do 1-5V x2, Do x2	Ver.2.31 or earlier	
		Ver.2.40 or later	
1xx8	Modbus, Do x3	Ver.2.31 or earlier	
		Ver.2.40 or later	
1xx9	Do x4	Ver.2.31 or earlier	
		Ver.2.40 or later	
54U-	1xx1	Modbus, Do x1, Di x1	Ver.1.03 or earlier
			Ver.2.00 to 2.20
			Ver.3.00 or later
	1xx2/7	Ao 4-20mA x4, Do1 x1, Di x1	Ver.1.03 or earlier
			Ver.2.00 to 2.20
			Ver.3.00 or later
	1xx3/8	Ao 1-5V x4, Do x1, Di x1	Ver.1.03 or earlier
			Ver.2.00 to 2.20
			Ver.3.00 or later
	1xx4	Modbus, Do x2	Ver.2.00 to 2.20
			Ver.3.00 or later
	1xx5/9	Ao 4-20mA x4, Do x2	Ver.2.00 to 2.20
			Ver.3.00 or later
	1xx6/A	Ao 1-5V x4, Do x2	Ver.2.00 to 2.20
			Ver.3.00 or later
2xx1	3P4W, Modbus, Do x1, Di x1		
2xx2/7	3P4W, Ao 4-20mA x4, Do x1, Di x1		
2xx3/8	3P4W, Ao 1-5V x4, Do x1, Di x1		
2xx4	3P4W, Modbus, Do x2		
2xx5/9	3P4W, Ao 4-20mA x4, Do x2		
2xx6/A	3P4W, Ao 1-5V x4, Do x2		

54UL-	1xx1	LONWORKS, Do x1, Di x1	Ver.1.02 or earlier Ver.3.00 or later
	1xx2	LONWORKS, Do x2	Ver.1.02 or earlier Ver.3.00 or later
	2xx1	3P4W, LONWORKS, Do x1, Di x1	
	2xx2	3P4W, LONWORKS, Do x2	
54UC-	1xx1	CC-Link, Do x1, Di x1	Ver.1.00 or earlier Ver.3.00 or later
	1xx2	CC-Link, Do x2	Ver.1.00 or earlier Ver.3.00 or later
	2xx1	3P4W, CC-Link, Do x1, Di x1	
	2xx2	3P4W, CC-Link, Do x2	
R7CWTU-	21x	3P4W, CC-Link, Counter x4	
	22x	3P4W, CC-Link, Input x2	
R7MWTU-	21x	3P4W, Modbus, Counter x4	
	22x	3P4W, Modbus, Input x2	
R7EWTU-	21x	3P4W, Modbus-TCP, Counter x4	
	22x	3P4W, Modbus-TCP, Input x2	
L53U-	1xx1	Modbus, Do x1, Di x1	
	1xx2	Ao 4 – 20mA x4	
	1xx3	Ao 1 – 5V x4	
	1xx4	Ao 4 – 20mA x2, Do x1, Di x1	
	1xx5	Ao 1 – 5V x2, Do x1, Di x1	
	1xx6	Ao 4 – 20mA x2, Do x2	
	1xx7	Ao 1 – 5V x2, Do x2	
R9CWTU-	2xxx	CC-Link, Input x8	
	2xxx	CC-Link, Input x8 + R9WTU-EP8 (Input x8)	
R9MWTU-	2xxx	Modbus, Input x8	
	2xxx	Modbus, Input x8 + R9WTU-EP8 (Input x8)	
R9EWTU-	2xxx	Modbus-TCP, Input x8	
	2xxx	Modbus-TCP, Input x8 + R9WTU-EP8 (Input x8)	
M5XWTU-	1x1	Ao x1	
	1x2	Do x1	
	1x3	Modbus	
M5XWT-	1x3	Modbus	
M50XWTU-	2x3	Modbus Do x2	
M50EXWTU-	2x3	Modbus Do x2	

Note: For models with 'External interface' code 2 or 7, select the same device type. Do the same for models with code 3 or 8, 5 or 9, and 6 or A.

## 4.2 INPUT

### SYSTEM

Choose an input wiring configuration from the following:

Selection / Range	
System	Single-phase / 2-wire (1CT) Single-phase / 3-wire (2CT) 3-phase / 3-wire, balanced load (1CT) *3 3-phase / 3-wire, unbalanced load (2CT) 3-phase / 4-wire, balanced load (1CT) *1 3-phase / 4-wire, unbalanced load (3CT) *1 3-phase / 3-wire, unbalanced load (3CT) *2

\*1. Selectable for the 53U, L53U, 54U-2, 54UL-2, 54UC-2, R7CW TU, R7MWTU and R7EWTU.

\*2. Selectable for the 54U-2, 54UL-2 and 54UC-2

\*3. The M5XWTU and M5XWT are not selectable.

For M50XWTU and M50EXWTU, choose an input wiring configuration from the following:

SELECTION	CIRCUIT A	CIRCUIT B	CIRCUIT C	CIRCUIT D
Single-phase/2-wire (1CT)	Single-phase/2-wire	Single-phase/2-wire	Single-phase/2-wire	Single-phase/2-wire
Single-phase/3-wire (2CT)	Single-phase/3-wire	–	Single-phase/3-wire	–
3-phase / 3-wire, unbalanced load (2CT)	Three-phase/3-wire	–	Three-phase/3-wire	–
3-phase / 4-wire, unbalanced load (3CT)	Three-phase/4-wire	–	–	–
Single-phase/2-wire branched from single-phase/3-wire	Single-phase/2-wire	Single-phase/2-wire	Single-phase/2-wire	Single-phase/2-wire
Single-phase/3-wire + Single-phase/2-wire	Single-phase/3-wire	–	Single-phase/2-wire	Single-phase/2-wire

The M50XWTU and M50EXWTU share the same voltage, but it can measure up to four circuits, and this setting allows individual load measurement by circuits A through D as shown in the table above.

### VOLTAGE

Enter VT's primary and secondary and secondary ratings when an external voltage transformer (VT) is used. The maximum selectable ratio is 400kV/50V, but both CT and VT ratios must be considered to satisfy the maximum measurable power value of 2GVA.

The secondary can be set up to 500V. However, this does not mean the unit accepts 500V for input. Do not use with the condition exceeding input rating written in the specification sheet of the unit.

'Bar 100%' value is applied as the full-scale bargraph range indicated on the left end of the LCD display and the full-scale vector chart range indicated on the monitor view. The 54U, 54UL and 54UC do not support this function. Use 'Bar Setting.'

Selection / Range	
Primary voltage	50 to 400000V
Secondary voltage	50 to 500V
Bar 100% voltage	50 to 400000V

### CURRENT

Enter CT's primary and secondary and secondary ratings when an external current transformer (CT) is used. The maximum selectable ratio is 20kA/1A, but both CT and VT ratios must be considered to satisfy the maximum measurable power value of 2GVA.

'Bar 100%' value is applied as the full-scale bargraph range indicated on the left end of the LCD display and the full-scale vector chart range indicated on the monitor view. The 54U, 54UL and 54UC do not support this function. Use 'Bar Setting.'

Selection / Range	
Primary current	1 to 20000A
Secondary current	1 to 5A
Bar 100% current	1 to 20000A



The sensors used for CT current input are the followings:

CLSE-R5  
CLSE-05  
CLSE-10  
CLSE-20  
CLSE-40  
CLSE-60

Primary current setting is necessary when choosing CLSE-R5. Set the CLSE-R5 to "5" at connection on the available measurements line, for other items, set primary current of the CT connected to CLSE-R5.

Select same current sensor for circuit A and B, and circuit C and D for the M50XWTU and M50EXWTU.

#### MEASUREMENT POSITION

For the M50XWTU and M50EXWTU, when selecting single-phase/2-wire branched from single-phase/3-wire, or single-phase/3-wire + single-phase/2-wire, the position of the load to be measured on the single-phase/2-wire can be selected from the following table.

1-N
3-N
1-3

## 5. FUNCTION PARAMETERS

When you click various control buttons under 'Function' on the initial window of the PMCFG, you can go to detailed setting.

### 5.1 DEMAND UPDATE INTERVAL

#### CURRENT & POWER

Choose how you want to update demand (average) values for the current and the power signals.

Selection / Range

Internal timer	Demand values are calculated automatically by the internal timer (clock). Specify in minutes.
Discrete input	Demand values are calculated when a contact input is supplied to the device's discrete input terminals.

---

---


#### Caution !

With 'Discrete input' setting, demand values are automatically updated if there is no contact input for 100 minutes. Be sure to set also 'Update demand value' for 'Discrete input function' as explained in Section 3.3.

---

## 5.2 ALARM

19 groups of measurands are available for alarm. Each alarm can have High and Low setpoints, enabled or disabled respectively.



### ■ ALARM OUTPUT SETTING

ID	DEFINITION	LOW SETPOINT	HIGH SETPOINT	UNIT	DEVICE*1
I1-3	Current, Line 1 thr. Line 3	0.000	20 000.000	A	
IN	Neutral current	0.000	20 000.000	A	53U, L53U, 54U, 54UL, 54UC*5, M5XWTU
U12-31	Delta voltage, Line 1 – 2, 2 – 3, 3 – 1	0.00	400 000.00	V	
U1N-3N	Phase voltage, Phase 1 thr. Phase 3	0.00	400 000.00	V	
P	Active power	-2 000 000 000	2 000 000 000	W	
Q	Reactive power	-2 000 000 000	2 000 000 000	var	
S	Apparent power	0	2 000 000 000	VA	
PF	Power factor	-1.0000	1.0000	cos $\phi$ *2	
F	Frequency	45.00	65.00	Hz	
I1-3 AVG	Average current, Line 1 thr. Line 3 (demand)	0.000	20 000.000	A	
IN AVG	Average neutral current (demand)	0.000	20 000.000	A	53U, L53U, 54U, 54UL, 54UC*5, M5XWTU
P AVG	Average active power (demand)	-2 000 000 000	2 000 000 000	W	
Q AVG	Average reactive power (demand)	-2 000 000 000	2 000 000 000	var	
S AVG	Average apparent power (demand)	0	2 000 000 000	VA	
THDI1-3	THD, Current, Line 1 thr. Line 3	0.0	999.9	%	
THDIN	THD, Neutral current	0.0	999.9	%	53U, L53U, 54U, 54UL, 54UC*5, M5XWTU
THDU12-31	THD, Delta voltage, Line 1 – 2, 2 – 3, 3 – 1	0.0	999.9	%	
THDU1N-3N	THD, Phase voltage, Phase 1 thr. Phase 3	0.0	999.9	%	
UT12-31	Phase angle between voltages, Phase 1 – 2, 2 – 3, 3 – 1	-180	180	$^{\circ}$ *4	53U*3, L53U, 54U, 54UL, 54UC

\*1. Function available for specific models.

\*2. Indicated PF on the 53U

\*3. Firmware Ver.2.00 or later

\*4. No unit indication on the module

\*5. Only for the models to which 3-phase/4-wire is applicable, or 54U, 54UL and 54UC whose firmware version is 3.00 or later.

### POWER ON DELAY TIME

Specify a time delay for the alarm to start functioning after the power is turned on. The time is counted up from the moment when the device starts measuring in approx. 2 seconds after all display segments are turned on at the startup.

Selection / Range

Power ON delay time      0 to 999 seconds

## LATCHING

Check 'Latching' if you do not want to automatically reset an alarm once the measured value is out of the alarm range. In order to reset, (1) reset through network by Modbus command, (2) Remove the 'Check' mark of this setting, or (3) turn off the power supply to the device.

## HIGH SETPOINT / LOW SETPOINT

Refer to the above table for the selectable ranges for respective measurand. High alarm is triggered when the measured value goes above the High setpoint, while Low alarm is triggered when it goes below the Low setpoint.

## HYSTERESIS (DEADBAND)

Hysteresis is selectable for each alarm from 0.0 to 99.9%. Relationships between the set value in % and actual process value are indicated in the table below. 0% hysteresis equals to 0 in engineering unit unless otherwise mentioned.

ID	DEFINITION	HYSTERESIS AT 100%	UNIT
I1-3	Current, Line 1 thr. Line 3	CT primary rating	A
IN	Neutral current	CT primary rating	A
U12-31	Delta voltage, Line 1 – 2, 2 – 3, 3 – 1	VT primary rating	V
U1N-3N	Phase voltage, Phase 1 thr. Phase 3	VT primary rating	V
P	Active power	CT primary rating x VT primary rating	W
Q	Reactive power	CT primary rating x VT primary rating	var
S	Apparent power	CT primary rating x VT primary rating	VA
PF	Power factor	1.0000	cos $\phi$
F	Frequency	65.00 (45.00 at 0%)	Hz
I1-3 AVG	Average current, Line 1 thr. Line 3 (demand)	CT primary rating	A
IN AVG	Average neutral current (demand)	CT primary rating	A
P AVG	Average active power (demand)	CT primary rating x VT primary rating	W
Q AVG	Average reactive power (demand)	CT primary rating x VT primary rating	var
S AVG	Average apparent power (demand)	CT primary rating x VT primary rating	VA
THDI1-3	THD, Current, Line 1 thr. Line 3	100.0	%
THDIN	THD, Neutral current	100.0	%
THDU12-31	THD, Delta voltage, Line 1 – 2, 2 – 3, 3 – 1	100.0	%
THDU1N-3N	THD, Phase voltage, Phase 1 thr. Phase 3	100.0	%
UT12-31	Phase angle between voltages, Phase 1 – 2, 2 – 3, 3 – 1	360	°

## ON DELAY

Specify a time delay for the alarm to be triggered after the measured value is out of the normal range.

Selection / Range

ON delay time	0 to 999 seconds
---------------	------------------

## OUTPUT

Specify where you want to output each alarm.

### [ Except L53U and M5XWTU ]

Selection	
Disable	No alarm output is provided.
Display	ALARM indicator is activated but no discrete signal output is provided.
Display + Do 1...Do 4	ALARM indicator is activated plus a discrete signal output is provided.

### [ L53U ]

Selection	
Disable	No alarm output is provided.
Communication	ALARM is activated only via communication but no discrete signal output is provided.
Communication + Do 1...Do 2	ALARM is activated via communication plus a discrete signal output is provided.

### [ M5XWTU ]


Selection	
Disable	No alarm output is provided.
Do1	Alarm output is provided to Do1.

#### Caution !

With 'Display + Do x' 'Communication + Do x' setting, be sure to set also 'Alarm status' for 'Discrete output function' as explained in Section 3.4. Otherwise no contact output is actually provided.

## 5.3 TARIFF


Choose one of the two energy counters. This setting is valid only when 'Tariff function' under 'Other' setting (See Section 5.5) is set to 'Enable.' When that is set to 'Disable,' this setting is invalid, and then the High tariff (peak time) counter is always used.



Selection	
Tariff	High tariff (peak time) Low tariff (off-peak time)

## 5.4 PASSCODE

4-digit passcode is needed to enter the programming mode when you use the front keys. Type in 4-digit number once and twice for confirmation and click OK.



Selection / Range	
Passcode	0000 to 9999

## 5.5 OTHER SETTINGS

### 5.5.1 INPUT

#### LOW-END CUTOFF (VOLTAGE & CURRENT)

Specify voltage/current low-end cutoff values in %. Actual cutoff voltage/current are calculated from the CT/VT's primary rating by the following equations:

Low-end cutoff current = Setting in % x CT's primary rating

Low-end cutoff voltage = Setting in % x VT's primary rating

When the input signal goes below the calculated values, '0' is supplied as the input, discarding the actual input signal. For the voltage, the setting is applied to Phase voltage (line-to-neutral) except for 3-phase/3-wire system, to Delta voltage (line-to-line).

#### FREQUENCY INPUT

Specify either voltage or current to monitor AC frequency.

As 50Hz fixed and 60Hz fixed are used for special purpose, do not use under normal conditions.

Selection	
I1	I1 current <sup>*2</sup>
U1N	U1 voltage
50Hz fixed	AC frequency is fixed to 50Hz. <sup>*1</sup>
60Hz fixed	AC frequency is fixed to 60Hz. <sup>*1</sup>

<sup>\*1</sup>. Selectable with M5XWTU, M5XWT, M50XWTU, and firmware version 2.40 or later of 53U.

<sup>\*2</sup>. M5XWTU, M5XWT, M50XWTU, and M50EXWTU are not selectable.

### 5.5.2 ENERGY

#### ENABLE / DISABLE TARIFF FUNCTION

Specify to enable or disable the tariff switching function. When enabled, two energy counters are switcheable at any specific timing.

This setting is not available for R7CWTU, R7MWTU and R7EWTU. Tariff function is enabled.

Selection	
Tariff function	Disable Enable

### 5.5.3 CALCULATION METHOD

#### POWER FACTOR PF SIGN

Selection	
Standard (IEC)	Positive in incoming active power, Negative in outgoing active power.
IEEE	Positive in LAG (inductive), Negative in LEAD (capacitive)

#### REACTIVE POWER Q SIGN

Selection	
Standard (IEC)	Positive from [PF = 1.0] to 180° in LAG direction; Negative for the other direction.
Inverted when outgoing (Special)	Identical to IEC method in incoming power; Positive-negative inverted in outgoing power.

#### PHASE REACTIVE POWER Qn

Selection	
	Calculate using vector method.
Standard (Vector S-P)	$Q_n = \sqrt{S_n^2 - P_n^2}$ $S_n = I_n \cdot U_n^{*1}$
Calculate using reactive power method.	
Reactive power method (Sigma UI)	$Q_n = \frac{1}{N_{smp}} \sum_{i=1}^{N_{smp}} (U_{n_i} - U_N) I_{n_{i+(N_{smp}/4)}}$ $S_n = \sqrt{P_n^2 + Q_n^2}^{*1}$

\*1. Accordingly in M50XWTU and M50EXWTU, the calculation method of each phase apparent power switches.

#### APPARENT POWER S

Selection	
Standard (Vector P+Q)	$S = \sqrt{P^2 + Q^2}$
Sum (S1+S2+S3)	$S = S1 + S2 + S3$

#### MEASUREMENT MODE, POWER FACTOR AT SIMPLIFIED MEASUREMENT

Selection	
Standard measurement	Performs standard measurement
Simplified measurement	$S = S1 + S2 + S3$
Selection	
Standard measurement	Performs standard measurement
Simplified measurement	Only DC current sensor measuring, calculates active power and active energy

When simplified measurement mode is selected, power factor at simplified measurement is selectable from 0.0000 to 1.0000.

When simplified measurement mode is selected, calculates active power based on power factor at simplified measurement.

When simplified measurement mode is selected, voltage is not measured but is calculated assuming the value set by the VT's primary rating.

## 5.6 CONVERSION VALUE

	Conv Value Coef
Circuit A	0.555
Circuit B	
Circuit C	0.555
Circuit D	

M50XWTU

	Conv value coef	Conv value unit
Circuit A	0.555	kG
Circuit B	0.555	kG
Circuit C	0.555	kG
Circuit D	0.555	kG

M50EXWTU

### 5.6.1 CONVERSION VALUE COEFFICIENT

This function calculates the conversion value by multiplying the active energy by the conversion value coefficient. The conversion value coefficient can be set in the range of 0.000 - 99.999 for each circuit. This function is enabled for M50XWTU only .

### 5.6.2 CONVERSION VALUE DISPLAY UNIT

The display unit of conversion value can be set.

Usable letter is (space), k(kilogram/small letter), number 0 to 9, capital letter A to Z, /(slash), -(minus), +(plus), ° (superscript circle), ° (subscript circle). 4 letters can be set at maximum.

Space or k(kilogram/small letter) needs to be set to either 1st, 2nd, or 3rd letter except for the last letter.

k(kilogram/small letter) can be set only for 1 letter.

Empty string cannot be set.


k(kilogram/small letter) cannot be set either for all letters or for the last letter.




## 6. OPTION PARAMETERS

When you click various control buttons under 'Option' on the initial window of the PMCFG, you can go to detailed setting.

### 6.1 DISPLAY



53U, 54U, 54UC, 54UL



M50EXWTU

#### 6.1.1 LCD BACKLIGHT

##### OPERATION MODE

Specify when you want to maintain the backlight continuously on or not.

###### Selection

Auto	Backlight turns on when keys are touched, when an alarm is triggered, or in a system error status. After the device is operated, it automatically turns off after 'Off timer' time has been elapsed.
On	Continuously on.
Off	Continuously off except when an alarm is triggered or in a system error status.

##### OFF TIMER

Specify the time duration to maintain the backlight turned on after the device is operated.

###### Selection / Range

Off timer	1 to 999 seconds
-----------	------------------

##### UPDATE RATE

Specify the time rate in which measurands are updated on the display. With '0,' the display is updated in the maximum possible rate.

This setting is irrelevant for the display's flashing in case of alarms.

###### Selection / Range

Update rate	0 to 60 seconds
-------------	-----------------

##### BRIGHTNESS

Three levels of brightness can be selected using the sliding bar on the screen.

###### Selection

Left	Dark
Center	Normal
Right	Bright

## 6.1.2 DISPLAY

### DATA DISPLAY VIEW

Specify which measuring variable you want to show on the 1st to 3rd line data displays. Enter the view number described in the flowchart in the 53U instruction manual (EM-6485-B).

### ENERGY DISPLAY VIEW

Specify which energy variable you want to show on the 4th line energy display.

Selection	
Energy display view	EP / Active energy, incoming EQ / Reactive energy, lag ES / Apparent energy EP- / Active energy, outgoing EQ- / Reactive energy, lead EQ+LAG / Reactive energy, lag, incoming EQ+ LEAD / Reactive energy, lead, incoming EQ-LAG / Reactive energy, lag, outgoing EQ-LEAD / Reactive energy, lead, outgoing EQ+P / Reactive energy, incoming *1 EQ-P / Reactive energy, outgoing *1 EPA / Active energy, (incoming – outgoing) *1 EQA / Reactive energy, (incoming + outgoing) *1 TIMER / Energy count time
	L-EP / Active energy, incoming, off-peak (low tariff) L-EQ / Reactive energy, lag, off-peak (low tariff) L-ES / Apparent energy, off-peak (low tariff) L-EP- / Active energy, outgoing, off-peak (low tariff) L-EQ- / Reactive energy, lead, off-peak (low tariff) L-EQ+LAG / Reactive energy, lag, incoming, off-peak (low tariff) L-EQ+LEAD / Reactive energy, lead, incoming, off-peak (low tariff) L-EQ-LAG / Reactive energy, lag, outgoing, off-peak (low tariff) L-EQ-LEAD / Reactive energy, lead, outgoing, off-peak (low tariff) L-EQ+P / Reactive energy, incoming (low tariff) *1 L-EQ-P / Reactive energy, outgoing (low tariff) *1 L-EPA / Active energy, (incoming – outgoing) (low tariff) *1 L-EQA / Reactive energy, (incoming + outgoing) (low tariff) *1 L-TIMER / Energy count time, off-peak (low tariff)

\*1. Available for the 53U and 54U Firmware Ver.2.00 or later, and all versions of the 54UL and 54UC

Choose 'k' if you want to add 'k' to the engineering unit indication. When the energy count time is specified, the unit is fixed at 'h.'

### KEY OPERATION LOCK

You can prohibit the device from unwanted operating and/or unauthorized programming changes.

Selection	
All key operations are available.	
All key operations are locked.	All keys locked except the operation to go to the infrared communication mode with the 54U, 54UL and 54UC.
Lock the key operation to go to Setting mode only	Key function to enter the programming mode (keep pressing E PRG key) is disabled. All other key operations to switch display views are available.

### 6.1.3 MY DEFAULT

You can choose a specific view to which the display always returns after a specified time while keys are untouched, or with single button control (hold down  $\Sigma$  button).

The  $\Sigma$  display automatically switches every 10 seconds from  $\Sigma 1$  through  $\Sigma 4$  (53U) or through  $\Sigma 6$  (54U, 54UL, and 54UC) when this is set to '-1.' (Available for the 53U Firmware Ver.2.00 or later, all versions of the 54U, 54UL and 54UC)

#### DATA DISPLAY VIEW & ENERGY DISPLAY VIEW

Specify the display view No. and the energy display type you want to return to.

#### USE PRESET TIMER

When you choose this selection, you can specify the time to return to My Default view if key are untouched.

Selection / Range	
Use preset timer	1 to 999 seconds

### 6.1.4 AUTO OFF

Select the time from finishing the device operation to turning off the display automatically.

Off
1 minute
5 minutes
10 minutes

Select Off to remain the display on continually.

### 6.1.5 DISPLAY BRIGHTNESS

Select the display brightness.

Low brightness
Standard brightness

### 6.1.6 DISPLAY FORMAT

Select the display range of measurement value.

#### Energy volume

Selection	Description
AUTO	Switch display range automatically according to measurement value.
0.00k	Display the digit of range from 000.00k to 999.99k.
0.0k	Display the digit of range from 0000.0k to 9999.9k.
0k	Display the digit of range from 00000k to 99999k.
0.000M	Display the digit of range from 00.000M to 99.999M.
0.00M	Display the digit of range from 000.00M to 999.99M.
0.0M	Display the digit of range from 0000.0M to 9999.9M.

When measurement value is out of display range, the upper limit value is not displayed. The digit in the display range is displayed.

## Energy

Selection	Description
AUTO	Switch display range automatically according to measurement value.
0.0	Display the range from -999.9 to 9999.9 with first decimal digit.
0	Display the range from -9999 to 99999 with no decimal digit.
0.000k	Display the range from -9.999k to 99.999k with three decimal digits.
0.00k	Display the range from -99.99k to 999.99k with two decimal digits.
0.0k	Display the range from -999.9k to 9999.9k with first decimal digit.
0k	Display the range from -9999k to 99999k with no decimal digit.
0.000M	Display the range from -9.999M to 99.999M with three decimal digits.
0.00M	Display the range from -99.99M to 999.99M with two decimal digits.
0.0M	Display the range from -999.9M to 999.9M with first decimal digit.

When energy value is out of display range, upper limit value or lower limit value in display range is displayed.

## Current

Selection	Description
AUTO	Switch display range automatically according to measurement value.
0.000	Display the range from 0.000 to 99.999 with three decimal digits.
0.00	Display the range from 0.00 to 999.99 with two decimal digits.
0.0	Display the range from 0.0 to 9999.9 with first decimal digit.
0	Display the range from 0 to 99999 with no decimal digit.
0.000K	Display the range from 0.000k to 99.999k with three decimal digits.
0.00K	Display the range from 0.00k to 99.99k with two decimal digits.
0.0K	Display the range from 0.0k to 99.9k with first decimal digit.

When current value is out of display range, upper limit value of display range is displayed.

## Voltage

Selection	Description
AUTO	Switch display range automatically according to measurement value.
0.00	Display the range from 0.00 to 999.99 with two decimal digits.
0.0	Display the range from 0.0 to 9999.9 with first decimal digit.
0	Display the range from 0 to 99999 with no decimal digit.
0.000k	Display the range from 0.000k to 99.999k with three decimal digits.
0.00k	Display the range from 0.00k to 999.99k with two decimal digits.
0.0k	Display the range from 0.0k to 999.9k with first decimal digit.

When voltage value is out of display range, upper limit value of display range is displayed.

## Power factor

Selection	Description
0.000	Display the range from -1.000 to 1.000 with three decimal digits.
0.00	Display the range from -1.00 to 1.00 with two decimal digits.


## Frequency

Selection	Description
0.00	Display the range from 0.00 / 40.00 to 70.00 with two decimal digits.
0.0	Display the range from 0.0 / 40.0 to 70.0 with first decimal digit.

### 6.1.7 ACTIVE DISPLAY

When unused circuit is unchecked, circuits can be switched by the device operation, and display can be skipped. Circuit A cannot be unchecked, so the display cannot be skipped.

## 6.2 EXTENSION BAR



This option is available for the 54U, 54UL and 54UC.


The measurand on the first line of the display is also on the bargraph. The following nine (9) parameters are selectable.

#### ■ EXTENSION BAR SETTING

ID	DEFINITION	100% RANGE VALUE		0% RANGE VALUE		UNIT
		MINIMUM	MAXIMUM	MINIMUM	MAXIMUM	
I	Current	0.000	20 000.000	0.000	20 000.000	A
U	Voltage	0.00	400 000.00	0.00	400 000.00	V
P	Active power	0	2 000 000 000	-2 000 000 000	2 000 000 000	W
Q	Reactive power	0	2 000 000 000	-2 000 000 000	2 000 000 000	var
S	Apparent power	0	2 000 000 000	0	2 000 000 000	VA
PF	Power factor	0.0000	1.0000	-1.0000	1.0000	cos $\phi$
F	Frequency	45.00	65.00	45.00	65.00	Hz
THD	Total harmonic distortion	0.0	999.9	0.0	999.9	%
PHASE DIF	Phase angle between voltages	0	180	-180	180	°*

\*No unit indication on the module

## 6.3 Σ DISPLAY



This option is available for the 53U Firmware Ver.2.00 or later, and all versions of the 54U, 54UL and 54UC.

### 53U

Four (4) Σ views are available. The following options are selectable for Line 1 through Line 3 of each view.

#### ■ 53U : Σ VIEW MEASURANDS & SELECTABLE POSITIONS (lines, X = selectable)

ID	PARAMETER	UNIT	LINE 1	LINE 2	LINE 3
NULL	Undefined	----	X	X	X
I	Current	A	X		
U	Voltage	V			X
P	Active power	W		X	
Q	Reactive power	var		X	
S	Apparent power	VA		X	
PF	Power factor	PF			X
F	Frequency	Hz			X

### 54U, 54UL and 54UC

Six (6) Σ views are available. The following options are freely selectable for Line 1 through Line 3 of each view. Energy and Count Time is selectable for only Line 4.

■ 54U, 54UL and 54UC : Σ VIEW MEASURANDS


ID	PARAMETER
NULL	Undefined
I	Current
U	Voltage
P	Active power
Q	Reactive power
S	Apparent power
PF	Power factor
F	Frequency
I1	Current, Line 1
I2	Current, Line 2
I3	Current, Line 3
IN	Current, Neutral *1
U12	Delta voltage, 1 – 2
U23	Delta voltage, 2 – 3
U31	Delta voltage, 3 – 1
U1N	Phase voltage, Phase 1
U2N	Phase voltage, Phase 2
U3N	Phase voltage, Phase 3
P1	Active power, Phase 1
P2	Active power, Phase 2
P3	Active power, Phase 3
Q1	Reactive power, Phase 1
Q2	Reactive power, Phase 2
Q3	Reactive power, Phase 3
S1	Apparent power, Phase 1
S2	Apparent power, Phase 2
S3	Apparent power, Phase 3
PF1	Power factor, Phase 1
PF2	Power factor, Phase 2
PF3	Power factor, Phase 3
THDI1	Current total harmonic distortion, Line 1
THDI2	Current total harmonic distortion, Line 2
THDI3	Current total harmonic distortion, Line 3
THDIN	Total harmonic distortion, Neutral *1
THDU12	Delta voltage total harmonic distortion, 1 – 2
THDU23	Delta voltage total harmonic distortion, 2 – 3
THDU31	Delta voltage total harmonic distortion, 3 – 1
THDU1N	Phase voltage total harmonic distortion, Phase 1
THDU2N	Phase voltage total harmonic distortion, Phase 2
THDU3N	Phase voltage total harmonic distortion, Phase 3
UT12	Phase angle between Phase 1 – 2 voltages
UT23	Phase angle between Phase 2 – 3 voltages
UT31	Phase angle between Phase 3 – 1 voltages
EP	Active energy, high tariff, incoming
EQ	Reactive energy, high tariff, LAG
ES	Apparent energy, high tariff
EP–	Active energy, high tariff, outgoing
EQ–	Reactive energy, high tariff, LEAD
EQ+LAG	Reactive energy, high tariff, incoming, LAG
EQ+LEAD	Reactive energy, high tariff, incoming, LEAD
EQ–LAG	Reactive energy, high tariff, outgoing, LAG
EQ–LEAD	Reactive energy, high tariff, outgoing, LEAD
TIMER	Energy count time, high tariff
L-EP	Active energy, low tariff, incoming
L-EQ	Reactive energy, low tariff, LAG
L-ES	Apparent energy, low tariff
L-EP–	Active energy, low tariff, outgoing
L-EQ–	Reactive energy, low tariff, LEAD
L-EQ+LAG	Reactive energy, low tariff, incoming, LAG
L-EQ+LEAD	Reactive energy, low tariff, incoming, LEAD

ID	PARAMETER
L-EQ-LAG	Reactive energy, low tariff, outgoing, LAG
L-EQ-LEAD	Reactive energy, low tariff, outgoing, LEAD
L-TIMER	Energy count time, low tariff
EQ+P	Reactive energy, high tariff, incoming <sup>*2</sup>
EQ-P	Reactive energy, high tariff, outgoing <sup>*2</sup>
EPA	Active energy, high tariff, (incoming - outgoing) <sup>*2</sup>
EQA	Reactive energy, high tariff, (incoming + outgoing) <sup>*2</sup>
L-EQ+P	Reactive energy, low tariff, incoming <sup>*2</sup>
L-EQ-P	Reactive energy, low tariff, outgoing <sup>*2</sup>
L-EPA	Active energy, low tariff, (incoming - outgoing) <sup>*2</sup>
L-EQA	Reactive energy, low tariff, (incoming + outgoing) <sup>*2</sup>

\*1. Available for the 54U-2, 54UL-2 and 54UC-2

\*2. Available for the 54U Firmware Ver.2.00 or later, and all versions of the 54UL and 54UC

## 6.4 DISPLAY EXPRESSION



### INPUT LINE INDICATION

Selection

1 - 2 - 3

*1R-2S 1R-2S*  
*2S-3T 2S-3T*  
*3T-1R 3T-1R*

R - S - T

*1R-2S 1R-2S*  
*2S-3T 2S-3T*  
*3T-1R 3T-1R*

### PHASE DIRECTION INDICATION

Selection

inductive / capacitive

*cap cap*  
*ind ind*  
*LEAG LEAG*

LAG / LEAD

*cap cap*  
*ind ind*  
*LEAG LEAD*

### POWER FORMAT


Selection

Use k if power <= 9999 0.0000k ... 9.999k

No use k if power <= 9999 0 ... 9999 (10.00k at 10 000)

## 6.5 SHORT CUT

Specify either you want to use the shortcut command to reset alarm






## 7. EXTERNAL INTERFACE PARAMETERS

External interface parameters specify the settings of the external interface installed on the device.

### 7.1 DISCRETE INPUT



#### FUNCTION

Specify which function you want to assign for the device's discrete input terminals.

Selection

---

No function                      Undefined

---

Update demand value

---

Reset energy count

---

Reset alarm

---

Switch tariff

#### CONTACT TYPE

Selection


---

Normal open

---

Normal closed

### 7.2 DISCRETE OUTPUT



#### FUNCTION

Specify which function you want to assign for the device's discrete output terminals Do 1 ... Do 4. You cannot assign those which are not provided as hardware.

Selection

---

No function                      Undefined

---

Energy count

---

Alarm status

For the M50XWTU and M50EXWTU, function is fixed to the energy count. It is not changeable.

#### CONTACT TYPE

Selection

---

Normal open


---

Normal closed


## ENERGY DETAIL

Clicking [Energy] button opens detailed energy setting window. (See Section 7.3)

## 7.3 ENERGY



Other than M50XWTU



M50XWTU, M50EXWTU

Define energy count parameters for pulse output. In order to have an energy count output, be sure to set 'Discrete output function' to 'Energy count' as explained in Section 7.2.

### ENERGY COUNT

Specify which energy parameter you want to supply to the pulse count output.

Choose from the tables below and in the following page.

#### PULSE WEIGHT

Specify how much energy value corresponds to one pulse.

Selection / Range

Pulse weight	0.1 to 10000.0 k (Wh/varh/VAh) (0.01 to 1000.00k (Wh/varh/VAh) for M50XWTU and M50EXWTU)
--------------	--

#### PULSE DURATION

Specify the output pulse width appropriate for a receiving instrument.

Selection / Range

Pulse duration	100 to 2000 milliseconds (in 100 msec. increments)
----------------	--

#### PULSE OUTPUT CIRCUIT

Select the circuit that outputs pulse. By selecting multiple circuits, pulses can be output according to the total amount of energy.

Note: Select only necessary circuits.

#### ■ 53U Firmware Ver.1.02 or earlier & 54U Firmware Ver.1.03 or earlier : ENERGY COUNT

ID	PARAMETER
EP	Active energy, incoming
EQ	Reactive energy, LAG
ES	Apparent energy
EP-	Active energy, outgoing
EQ-	Reactive energy, LEAD
EQ+LAG	Reactive energy, incoming, LAG
EQ+LEAD	Reactive energy, incoming, LEAD
EQ-LAG	Reactive energy, outgoing, LAG
EQ-LEAD	Reactive energy, outgoing, LEAD

#### ■ 53U Firmware Ver.2.00 or later, 54U Firmware Ver.2.00 or later, and all versions of 54UL, 54UC and L53U : ENERGY COUNT

ID	PARAMETER
T-EP	Active energy, incoming
T-EQ	Reactive energy, LAG
T-ES	Apparent energy
T-EP-	Active energy, outgoing
T-EQ-	Reactive energy, LEAD
T-EQ+LAG	Reactive energy, incoming, LAG
T-EQ+LEAD	Reactive energy, incoming, LEAD

ID	PARAMETER
T-EQ-LAG T-EQ-LEAD	Reactive energy, outgoing, LAG Reactive energy, outgoing, LEAD
T-EQ+P T-EQ-P	Reactive energy, incoming Reactive energy, outgoing
T-EQA	Reactive energy, (incoming + outgoing)
EP	Active energy, high tariff, incoming
EQ	Reactive energy, high tariff, LAG
ES	Apparent energy, high tariff
EP-	Active energy, high tariff, outgoing
EQ-	Reactive energy, high tariff, LEAD
EQ+LAG EQ+LEAD	Reactive energy, high tariff, incoming, LAG Reactive energy, high tariff, incoming, LEAD
EQ-LAG EQ-LEAD	Reactive energy, high tariff, outgoing, LAG Reactive energy, high tariff, outgoing, LEAD
EQ+P EQ-P	Reactive energy, high tariff, incoming Reactive energy, high tariff, outgoing
EQA	Reactive energy, high tariff, (incoming + outgoing)
L-EP	Active energy, low tariff, incoming
L-EQ	Reactive energy, low tariff, LAG
L-ES	Apparent energy, low tariff
L-EP-	Active energy, low tariff, outgoing
L-EQ-	Reactive energy, low tariff, LEAD
L-EQ+LAG L-EQ+LEAD	Reactive energy, low tariff, incoming, LAG Reactive energy, low tariff, incoming, LEAD
L-EQ-LAG L-EQ-LEAD	Reactive energy, low tariff, outgoing, LAG Reactive energy, low tariff, outgoing, LEAD
L-EQ+P L-EQ-P	Reactive energy, low tariff, incoming Reactive energy, low tariff, outgoing
L-EQA	Reactive energy, low tariff, (incoming + outgoing)

■ M5XWTU-1x2, M50XWTU, M50EXWTU : ENERGY COUNT

ID	PARAMETER
EP	Active energy, incoming
EQ	Reactive energy, LAG
ES	Apparent energy
EP-	Active energy, outgoing
EQ-	Reactive energy, LEAD
EQ+LAG EQ+LEAD	Reactive energy, incoming, LAG Reactive energy, incoming, LEAD
EQ-LAG EQ-LEAD	Reactive energy, outgoing, LAG Reactive energy, outgoing, LEAD
EQ+P EQ-P	Reactive energy, incoming Reactive energy, outgoing
EQA	Reactive energy, (incoming + outgoing)

## 7.4 ANALOG OUTPUT

	Ao1	Ao2	Ao3	Ao4
Input	(NULL)	(NULL)	(NULL)	(NULL)
Adjust zero	0.00 (%)	0.00 (%)	0.00 (%)	0.00 (%)
Adjust span	100.00 (%)	100.00 (%)	100.00 (%)	100.00 (%)
Linearizer	Linear	Linear	Linear	Linear
Input 0%	0.00 (%)	0.00 (%)	0.00 (%)	0.00 (%)
Output 0%	4.00 (mA)	4.00 (mA)	4.00 (mA)	4.00 (mA)
Input 100%	100.00 (%)	100.00 (%)	100.00 (%)	100.00 (%)
Output 100%	20.00 (mA)	20.00 (mA)	20.00 (mA)	20.00 (mA)
Table X[0]	0.00 (%)	0.00 (%)	0.00 (%)	0.00 (%)
Table Y[0]	4.00 (mA)	4.00 (mA)	4.00 (mA)	4.00 (mA)
Table X[1]	0.00 (%)	0.00 (%)	0.00 (%)	0.00 (%)
Table Y[1]	4.00 (mA)	4.00 (mA)	4.00 (mA)	4.00 (mA)
Table X[2]	0.00 (%)	0.00 (%)	0.00 (%)	0.00 (%)
Table Y[2]	4.00 (mA)	4.00 (mA)	4.00 (mA)	4.00 (mA)
Table X[3]	0.00 (%)	0.00 (%)	0.00 (%)	0.00 (%)
Table Y[3]	4.00 (mA)	4.00 (mA)	4.00 (mA)	4.00 (mA)
Table X[4]	0.00 (%)	0.00 (%)	0.00 (%)	0.00 (%)
Table Y[4]	4.00 (mA)	4.00 (mA)	4.00 (mA)	4.00 (mA)
Table X[5]	0.00 (%)	0.00 (%)	0.00 (%)	0.00 (%)
Table Y[5]	4.00 (mA)	4.00 (mA)	4.00 (mA)	4.00 (mA)
Table X[6]	0.00 (%)	0.00 (%)	0.00 (%)	0.00 (%)
Table Y[6]	4.00 (mA)	4.00 (mA)	4.00 (mA)	4.00 (mA)
Table X[7]	0.00 (%)	0.00 (%)	0.00 (%)	0.00 (%)

Specify which function you want to assign for the device's analog output terminals Ao 1 ... Ao 4.

You cannot assign those which are not provided as hardware.

You can conduct fine adjustments, set scaling and linearization table for each assigned output.

### INPUT

Choose measurand from the table below.

#### ■ PARAMETERS TO BE ASSIGNED TO ANALOG OUTPUTS

ID	DEFINITION	RANGE (0 to 100%)
NULL	Not assigned *2	
I	Current	0 to CT primary rating
U	Voltage	0 to VT primary rating
P	Active power	$\pm$ (VT primary rating $\times$ CT primary rating $\times$ n) *1
Q	Reactive power	$\pm$ (VT primary rating $\times$ CT primary rating $\times$ n) *1
S	Apparent power	0 to (VT primary rating $\times$ CT primary rating $\times$ n) *1
PF	Power factor	-1.0000 to + 1.0000
F	Frequency	45.00 to 65.00
I1	Current, Line 1	0 to CT primary rating
I2	Current, Line 2	0 to CT primary rating
I3	Current, Line 3	0 to CT primary rating
IN *3	Neutral current	0 to CT primary rating
U12	Delta voltage, Line 1 – 2	0 to VT primary rating
U23	Delta voltage, Line 2 – 3	0 to VT primary rating
U31	Delta voltage, Line 3 – 1	0 to VT primary rating
U1N	Phase voltage, Phase 1	0 to VT primary rating
U2N	Phase voltage, Phase 2	0 to VT primary rating
U3N	Phase voltage, Phase 3	0 to VT primary rating
P1	Active power, Phase 1	$\pm$ (VT primary rating $\times$ CT primary rating $\times$ n) *1
P2	Active power, Phase 2	$\pm$ (VT primary rating $\times$ CT primary rating $\times$ n) *1
P3	Active power, Phase 3	$\pm$ (VT primary rating $\times$ CT primary rating $\times$ n) *1
Q1	Reactive power, Phase 1	$\pm$ (VT primary rating $\times$ CT primary rating $\times$ n) *1
Q2	Reactive power, Phase 2	$\pm$ (VT primary rating $\times$ CT primary rating $\times$ n) *1
Q3	Reactive power, Phase 3	$\pm$ (VT primary rating $\times$ CT primary rating $\times$ n) *1
S1	Apparent power, Phase 1	0 to (VT primary rating $\times$ CT primary rating $\times$ n) *1
S2	Apparent power, Phase 2	0 to (VT primary rating $\times$ CT primary rating $\times$ n) *1
S3	Apparent power, Phase 3	0 to (VT primary rating $\times$ CT primary rating $\times$ n) *1
PF1	Power factor, Phase 1	-1.0000 to + 1.0000
PF2	Power factor, Phase 2	-1.0000 to + 1.0000
PF3	Power factor, Phase 3	-1.0000 to + 1.0000
THDI1	THD, Current, Line 1	0.0 to 100.0
THDI2	THD, Current, Line 2	0.0 to 100.0
THDI3	THD, Current, Line 3	0.0 to 100.0
THDIN *3	THD, Neutral current	0.0 to 100.0

ID	DEFINITION	RANGE (0 to 100%)
THDU12	THD, Delta voltage, Line 1 – 2	0.0 to 100.0
THDU23	THD, Delta voltage, Line 2 – 3	0.0 to 100.0
THDU31	THD, Delta voltage, Line 3 – 1	0.0 to 100.0
THDU1N	THD, Phase voltage, Phase 1	0.0 to 100.0
THDU2N	THD, Phase voltage, Phase 2	0.0 to 100.0
THDU3N	THD, Phase voltage, Phase 3	0.0 to 100.0
T-Q	Reactive power for bidirectional current	$Q_{max} = (CT \text{ primary rating}) \times (VT \text{ primary rating}) \times n^{*1*4}$ 
T-PF	Power factor for bidirectional current	 *4

\*1. Single-phase/2-wire: n = 1, Single-phase/3-wire: n = 2, Three-phase/3-wire:  $n = 3 / \sqrt{3}$ , Three-phase/4-wire: n = 3

\*2. When an output is re-assigned to 'Not Assigned' during measuring, the output value is held until the power supply is turned off.

\*3. Available for the 53U, L53U and M5XWTU, the 54U, 54UC and 54UL with firmware version 3.00 or later, and all versions of 54U, 54UL and 54UC with 3-phase/4-wire input.

\*4. For M5XWTU firmware version 1.2.9 or later 2.10 or later, and for L53U firmware version 2.10 or later.

Input 0%      0.00% - 24.99% (Outgoing, LEAD)

Input 100%    75.01% - 100.00% (Incoming, LAG)


The above conditions are satisfied, the module operates as follows.

Outgoing      Outputs (input 0%) - (input 100% - 50%) as output 0% - 50%

Incoming      Outputs (50% + input 0%) - (input 100%) as output 50% - 100%.

E.g.)  $Q_{max}=1000 \text{ var}$ , to set scaling for 400 var for LEAD, and 500 var for LAG,

Input 0% =  $(1000 - 400) / 1000 \times 25 = 15\%$ , input 100% =  $100 - (1000 - 500) / 1000 \times 25 = 87.5\%$  (100-12.5)%



## ADJUST ZERO / ADJUST SPAN

Analog output can be finely calibrated using Adjust Zero and Adjust Span by the following equation:

$$\text{Analog Output} = (\text{Output Value} - \text{Analog 0\%}) \times \text{Adjust Fine} + \text{Analog 0\%} + [\text{Adjust Zero} \times (\text{Analog 100\%} - \text{Analog 0\%})]$$

Where

Analog 0% = 4mA or 1V, output 0% or lower limit value set by the table for M5XWTU

Analog 100% = 20mA or 5V, output 0% or lower limit value set by the table for M5XWTU

Adjust Zero, Adjust Span 100.00% = 1.0000

Zero is adjustable within  $\pm 5\%$ , while Span is adjustable from 95.00 to 105.00%.

## LINEARIZER

Specify whether the output is proportional to the input or to be linearized. When 'Table' is selected, the segment data is specified with Table X[0] ... Table X[9] and Table Y[0] ... Table Y[9].

Selection / Range	
Linear	Proportional to the input
Table	Linearized output

## INPUT 0% / OUTPUT 0% / INPUT 100% / OUTPUT 100%

When 'Linear' is selected with 'Linearizer,' the output range is scaled using these parameters.

$$\text{Output} = \frac{\text{Input} - \text{Input 0\%}}{\text{Input 100\%} - \text{Input 0\%}} \times (\text{Output 100\%} - \text{Output 0\%}) + \text{Output 0\%}$$

[Note] Input value in engineering unit is first converted into percentage of the full-scale range before provided to the above equation.

Input 0% and Input 100% are selectable from -15.00 to 140.00%.

Output 0% and Output 100% is selectable from 1.60 to 22.40mA (4 to 20 mA range), or from 0.400 to 5.600V (1 to 5V range).

## TABLE X[0] ... TABLE X[9] / TABLE Y[0] ... TABLE Y[9]

When 'Table' is selected with 'Linearizer,' the segment data table must be set.

Table consists of ten (10) pairs of X (input) and Y (output) values. When the input is equal to X[n], Y[n] is provided as output.

When the input is between X[n-1] and X[n], the output is provided by the following equation.


$$\text{Output} = \frac{\text{Input} - \text{Table X}[n-1]}{\text{Table X}[n] - \text{Table X}[n-1]} \times (\text{Table Y}[n] - \text{Table Y}[n-1]) + \text{Table Y}[n-1]$$

[Note] Input value in engineering unit is first converted into percentage of the full-scale range before provided to the above equation.


Segment data must be arranged in ascending order, i.e. X[n] must be greater than X[n-1]. For example, if you have set X[7] smaller than X[6], Table X[7] and later values are not used. Linearization is complete with data from X[0] to X[6].

When the input value is lower than X[0], the output equals Y[0]. When the input is higher than X[max], the output equals Y[max].


## 7.5 MODBUS



For 53U, 54U, L53U, M5XWTU, M5XWT, M50XWTU, and M50EXWTU



For R7MWTU, R9MWTU



For R7EWTU, R9EWTU

Modbus communication parameters are applied only when the device is restarted (power is turned off and on). Only 'downloading' modified parameters does not affect the device operation.

### DEVICE ADDRESS

Selection / Range

Device address	1 to 247
----------------	----------

### TRANSFER RATE

Selection / Range

Transfer rate	1200 bps
	2400 bps
	4800 bps
	9600 bps
	19200 bps
	38400 bps

### PARITY BIT

Selection / Range

Parity bit	None
	Odd
	Even

### STOP BIT

Selection / Range

Stop bit	1 bit
	2 bit

### MODE

Modbus transmission mode is selectable with the items detailed below.

RTU (7bit)
ASCII (8bit)

### IP ADDRESS, SUBNET MASK, DEFAULT GATEWAY

Specify IP address, subnet mask, default gateway for Modbus/TCP.

### PORT NO.

Specify the TCP port number for Modbus/TCP. The setting range is 0 to 65535.

### CONNECTION TIME OUT


Modbus/TCP connection is severed if no communication is established for the specified time period. The setting range is 0.0 to 3200.0 sec.

### RUN LED TIMEOUT

RUN LED turns off to inform an error when there is an interruption of reading query from the master Modbus module and the specified time passes. The setting range is 0.0 to 3200.0 sec.

Click [Advanced] button to go to 'Advanced Modbus Setting' (See 7.6).

## 7.6 ADVANCED MODBUS SETTING



### LONG REGISTER (32-bit words assignments)

Specify the order of lower digits and higher digits in sending a 32-bit word data.

Selection

Normal (low first)	Lower digit word assigned to the lower address
Swap (high first)	Higher digit word assigned to the lower address

### PROTOCOL OPERATION TIMER

Specify the character length for t1.5 and t3.5 timers. Modbus defines t1.5 timer as 1.5 character, and t3.5 timer as 3.5 character. These settings should not be changed in normal circumstances. Change these settings only upon our customer support's suggestion.

Selection / Range

t1.5	0.1 to 6.0 characters
t3.5	0.1 to 6.0 characters


### Caution !

Modbus communication parameters are applied only when the device is restarted (power is turned off and on).

Only 'downloading' modified parameters does not affect the device operation.

M5XWTU, M5XWT, M50XWTU, and M50EXWTU cannot set.

## 7.7 CC-Link



CC-Link communication parameters are applied only when the device is restarted (power is turned off and on). Only 'downloading' modified parameters does not affect the device operation.

### NODE ADDRESS

Selection / Range

Node address	1 to 64
--------------	---------

### TRANSFER RATE

Selection / Range

Transfer rate	156 kbps
	625 kbps
	2.5 Mbps
	5 Mbps
	10 Mbps